

## OIVO TP4-1785

# OIVO PS4 Stand Instruction Manual

Model: TP4-1785

## INTRODUCTION

The OIVO PS4 Stand is a multi-functional accessory designed to enhance your PlayStation 4 gaming experience. It serves as a vertical stand for your console, provides efficient cooling with integrated fans, and includes a dual charging dock for your PS4 controllers. Additionally, it offers convenient storage for up to 12 game cases, helping to keep your gaming area organized.

This stand is compatible with the original PlayStation 4, PS4 Slim, and PS4 Pro consoles.



Figure 1: The OIVO PS4 Stand with a PlayStation 4 console and two controllers docked for charging. The image highlights the vertical orientation of the console and the integrated controller charging stations.

## SETUP GUIDE

1. **Unpack the Stand:** Carefully remove all components from the packaging. Ensure all parts are present, including the main stand unit and any adapters.
2. **Console Placement:**
  - For **PS4 Slim**: Attach the included adapter to the bottom of your PS4 Slim console before placing it into the stand. This adapter ensures a secure fit.
  - For **PS4 Pro** and **Regular PS4**: Place your console directly into the vertical slot of the stand. Ensure it is seated firmly and securely.

# Vertical Stand For PS4 Slim/PS4 Pro/Regular PS4



Figure 2: This diagram illustrates how the OIVO PS4 Stand accommodates different PlayStation 4 models: PS4 Slim (with adapter), PS4 Pro, and the original Regular PS4. Each console type is shown vertically mounted on the stand.

3. **Power Connection:** Connect the provided USB cable from the OIVO PS4 Stand to a power source.
- The stand can be powered directly from your PS4 console's USB port.
  - Alternatively, you can use a USB adapter, USB HUB, or a wall adapter for power.

# VARIOUS POWER SUPPLY WAYS



Figure 3: This image displays the different methods to power the OIVO PS4 Stand, including connecting to a USB adapter, USB HUB, wall adapter, or directly to the PS4 console. A 20cm/7.9in USB cable is shown.

4. **Controller Charging Ports:** The stand features two charging docks for PS4 controllers. These docks utilize the EXT port on the controllers for faster charging.
5. **Game Storage:** Utilize the 12 integrated slots on the side of the stand to store your game cases vertically.



Figure 4: A detailed view of the OIVO PS4 Stand, highlighting its various components: 12 game storage slots, two cooling fans, a durable charging port with earphone jack, a USB port for power, an ON/OFF button, and a USB charging & data transmission port.

## OPERATING INSTRUCTIONS

### Cooling Fan Operation

- **Activating Fans:** After connecting the power and placing your console, press the ON/OFF button located on the stand to activate the cooling fans. The fans operate quietly, with noise levels as low as 50dB.
- **Cooling Efficiency:** The integrated fans work to dissipate heat from your PlayStation 4 console, helping to maintain optimal operating temperatures during extended gaming sessions. The stand features a metal bottom for improved heat conduction.

# Improved Cooling System

Higher speed, lower noise



Figure 5: This image highlights the "Improved Cooling System" of the OIVO PS4 Stand, showing blue airflow arrows indicating the cooling effect from the fans. It emphasizes higher speed and lower noise operation, with a comparison of fan types.

## Controller Charging

- **Placing Controllers:** Gently place your PS4 controllers onto the charging docks, ensuring the EXT port aligns correctly with the charging pin.
- **LED Indicators:** The charging docks feature LED indicators to show the charging status:
  - **Red Light:** Indicates that the controller is currently charging.
  - **Green Light:** Indicates that charging is complete, or the dock is in standby mode.
- **Charging Speed:** Charging through the EXT port provides a faster charging speed, typically completing a full charge in approximately 2 hours for dual controllers, compared to 4 hours via standard USB dongles.

# LED Indicators

2 hours for charging done dual controllers,  
saving your time and have more fun.



Figure 6: This image illustrates the LED indicators on the OIVO PS4 Stand's charging docks. It shows a timer indicating 2 hours for dual controller charging, with red light for charging and green light for fully charged/standby.



Figure 7: A close-up view of two PS4 controllers on the OIVO charging station. One controller's indicator shows a red light, signifying it is charging, while the other shows a green light, indicating it is fully charged or in standby.




Figure 8: This comparison image highlights two key advantages of the OIVO PS4 Stand: faster EXT charging (2 hours) compared to Micro USB charging (4 hours), and the use of a galvanized metal base for efficient cooling versus a plastic base that retains heat.

## MAINTENANCE

- **Cleaning:** Regularly wipe the stand with a soft, dry cloth to remove dust. Avoid using abrasive cleaners or solvents.
- **Fan Vents:** Ensure the fan vents are clear of obstructions to maintain optimal airflow and cooling performance. Periodically check for dust buildup and gently clean if necessary.
- **Charging Ports:** Keep the charging pins and controller EXT ports clean and free of debris to ensure reliable charging connections.

## TROUBLESHOOTING

- **Fans Not Turning On:**
  - Ensure the stand is properly connected to a power source.
  - Press the ON/OFF button on the stand to activate the fans. Even if the console is powered on, the fan button needs to be pressed separately.

- **Controllers Not Charging:**

- Verify that the controllers are correctly seated on the charging docks and the EXT port is fully engaged with the charging pin.
- Check the LED indicators; if no light appears, ensure the stand is powered.
- Try charging one controller at a time to isolate if the issue is with a specific dock or controller.

- **Console Not Stable in Stand:**

- Ensure the correct adapter is used for PS4 Slim models.
- Verify the console is fully inserted into the stand's slot.
- When removing controllers, place a hand on top of the PS4 console to stabilize it and prevent accidental tipping.

- **Cooling Performance Seems Low:**

- Ensure the fan vents on the stand and the console are not blocked by dust or other objects.
- While the fans are designed to be quiet, their cooling effect is supplementary. For consoles with pre-existing overheating issues, internal cleaning of the console may be required.

## SPECIFICATIONS

Feature	Detail
Product Dimensions	20.5 x 13.5 x 17 inches
Item Weight	1.59 pounds
Model Number	TP4-1785
Compatible Consoles	PS4, PS4 Slim, PS4 Pro
Controller Charging	Dual EXT Port Charger
Game Storage Slots	12
Cooling Fans	Integrated, low noise (approx. 50dB)
Power Supply	USB (via console, adapter, or HUB)
Manufacturer	OIVO
Country of Origin	China

## WARRANTY AND SUPPORT

For specific warranty information and customer support, please refer to the documentation included with your purchase or visit the official OIVO website or brand store. Contact details for support are typically provided by the retailer or manufacturer.

You can find more information about OIVO products at their official Amazon Brand Store [OIVO Brand Store](#).

## IMPORTANT NOTES

- This product is designed to be used with PlayStation 4 consoles and controllers only.

- Do not disassemble or attempt to repair the unit yourself. Refer to qualified service personnel.
- Keep the product away from water, moisture, and direct heat sources.