

LKPower 180130110

LKPower AC Adapter User Manual

FOR MEMOREX MC7101 AND MC7211 CD ALARM CLOCK RADIOS

Model: 180130110

Introduction

This manual provides essential information for the safe and effective use of your LKPower AC Adapter, specifically designed for Memorex MC7101 and MC7211 CD Alarm Clock Radios. This adapter converts standard AC wall power into the DC power required by your device, enabling operation and battery charging.

Safety Information

- Ensure the adapter is used with compatible devices only.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to severe impact.
- Do not attempt to open or repair the adapter. Refer to qualified personnel for service.
- Unplug the adapter from the power outlet when not in use for extended periods.

Setup

1. **Verify Compatibility:** Confirm that your device is a Memorex MC7101 or MC7211 CD Alarm Clock Radio. This adapter is specifically designed for these models.
2. **Connect to Device:** Insert the barrel connector end of the LKPower AC Adapter into the DC input port of your Memorex CD Alarm Clock Radio. Ensure a secure connection.
3. **Connect to Power Outlet:** Plug the AC adapter's two-prong plug into a standard electrical wall outlet (AC 100-240V, 50/60Hz).
4. **Power On Device:** Once connected, your Memorex CD Alarm Clock Radio should receive power and be ready for operation.



Figure 1: The LKPower AC Adapter, showing the main unit with the two-prong plug and the barrel connector cable.



Figure 2: Example of the AC adapter connected to a power strip, providing power to a device.

Operating

The LKPower AC Adapter is designed for straightforward operation. Once properly connected to a power outlet and your compatible Memorex device, it automatically supplies the necessary DC power. The adapter features an auto-sensing input voltage range of 100-240V AC, making it suitable for use in various regions without manual voltage selection.

Maintenance

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and excessive heat. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the cable and connectors for any signs of wear, fraying, or damage. Discontinue use if damage is observed.

Troubleshooting

- **Device Not Powering On:**
 - Ensure the adapter is securely plugged into both the wall outlet and the device.
 - Test the wall outlet with another device to confirm it is functional.
 - Verify that the Memorex device itself is in working order.
- **Adapter Feels Warm:** It is normal for the adapter to feel slightly warm during operation. If it becomes excessively hot, disconnect it immediately and contact support.

Specifications

Model Number	180130110
Input	AC 100-240V, 50/60Hz
Output	Compatible with Memorex MC7101/MC7211 requirements
Connector Type	Barrel Connector
Cable Length	76 inches (approx. 1.93 meters)
Dimensions (Adapter Unit)	2.6 inches (L) x 1.6 inches (W) x 1.2 inches (H)
Safety Features	Over Voltage Protection, Over Heat Protection




Figure 3: Dimensions of the adapter unit and cable length.

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt for warranty claims.

© 2024 LKPower. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question