

[Manuals.plus](#) /

› [TOPCHARGEUR](#) /

› TOPCHARGEUR 6V Power Adapter for Proform 275 ZLX Exercise Bike Instruction Manual

TOPCHARGEUR PFIVEX51811

TOPCHARGEUR 6V Power Adapter Instruction Manual

Model: PFIVEX51811

INTRODUCTION

Thank you for choosing the TOPCHARGEUR 6V Power Adapter. This manual provides essential information for the safe and efficient use of your new power adapter. Please read these instructions carefully before use and retain them for future reference.

This power adapter is designed to provide a stable 6V power supply for compatible devices, specifically the Proform 275 ZLX exercise bike (Model PFIVEX51811).

IMPORTANT SAFETY INFORMATION

- **Read all instructions:** Before using the power adapter, read all safety and operating instructions.
- **Proper Voltage:** Ensure the input voltage of your device matches the output voltage of this adapter (6V).
- **Polarity:** This adapter features a positive (+) center polarity. Verify your device requires this polarity to prevent damage.
- **Indoor Use Only:** This adapter is designed for indoor use in dry conditions. Do not expose to water, rain, or excessive humidity.
- **Avoid Damage:** Do not use the adapter if the cable or plug is damaged. Do not attempt to open or repair the adapter.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it.
- **Children:** Keep out of reach of children.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use for extended periods.

PACKAGE CONTENTS

Your package should contain the following item:

- 1 x TOPCHARGEUR 6V Power Adapter

SETUP INSTRUCTIONS

1. **Verify Compatibility:** Before connecting, ensure your device (e.g., Proform 275 ZLX exercise bike) requires a 6V power supply with positive center polarity. Refer to your device's manual for specific power requirements.
2. **Connect to Device:** Insert the barrel connector of the TOPCHARGEUR adapter firmly into the power input port of your device.
3. **Connect to Power Outlet:** Plug the AC power cord of the adapter into a standard 100-240V AC, 50-60Hz wall outlet.
4. **Power Indicator:** The adapter features an LED power indicator. Once plugged into a live outlet, the LED should illuminate, indicating power is being supplied.
5. **Power On Device:** You can now power on your device according to its own operating instructions.



Image: The TOPCHARGEUR 6V Power Adapter. This image shows the compact design of the adapter, featuring the barrel connector for device input and the standard AC plug for wall outlets. A small LED indicator is visible, which illuminates when the adapter is receiving power.

OPERATING INSTRUCTIONS

Once properly connected, the TOPCHARGEUR 6V Power Adapter operates automatically to supply power to your compatible device. There are no user-adjustable settings on the adapter itself.

- **Continuous Power:** The adapter provides continuous 6V DC power as long as it is plugged into a live AC outlet and connected to your device.
- **LED Indicator:** The integrated LED light indicates that the adapter is receiving power from the wall outlet. If the LED is off, check the wall outlet and the adapter's connection.
- **Disconnecting:** To disconnect power, first turn off your device, then unplug the adapter from the wall outlet, and finally disconnect the barrel connector from your device.

MAINTENANCE AND CARE

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or sprays.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as cuts, fraying, or bent pins. If damage is found, discontinue use and replace the adapter.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Adapter LED is off, device not receiving power.	◦ Adapter not properly plugged into wall outlet. ◦ Wall outlet is not live. ◦ Adapter cable or unit is damaged.	◦ Ensure the adapter is fully inserted into a working wall outlet. ◦ Test the wall outlet with another device. ◦ Inspect the adapter for visible damage. If damaged, replace it.
Device not powering on, but adapter LED is on.	◦ Incorrect voltage or polarity for the device. ◦ Device's power input port is faulty. ◦ Device itself is faulty. ◦ Barrel connector not fully inserted into device.	◦ Double-check your device's power requirements (voltage and polarity). This adapter is 6V, positive center. ◦ Ensure the barrel connector is securely plugged into the device. ◦ Consult your device's manual for troubleshooting its power issues.
Adapter feels excessively hot.	◦ Poor ventilation. ◦ Overload or internal fault.	◦ Ensure the adapter is in an open area with good airflow. ◦ Unplug immediately and discontinue use. Contact support if the issue persists.

PRODUCT SPECIFICATIONS

Brand	TOPCHARGEUR
Model	PFIVEX51811 (Compatible with Proform 275 ZLX)
Input Voltage	100-240V AC, 50-60Hz
Output Voltage	6V DC
Polarity	Positive (+) Center
Connector Type	Barrel Connector
Cable Length	120 cm (approximately 47 inches)
Color	Black

Material	Plastic
Certifications	FCC Compliant

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact TOPCHARGEUR customer service directly. Keep your proof of purchase for warranty claims.

For further assistance, please visit the TOPCHARGEUR website or contact your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question