

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Fisher-Price](#) /

› [Fisher-Price Think & Learn Rocktopus Instruction Manual](#)

Fisher-Price FXW98

Fisher-Price Think & Learn Rocktopus Instruction Manual

Model: FXW98

1. PRODUCT OVERVIEW

The Fisher-Price Think & Learn Rocktopus is an interactive musical toy designed to help children explore various musical styles, instruments, and rhythmic patterns. It encourages creativity and learning through engaging play modes.

Key Features:

- 15 unique musical instruments.
- 5 distinct musical styles.
- 3 interactive play modes: Math, Music, and Game.
- Responds to instrument insertion or tapping.
- Allows children to control tempo and add sound effects.
- Supports a free companion app for music video creation.

2. SETUP

Battery Installation:

The Rocktopus requires 2 D batteries (included). Locate the battery compartment, typically on the underside of the unit. Use a Phillips head screwdriver to open the compartment, insert the batteries according to the polarity indicators (+/-), and securely close the cover.

Initial Power On:

Once batteries are installed, locate the power switch (usually on the back or bottom of the unit) and slide it to the 'ON' position. The Rocktopus will greet you and be ready for play.

3. OPERATING INSTRUCTIONS

The Rocktopus offers three primary play modes and interactive instrument play.

Instrument Interaction:

The Rocktopus comes with 15 musical instrument pods. To play, insert an instrument pod into one of the Rocktopus's tentacles or tap an already inserted instrument. The Rocktopus will respond with sounds and lights corresponding to the instrument and current musical style.

Play Modes:

Select a play mode using the buttons on the Rocktopus's head:

- **Music Mode:** Allows children to mix and remix different musical styles and instruments. Add or remove instruments, control the tempo, and apply sound effects to create unique compositions.
- **Math Mode:** Engages children in mathematical concepts such as counting, addition, and subtraction through musical challenges.
- **Game Mode:** Features fast-paced games that require children to follow directions from the Rocktopus, helping to develop attention and listening skills.

Companion App:

Download the free Rocktopus app to enhance gameplay. The app allows children to create music videos with their compositions and provides additional interactive features. Follow the app's on-screen instructions for specific gameplay.

Description: Official product video demonstrating the Fisher-Price Think & Learn Rocktopus in action, showcasing its interactive features and musical capabilities.

4. MAINTENANCE

To ensure the longevity of your Fisher-Price Think & Learn Rocktopus, wipe the unit and instrument pods with a damp cloth. Do not immerse the toy in water. Avoid using harsh chemicals or abrasive cleaners. Store the toy and its accessories in a dry place away from direct sunlight.

5. TROUBLESHOOTING

If the Rocktopus is not functioning correctly, try the following steps:

- **No Power:** Check if the batteries are correctly installed and not depleted. Replace with fresh D batteries if necessary.
- **No Sound/Lights:** Ensure the power switch is fully in the 'ON' position. If using the app, check device volume settings.
- **Instrument Not Responding:** Ensure the instrument pod is fully inserted into the tentacle. Try a different instrument pod to see if the issue persists.
- **App Connectivity Issues:** Ensure your device's Bluetooth is enabled and the Rocktopus is within range. Restart both the app and the Rocktopus.

If problems persist, refer to the manufacturer's customer support information.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	5 x 5 x 5 inches
Item Weight	1 pound
Item Model Number	FXW98
Manufacturer Recommended Age	36 months - 6 years
Batteries	2 D batteries required (included)
Release Date	January 5, 2018
Manufacturer	Fisher-Price

7. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official Fisher-Price website or contact their customer service department. Specific warranty details may vary by region and purchase location.

© 2026 Fisher-Price. All rights reserved.