

[Manuals.plus](#) /

› [TIMBER RIDGE](#) /

› TIMBER RIDGE TR-FCH037 2-Person Folding Loveseat Instruction Manual

## TIMBER RIDGE TR-FCH037

# TIMBER RIDGE 2-Person Folding Loveseat Instruction Manual

Model: TR-FCH037

## 1. PRODUCT OVERVIEW

The TIMBER RIDGE 2-Person Folding Loveseat is a comfortable and portable seating solution designed for outdoor activities. This double chair is ideal for two individuals, offering a relaxed seating position with its lower height design. It features a lightweight yet sturdy steel frame and includes convenient cup holders.



*Image: The TIMBER RIDGE 2-Person Folding Loveseat in Grey, showcasing its overall design and two-person capacity.*

## **2. SETUP AND ASSEMBLY**

The TIMBER RIDGE 2-Person Folding Loveseat is designed for quick and easy setup. Simply remove the chair from its carrying bag and unfold it. Ensure all four legs are fully extended and locked into place for stability. The chair collapses to a compact size for convenient transport and storage.

Your browser does not support the video tag.

*Video: Official demonstration of unfolding and folding the Timber Ridge 2-Person Loveseat for easy setup and storage.*



*Image: Visual guide demonstrating the easy folding process of the loveseat for portability.*

### 3. OPERATING INSTRUCTIONS

Once set up, the loveseat provides comfortable seating for two. The adjustable armrests can be positioned to your preferred height for optimal comfort. Each armrest includes a mesh cup holder, suitable for beverages or small items.



*Image: A close-up view of the integrated cup holder on the armrest, designed for convenience.*

#### 4. MAINTENANCE AND CARE

- **Cleaning:** Wipe clean with a damp cloth.
- **Storage:** Store in a dry place when not in use to prevent damage from moisture or other elements.
- **Safety:** Keep away from open flames or high heat sources. Supervise children and pets to avoid entrapment risks.
- **Inspection:** Inspect the product regularly for any signs of damage or wear and tear. Follow the manufacturer's instructions for proper maintenance and care.

#### 5. SPECIFICATIONS

<b>Brand</b>	TIMBER RIDGE
<b>Model Name</b>	Comfortable Lawn Chairs Folding Outdoor Camping Loveseat Sports Chairs
<b>Model Number</b>	TR-FCH037
<b>Color</b>	Grey
<b>Material</b>	Alloy Steel Frame, Polyester Fabric
<b>Product Dimensions (Set Up)</b>	17.7"D x 41.3"W x 33.1"H
<b>Folding Size</b>	11.02" x 9.45" x 32.28"
<b>Item Weight</b>	10.47 Pounds
<b>Maximum Weight Recommendation</b>	500 Pounds
<b>Seat Height</b>	12.8 Inches
<b>Seat Depth</b>	17.7 Inches



WEIGHT CAPACITY **500 lbs**



PRODUCT WEIGHT **10.8 lbs**

*Image: Detailed dimensions of the loveseat when set up and folded.*

## 6. TROUBLESHOOTING

If you encounter any issues with your TIMBER RIDGE 2-Person Folding Loveseat, please check the following:

- **Stability:** Ensure all frame joints are fully extended and locked into place.
- **Folding/Unfolding:** If the chair is difficult to fold or unfold, gently manipulate the frame to align the joints. Avoid excessive force.
- **Damage:** Inspect the fabric and frame for any visible damage. Do not use the chair if it appears compromised.

For further assistance, please refer to the warranty and support information below.

## 7. WARRANTY AND SUPPORT

This TIMBER RIDGE 2-Person Folding Loveseat comes with a **1-year manufacturer's warranty**. For

warranty claims, product support, or any questions regarding your loveseat, please contact TIMBER RIDGE customer service. Keep your purchase receipt for warranty validation.