

## Masterbuilt MB20080319

# Masterbuilt MB20080319 30-inch Electric Smoker Cover Instruction Manual

Model: MB20080319 | Brand: Masterbuilt

## 1. INTRODUCTION

This instruction manual provides essential information for the proper use and care of your Masterbuilt MB20080319 30-inch Electric Smoker Cover. Designed to protect your Masterbuilt Digital Electric Smoker from various environmental elements, this cover ensures the longevity and performance of your smoker.

## 2. PRODUCT FEATURES

- **Material:** Constructed from heavyweight polyurethane-coated polyester for durability.
- **Weather Resistance:** Designed to be weather and fade-resistant, protecting against rain, snow, and sun.
- **Cold Weather Performance:** Resists cracking in cold weather conditions.
- **Compatibility:** Specifically compatible with Masterbuilt 30-inch Digital Electric Smokers.
- **Dimensions:** Measures approximately 19.5 inches (W) x 16.9 inches (D) x 30.9 inches (H).
- **Closure Type:** Features a drawstring closure for a secure fit.

## 3. SETUP AND INSTALLATION

To install the Masterbuilt 30-inch Electric Smoker Cover:

1. Ensure your Masterbuilt 30-inch Digital Electric Smoker is cool and clean before covering.
2. Carefully drape the cover over the top of the smoker, aligning the seams with the smoker's edges.
3. Pull the cover down evenly on all sides until it fully covers the smoker.
4. Utilize the integrated drawstring closure at the bottom to secure the cover tightly around the base of the smoker. This helps prevent the cover from being dislodged by wind.






Image 1: The Masterbuilt 30-inch Electric Smoker Cover fully installed, providing complete protection.



Image 2: A close-up view of the Masterbuilt logo on the cover, indicating product authenticity and fit.

#### 4. OPERATING INSTRUCTIONS (COVER USE)

---

The smoker cover is designed for passive protection. No active operation is required. Simply ensure it is correctly fitted and secured when the smoker is not in use.

- Always remove the cover completely before operating the electric smoker.
- Ensure the smoker is completely cool before placing the cover back on.
- Periodically check the drawstring to ensure it remains tight and secure, especially in windy conditions.





Image 3: Water droplets on the cover surface, illustrating its weather-resistant properties.

## 5. MAINTENANCE AND CARE

Proper maintenance will extend the life of your smoker cover:

- **Cleaning:** Hand wash the cover with mild soap and water. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Allow the cover to air dry completely before storing or placing it back on the smoker.
- **Storage:** When not in use for extended periods, store the cover in a cool, dry place away from direct sunlight.
- **Important Note:** Avoid leaving the cover on the smoker for extended periods in direct sunlight or during heavy rain if pooling occurs, as this can potentially compromise the material over time. Regularly check for any water accumulation and remove it.

## 6. TROUBLESHOOTING

Issue	Possible Cause	Solution
Cover blows off in wind.	Drawstring not tightened sufficiently.	Ensure the drawstring is pulled taut and securely fastened around the base of the smoker.
Water pooling on top of cover.	Improper fit or prolonged exposure to heavy rain.	Adjust the cover for a tighter fit. Consider placing a small object (e.g., a ball) under the center of the cover to create a peak, allowing water to run off.
Cover appears faded or cracked.	Prolonged exposure to harsh UV rays or extreme cold.	While the cover is fade-resistant, extreme conditions can still cause wear. Ensure proper storage when not in use. Consider replacement if damage is significant.

## 7. PRODUCT SPECIFICATIONS

Attribute	Detail
Brand	Masterbuilt
Model Number	MB20080319
Material	Polyurethane-coated Polyester
Color	Black
Product Dimensions (L x W x H)	19.5" x 16.9" x 30.9"
Item Weight	7.8 ounces
Closure Type	Drawstring
Care Instructions	Hand Wash
Manufacturer	Masterbuilt Manufacturing, LLC

## 8. PRODUCT VIDEOS

### Masterbuilt Product Video

Your browser does not support the video tag.

Video 1: An overview of Masterbuilt products, including the smoker cover, highlighting its features and benefits. This video is provided by Premier Specialty Brands LLC (Seller).

### Product Overview Video (Smoker Cover)







Your browser does not support the video tag.

Video 2: A brief product overview focusing on the smoker cover, demonstrating its fit and material. This video is provided by Amazon Product Imaging (Seller).

## 9. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. For specific details regarding warranty coverage and to access customer support, please refer to the documentation included with your purchase or visit the official Masterbuilt website. For additional assistance or inquiries, please contact Masterbuilt customer service.



<div><p>MB20041525</p><p>Gravity Series™ 1150 Digital Charcoal Grill and Smoker Barbecue et fumoir numérique au charbon de bois Gravity Series™ 1150 Parrilla y ahumador de carbón digital de la serie Gravity™ 1150</p></div>	<p><a href="#">Masterbuilt Gravity Series 1150 Digital Charcoal Grill and Smoker Manual</a></p> <p>Assembly, operation, and maintenance guide for the Masterbuilt Gravity Series 1150 Digital Charcoal Grill and Smoker. Learn how to safely set up, use, and care for your grill.</p>
<div><p>Operating Instructions</p><p>MB20070924</p><p>Electric Smoker Fumoir électrique Parrilla eléctrica</p></div>	<p><a href="#">Masterbuilt Electric Smoker Operating Instructions and Guide</a></p> <p>Comprehensive operating instructions, troubleshooting guide, and wood chip smoking guide for the Masterbuilt Electric Smoker. Learn how to set up, use, clean, and maintain your smoker for optimal results.</p>
<div><p>MB20070924</p><p>Digital Electric WiFi Smoker 710 Fumoir électrique numérique WiFi 710 Parrilla eléctrica digital WiFi 710</p></div>	<p><a href="#">Masterbuilt MB20070924 Digital Electric WiFi Smoker 710 Assembly and Safety Manual</a></p> <p>Comprehensive assembly instructions, safety guidelines, and parts list for the Masterbuilt MB20070924 Digital Electric WiFi Smoker 710. Essential reading for safe outdoor household use.</p>
<div><p>MES 340G</p><p>Digital Electric Smoker Fumoir électrique numérique Parrilla eléctrica digital</p></div>	<p><a href="#">Masterbuilt MES 340G Digital Electric Smoker: User Manual and Safety Guide</a></p> <p>Your essential guide to the Masterbuilt MES 340G Digital Electric Smoker. Learn about safe assembly, operation, cleaning, maintenance, and troubleshooting for optimal smoking results.</p>
<div><p>MES 130P, MES 140P</p><p>Bluetooth Digital Electric Smoker Fumoir électrique numérique Bluetooth Parrilla eléctrica digital Bluetooth</p></div>	<p><a href="#">Masterbuilt MES 130P, MES 140P Bluetooth Digital Electric Smoker User Manual</a></p> <p>Comprehensive user manual for the Masterbuilt MES 130P and MES 140P Bluetooth Digital Electric Smoker. Includes safety warnings, operating instructions, and maintenance guidelines.</p>
<div><p>MB20070924</p><p>Digital Electric WiFi Smoker 710 Fumoir électrique numérique WiFi 710 Parrilla eléctrica digital WiFi 710</p></div>	<p><a href="#">Masterbuilt MB20070924 Digital Electric WiFi Smoker 710 User Manual &amp; Guide</a></p> <p>Download the official user manual for the Masterbuilt MB20070924 Digital Electric WiFi Smoker 710. Includes assembly instructions, operating guide, safety precautions, troubleshooting tips, and warranty information.</p>