

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Amazon Basics](#) /
- › [Amazon Basics 4K HDMI 5 Port Switch User Manual AZSW5T1A-4K2K](#)

## Amazon Basics AZSW5T1A-4K2K

### Amazon Basics 4K HDMI 5 Port Switch User Manual

Model: AZSW5T1A-4K2K

#### INTRODUCTION

This manual provides instructions for the Amazon Basics 4K HDMI 5 Port Switch. This device allows you to connect up to five HDMI source devices to a single HDMI display, such as a TV or monitor, and switch between them easily. It supports 4K resolution at 30Hz and is HDCP compliant.

#### SAFETY INFORMATION

- Do not expose the device to moisture or extreme temperatures.
- Do not disassemble the device. Refer all servicing to qualified personnel.
- Use only the provided USB power cable.
- Ensure proper ventilation around the device.

#### PACKAGE CONTENTS

- Amazon Basics 4K HDMI 5 Port Switch
- USB Power Cable (power only)
- Remote Control (CR2025 battery not included)
- User Manual







Image: The HDMI switch connected to a laptop via an HDMI cable, demonstrating a typical setup.

## OPERATING INSTRUCTIONS

### Switching Inputs

You can switch between connected HDMI sources using either the manual selection button on the device or the included remote control.

- **Manual Switching:** Press the "SELECTION" button on the front panel of the switch to cycle through the HDMI input ports (1-5). The corresponding INPUT LED will light up to indicate the active source.
- **Remote Control Switching:** Point the remote control towards the IR receiver on the front of the switch. Press the numbered buttons (1-5) on the remote to directly select the desired HDMI input port.

The switch does not feature automatic input sensing or switching. You must manually select the desired input.

## MAINTENANCE

- Clean the device with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- Keep the device free from dust and debris to ensure proper ventilation.
- Store the device in a cool, dry place when not in use.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No signal on display.	Incorrect input selected. Loose HDMI cables. No power to the switch. Source device not active.	Ensure the correct input is selected on the switch and your display. Check all HDMI cable connections. Verify the USB power cable is connected and the POWER LED is on. Ensure the source device is powered on and outputting a signal.
Picture flickering or poor quality.	Faulty HDMI cable. Cable length too long. Resolution incompatibility.	Try a different HDMI cable. Ensure HDMI cables are within recommended length (e.g., under 10 ft for 4K). Verify your display and source device support the output resolution (e.g., 4K).
Remote control not working.	No battery or dead battery. Obstruction to IR receiver. Incorrect remote aim.	Insert a new CR2025 battery with correct polarity. Ensure a clear line of sight between the remote and the switch's IR receiver. Aim the remote directly at the IR receiver.

## SPECIFICATIONS

- **Product Dimensions:** 6.46 x 0.79 x 2.16 inches
- **Item Weight:** 11.4 ounces
- **Model Number:** AZSW5T1A-4K2K
- **Connector Type:** HDMI
- **Input Ports:** 5 x HDMI
- **Output Ports:** 1 x HDMI
- **Resolution Support:** Up to 4K @ 30Hz
- **HDCP Compliance:** HDCP 1.4b
- **Power:** DC 5V (via USB cable)
- **Compatible Devices:** Computer, PS4, Xbox, Blu-ray DVD player, STB, Projectors, HDTVs, Apple TV, monitors, etc.

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the Amazon Basics official website or contact Amazon customer service. Keep your purchase receipt for warranty claims.