

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Mikado](#) /

› [Mikado MD-856 Multimedia Bluetooth Speaker User Manual](#)

Mikado MD-856

Mikado MD-856 Multimedia Bluetooth Speaker User Manual

Model: MD-856

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Mikado MD-856 Multimedia Bluetooth Speaker system. Please read this manual thoroughly before using the product and retain it for future reference.

SAFETY INFORMATION

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not open the casing. Refer all servicing to qualified personnel.
- Ensure proper ventilation around the unit.
- Use only the power supply specified for this device.
- Keep away from direct sunlight, heat sources, and strong magnetic fields.
- Avoid placing heavy objects on the unit.

PACKAGE CONTENTS

Please check that all items listed below are included in your package:

- Main Subwoofer Unit
- Satellite Speakers (5 units)
- Remote Control
- Usage Manual (this document)
- Warranty Certificate
- RCA Cable
- Antenna Cable

PRODUCT OVERVIEW

The Mikado MD-856 is a 5.1 channel multimedia speaker system designed to deliver rich audio. It features multiple connectivity options including Bluetooth, USB, SD card, FM radio, and AUX input.



Figure 1: Front view of the Mikado MD-856 5.1 Multimedia Bluetooth Speaker system, showing the central subwoofer unit, five satellite speakers, and the remote control.



Figure 2: Rear panel of the Mikado MD-856 subwoofer, displaying various audio input and output ports, power switch, and power cable connection.

SETUP

1. Speaker Connection

1. Connect the five satellite speakers to the corresponding output ports on the rear panel of the main subwoofer unit. Ensure correct polarity (+ to + and - to -).
2. Position the speakers for optimal 5.1 surround sound experience. Typically, one center speaker, two front speakers, and two rear speakers.

2. Power Connection

1. Ensure the power switch on the rear panel is in the OFF position.
2. Connect the power cable to the main subwoofer unit and then plug it into a standard electrical outlet.

3. Audio Input Connections

Choose one of the following methods to connect your audio source:

- **RCA (AUX) Input:** Use the provided RCA cable to connect your audio source (e.g., TV, PC, DVD player) to

the "AUX AUDIO INPUT" ports on the rear panel. Match the red and white connectors.

- **USB/SD Card:** Insert a USB flash drive or SD card into the respective slots on the front panel of the subwoofer.
- **FM Antenna:** Connect the included antenna cable to the FM antenna port on the rear panel for improved radio reception.

OPERATING INSTRUCTIONS

1. Power On/Off

Flip the power switch on the rear panel to the ON position. The display on the front panel will illuminate.

2. Mode Selection

Press the "MODE" button on the front panel or the remote control to cycle through available input modes: Bluetooth, USB, SD, FM, and AUX.

3. Volume Control

Adjust the master volume using the large knob on the front panel or the volume buttons on the remote control.

4. Bluetooth Pairing

1. Switch the speaker system to Bluetooth mode. The display will show "BT" or a similar indicator.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.) and search for available devices.
3. Select "MD-856" from the list of devices. Once paired, you will hear a confirmation sound.

5. USB/SD Playback

When a USB drive or SD card is inserted, the system will automatically switch to USB/SD mode and begin playing compatible audio files. Use the remote control for playback functions (play/pause, next/previous track).

6. FM Radio

In FM mode, press the "SCAN" button on the remote control to automatically scan and save available radio stations. Use the "PREV/NEXT" buttons to navigate through saved stations.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the speakers. Do not use liquid cleaners or abrasive materials.
- **Storage:** If storing the unit for an extended period, disconnect it from the power supply and store it in a cool, dry place.
- **Ventilation:** Ensure that the ventilation openings on the subwoofer are not blocked to prevent overheating.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Power switch off; Power outlet faulty	Check power cable connection; Turn power switch ON; Try a different power outlet

Problem	Possible Cause	Solution
No sound	Volume too low; Incorrect input mode; Audio cables not connected properly; Source device not playing	Increase volume; Select correct input mode; Check audio cable connections; Ensure source device is playing audio
Bluetooth not pairing	Speaker not in Bluetooth mode; Device too far; Bluetooth on device off	Switch to Bluetooth mode; Move device closer; Enable Bluetooth on your device
Poor FM reception	Antenna not connected; Weak signal	Connect FM antenna; Adjust antenna position for better signal

SPECIFICATIONS

Model: MD-856

Brand: Mikado

Speaker Type: Multimedia 5.1 Channel

Connectivity Technology: Bluetooth, USB

Speaker Maximum Output Power: 25 Watts

Surround Sound Channel Configuration: 5.1

Recommended Uses: PC - TV

Product Dimensions: 35 x 35 x 44 cm

Item Weight: 7.9 Kilograms

Color: Black

Included Components: Controller, Usage Manual, Warranty Certificate, RCA Cable, Antenna Cable

WARRANTY AND SUPPORT

Your Mikado MD-856 speaker system comes with a Warranty Certificate. Please refer to the certificate for details regarding warranty coverage and terms. For technical support or service inquiries, please contact your local Mikado dealer or authorized service center.

© 2023 Mikado. All rights reserved.

Related Documents - MD-856

 <p>MD-51BT CYCLONE</p> <p>IPX6 Kablosuz Hoparlör USER MANUAL/WARRANTY CERTIFICATE KULLANIM KİALVUZU/MAĞİFTİ BELGESE</p> <p>CE</p> <p>MIKADO MD-51BT Beyazgül Teknoloji A.Ş. MIKADO Beyazgül Teknoloji A.Ş.</p>	<p>Mikado MD-51BT Cyclone IPX6 Wireless Speaker User Manual & Warranty</p> <p>Comprehensive user manual and warranty information for the Mikado MD-51BT Cyclone IPX6 wireless speaker. Includes specifications, operating instructions, safety guidelines, and warranty terms.</p>
 <p>MD-50BT HARMONY</p> <p>Kablosuz Taşınabilir Speaker USER MANUAL/WARRANTY CERTIFICATE KULLANIM KİALVUZU/MAĞİFTİ BELGESE</p> <p>CE</p> <p>MIKADO MD-50BT Beyazgül Teknoloji A.Ş. MIKADO Beyazgül Teknoloji A.Ş.</p>	<p>Mikado MD-50BT Harmony Portable Speaker User Manual and Warranty</p> <p>User manual and warranty certificate for the Mikado MD-50BT Harmony portable speaker, including product specifications, key functions, Bluetooth connection, safety instructions, and care guidelines.</p>
 <p>USB SOUNDBAR SPEAKER MD-SBT25</p> <p>CE</p>	<p>Mikado MD-SBT25 USB Soundbar Speaker: User Manual, Specifications, and Warranty</p> <p>Detailed user manual for the Mikado MD-SBT25 USB Soundbar Speaker, covering technical specifications, setup, safety guidelines, warranty terms, and EC Declaration of Conformity.</p>
	<p>Mikado MD-672BT 5+1 Wireless Home Speaker User Manual and Specifications</p> <p>Comprehensive user manual and technical specifications for the Mikado MD-672BT 5+1 Wireless Home Speaker, including safety instructions, package contents, remote control guide, features, specifications, unit operation, and warranty information.</p>
	<p>Mikado LOGO 600 SE RC Helicopter Assembly and Operation Manual</p> <p>Comprehensive assembly and operational guidance for the Mikado LOGO 600 SE radio-controlled helicopter. This manual details construction steps, safety instructions, and operational procedures for users.</p>
	<p>Mikado LOGO 10 RC Helicopter Assembly and Operation Manual</p> <p>Comprehensive guide for the Mikado LOGO 10 remote-controlled helicopter, detailing assembly, setup, safety, and operation. Includes parts list, RC programming, and pre-flight checks.</p>