

Simba 105733245

Simba Steffi Love Dream Castle Playset Instruction Manual

Model: 105733245

Brand: Simba

1. INTRODUCTION

This instruction manual provides essential information for the assembly, operation, and maintenance of your Simba Steffi Love Dream Castle Playset, Model 105733245. Please read this manual thoroughly before use to ensure safe and correct handling of the product. Keep this manual for future reference.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Always supervise children during play.
- Ensure all parts are securely assembled before allowing children to play.
- Do not modify the product in any way.
- Keep packaging materials away from children to prevent suffocation.
- Inspect the playset regularly for any damage or loose parts. Discontinue use if damage is found.

3. PACKAGE CONTENTS

The Simba Steffi Love Dream Castle Playset includes 38 pieces. Carefully unpack all components and verify against the list below. If any parts are missing or damaged, please contact customer support.



Image 3.1: The product packaging, illustrating the main castle structure, dolls, and various accessories included in the set.

- Main Castle Structure (various plastic panels and towers)
- 1 Steffi Love Doll
- 1 Smaller Doll
- Assorted Furniture (e.g., dining table, chairs, bed, rocking horse)
- Small Accessories (e.g., tea set, pets, decorative items)
- Assembly Instructions (this manual)

4. SETUP AND ASSEMBLY

While the product specifications indicate "No assembly required," user feedback suggests that some assembly of the playset elements and accessories is necessary. Follow these general steps for setting up your Dream Castle:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, flat surface.
2. **Identify Main Structure:** Locate the larger plastic panels that form the castle walls and floors.
3. **Connect Panels:** Assemble the main castle structure by snapping or sliding the panels together. Ensure all connections are firm. Refer to any diagrams provided on the packaging or included inserts for specific connection points.
4. **Attach Towers and Balconies:** Securely attach the castle towers, balconies, and staircases to the main structure.
5. **Install Cardboard Backdrops:** Some parts, such as room backdrops, may be made of cardboard. Insert these carefully into their designated slots. *Note: These may require occasional re-insertion during play.*
6. **Arrange Furniture:** Place the included furniture pieces (table, chairs, bed, etc.) within the castle rooms as desired.
7. **Add Accessories:** Distribute the smaller accessories and dolls throughout the playset.



Image 4.1: The fully assembled Dream Castle playset, showcasing its multi-level structure, various rooms, and included furniture.



Image 4.2: A detailed front view of the assembled castle, highlighting the main entrance and decorative elements.

5. OPERATING INSTRUCTIONS

The Steffi Love Dream Castle Playset is designed for imaginative play. Here are some ways to interact with its features:

- **Opening Doors:** The main entrance doors can be opened and closed to allow dolls to enter and exit the castle.
- **Using the Swing:** Place a doll on the swing located on the upper level balcony. Gently push the swing to simulate movement.



Image 5.1: Steffi Love doll enjoying the swing feature on the castle's balcony.

- **Dining Area:** Arrange the dining table and chairs in the designated area. Use the tea set accessories for pretend meals.



Image 5.2: Steffi Love and a smaller doll seated at the dining table, ready for a tea party.

- **Bedroom and Nursery:** Utilize the bed for the Steffi Love doll and the rocking horse for the smaller doll.



Image 5.3: Steffi Love doll relaxing in the castle's bedroom area, complete with a bed and shelves.



Image 5.4: A smaller doll riding a rocking horse, accompanied by two pet figures, in a nursery-like setting.

6. MAINTENANCE

- **Cleaning:** Wipe the plastic surfaces of the playset with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.

- **Dolls and Fabric:** Dolls can be wiped clean. Fabric clothing can be hand-washed gently if necessary.
- **Storage:** Store the playset in a dry, clean environment away from direct sunlight to prevent fading and material degradation.
- **Cardboard Parts:** The cardboard back walls may become dislodged during play. Gently re-insert them into their slots as needed.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Playset feels unstable after assembly.	Parts not fully snapped into place.	Carefully check all connection points and press firmly until they click or are securely seated.
Cardboard backdrops fall out frequently.	Loose fit or vigorous play.	Gently re-insert the cardboard pieces. For a more secure fit, a small amount of non-permanent adhesive (e.g., poster putty) can be used on the edges, applied by an adult.
Missing parts upon unboxing.	Manufacturing error or packaging oversight.	Contact Simba customer support with your product model number and purchase details.

8. SPECIFICATIONS

Model Number: 105733245

Brand: Simba

Material: Plastic (main structure), Cardboard (some backdrops)

Dimensions (L x W x H): 15.2 x 50.5 x 80 cm (approximately 6 x 20 x 31.5 inches)

Item Weight: Approximately 1 kg (2.2 lbs)







Number of Pieces: 38

Recommended Age: 3 years and up (due to small parts)

Assembly Required: Yes, some assembly of playset elements and accessories.

9. WARRANTY AND SUPPORT

Simba products are manufactured to high-quality standards. For specific warranty information, please refer to the documentation included with your purchase or visit the official Simba website. For customer support, inquiries regarding missing parts, or technical assistance, please contact Simba customer service through their official channels. You can find more information about Simba products at [Simba's Amazon Store](#).

	<p>My Music World 32-Key Toy Keyboard by Simba</p> <p>Discover the Simba My Music World 32-key toy keyboard. This interactive musical toy for children features 8 demo songs, various instrument sounds, rhythm options, recording capabilities, and easy-to-use controls for tempo and volume.</p>
<p>SOCCER TABLE MARACANÁ[®] INSTRUCTIONS</p> 	<p>Soccer Table Maracanã Instructions and Assembly Guide Simba</p> <p>Official assembly instructions and parts list for the Simba Maracanã Soccer Table (Foosball Table). Learn how to build your table step-by-step.</p>
<p>POOL TABLE 8FT INSTRUCTIONS</p> 	<p>Simba 8ft Pool Table Assembly Instructions</p> <p>Detailed assembly instructions for the Simba 8ft pool table, including a comprehensive parts list and step-by-step guidance for setup.</p>
<p>POOL TABLE 7FT INSTRUCTIONS</p> 	<p>Simba 7ft Pool Table Assembly Instructions</p> <p>Detailed assembly instructions for the Simba 7ft pool table, including a comprehensive parts list and step-by-step guidance for setup.</p>
<p>POOL TABLE BECOME TABLE INSTRUCTIONS</p> 	<p>SIMBA Convertible Pool Table to Dining Table and Stool Assembly Instructions</p> <p>Comprehensive assembly guide for the SIMBA 2-in-1 pool table that converts to a dining table, including a detailed parts list and step-by-step instructions for both the table and accompanying stools.</p>
<p>POOL TABLE 4IN-1 MULTIGAMES INSTRUCTIONS</p> 	<p>Pool Table 4-in-1 Multigames Assembly Instructions and Parts Identifier</p> <p>Comprehensive assembly instructions and parts identifier for the SIMBA Pool Table 4-in-1 Multigames, including air hockey and table tennis. Ensure safe and correct assembly with detailed steps and part lists.</p>