

Ryght R483140

User Manual
RYGHT JUMBO WIRELESS MOBILE BLUETOOTH SPEAKER
Model: R483140

1. Introduction

Thank you for purchasing the RYGHT Jumbo Wireless Mobile Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

Box Contents:

- 1 x RYGHT Jumbo Speaker
- 1 x USB Charging Cable
- 1 x User Manual (this document)

2. Safety Information

To prevent damage to your device or injury to yourself or others, please read all safety information before using the device.

- Do not disassemble, repair, or modify the speaker.
- Keep the speaker away from extreme temperatures, direct sunlight, and high humidity.
- Do not expose the speaker to fire or dispose of it in fire, as the battery may explode.
- Ensure all port covers are securely closed when using the speaker near water to maintain its IP67 water and dust resistance.
- Avoid dropping the speaker or subjecting it to strong impacts.
- Use only the provided USB cable for charging.
- Keep out of reach of children.

3. Product Overview and Features

The RYGHT Jumbo speaker is designed for portability and robust sound, featuring:

- **Wireless Connectivity:** Bluetooth 4.2 for seamless audio streaming.
- **Powerful Sound:** 2x10 Watt output for clear and strong audio.

- **Water and Dust Resistance:** IP67 rating, protecting against dust and temporary immersion in water up to 1 meter for 30 minutes.
- **Integrated Power Bank:** Use the speaker's battery (4400 mAh) to charge your mobile devices.
- **MicroSD Card Slot:** Play music directly from a MicroSD card.
- **Hands-Free Calling:** Built-in microphone for answering calls.
- **Long Battery Life:** Up to 11 hours of playback on a single charge.




Figure 3.1: Front view of the RYGHT Jumbo speaker, showcasing its sleek black design and mesh grille.



Figure 3.2: Top view of the speaker, highlighting the intuitive control buttons for power, volume, track navigation, and Bluetooth pairing, along with LED indicators.



Figure 3.3: Side view of the speaker, revealing the securely covered ports for charging, USB output, and auxiliary input, essential for maintaining its water resistance.

4. Setup

4.1 Initial Charging

Before first use, fully charge the speaker. Connect the supplied USB cable to the speaker's micro-USB port and the other end to a USB power adapter (not included) or a computer USB port. The LED indicators on top will show charging progress. A full charge typically takes approximately 3.5 hours.

4.2 Powering On/Off

- To power on: Press and hold the **Power button** (*symbol: circle with vertical line*) on the top panel until you hear an audible prompt and the LED indicators light up.
- To power off: Press and hold the **Power button** again until you hear an audible prompt and the LED indicators turn off.

5. Operating Instructions

5.1 Bluetooth Pairing

1. Ensure the speaker is powered on. The Bluetooth LED indicator will flash, indicating it's in pairing mode.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Ryght JUMBO" from the list of found devices.
4. Once paired, the Bluetooth LED indicator will glow solid, and you will hear a confirmation sound.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range and Bluetooth is enabled.

5.2 Audio Playback

- **Play/Pause:** Press the **Bluetooth/Play/Pause button** (*symbol: hexagon*) to play or pause audio.
- **Volume Up:** Press the **Volume + button** (*symbol: plus sign*) to increase volume.
- **Volume Down:** Press the **Volume - button** (*symbol: minus sign*) to decrease volume.
- **Next Track:** Press the **Next Track button** (*symbol: right triangle*) to skip to the next song.
- **Previous Track:** Press the **Previous Track button** (*symbol: left triangle*) to go to the previous song.

5.3 Hands-Free Calling

- **Answer Call:** When a call comes in, press the **Bluetooth/Play/Pause button** to answer.
- **End Call:** During a call, press the **Bluetooth/Play/Pause button** to end the call.
- **Reject Call:** Press and hold the **Bluetooth/Play/Pause button** to reject an incoming call.

5.4 Power Bank Function

The RYGHT Jumbo speaker can act as a power bank to charge other devices.

- Open the protective cover on the side of the speaker.
- Connect your mobile device's charging cable to the USB-A output port on the speaker.
- Charging will begin automatically.

5.5 MicroSD Card Playback

To play music directly from a MicroSD card:

- Open the protective cover on the side of the speaker.
- Insert a MicroSD card (with supported audio files) into the MicroSD card slot until it clicks into place.
- The speaker will automatically switch to MicroSD playback mode. Use the playback controls (Play/Pause, Next/Previous Track) as described in section 5.2.



Figure 5.1: The RYGHT Jumbo speaker demonstrating its IP67 water resistance, suitable for use near water.

6. Maintenance

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** Always ensure the port cover is firmly sealed when the speaker is exposed to water or dust. After

exposure to water, dry the speaker thoroughly before opening the port cover or charging.

- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid prolonged exposure to direct sunlight or extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

7. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully.
No sound from speaker.	Volume is too low; Device not paired; Incorrect input source.	Increase volume on speaker and device; Re-pair Bluetooth; Ensure correct mode (Bluetooth/MicroSD).
Bluetooth pairing fails.	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is flashing Bluetooth LED; Move device closer; Turn off other Bluetooth devices.
Charging other devices fails.	Speaker battery too low; Cable issue.	Charge the speaker; Try a different USB cable.

8. Specifications

Feature	Detail
Model Number	R483140
Brand	RYGHT
Dimensions (L x W x H)	19 x 8 x 5.1 cm
Weight	940 g
Battery Type	Lithium-Polymer
Battery Capacity	4400 mAh (7.4V)
Charging Time	Approx. 3.5 hours
Playback Time	Up to 11 hours
Output Power	2 x 10 Watt (Total 20 Watt)
Connectivity	Bluetooth 4.2
Water/Dust Resistance	IP67
Material	Plastic, Metal
Special Features	Wireless, Power Bank Function, MicroSD Card Slot, Hands-Free Calling

9. Warranty and Support

RYGHT products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official RYGHT website. Please retain your proof of purchase for any warranty claims.

For further assistance, you may contact RYGHT customer service through their official channels.

© 2024 RYGHT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question