

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Miele](#) /

› [Miele Complete C3 Calima Bagged Canister Vacuum Cleaner Instruction Manual](#)

Miele 10796510

Miele Complete C3 Calima Bagged Canister Vacuum Cleaner

Model: 10796510

1. INTRODUCTION AND SAFETY INFORMATION

The Miele Complete C3 Calima is a high-performance bagged canister vacuum cleaner designed for effective cleaning of smooth floors and low-medium pile carpets. It features a powerful motor, advanced filtration, and user-friendly controls to ensure a clean and healthy home environment.

Important Safety Instructions:

- Read all instructions before using this appliance.
- Do not leave the vacuum cleaner unattended when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.

2. SETUP AND ASSEMBLY

Follow these steps to set up your Miele Complete C3 Calima vacuum cleaner:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all parts listed in the packing contents are present.
2. **Attaching the Hose:** Insert the hose connector into the suction opening on the vacuum cleaner until it clicks securely into place.
3. **Assembling the Wand and Floorhead:** Connect the telescopic suction wand to the hose handle. Then, attach your desired floorhead (Turbobrush or Parquet Twister) to the end of the telescopic wand.
4. **Inserting the Dustbag:** Open the dustbag compartment by pressing the release button. Ensure a HyClean dustbag is correctly inserted and sealed. The vacuum comes with one pre-installed.
5. **Checking Filters:** Verify that the motor protection filter and the HEPA Lifetime filter are correctly seated. These are typically pre-installed.



Figure 2.1: Fully assembled Miele Complete C3 Calima vacuum cleaner.

3. OPERATING INSTRUCTIONS

Your Miele Complete C3 Calima offers versatile cleaning options:

- **Power On/Off:** Plug the power cord into a suitable electrical outlet. Press the large foot switch with the power symbol (①) on the vacuum cleaner to turn it on or off.
- **Adjusting Suction Power:** The vacuum features convenient foot switches for suction control. Use the '+' and '-' buttons to select from 6 cleaning modes, optimizing suction for different surfaces without bending down. The selected mode will be indicated by illuminated icons.




Figure 3.1: Foot controls for power and suction adjustment.

- **Using Floorheads:**
 - **Turbobrush Floorhead:** Ideal for low-medium pile carpets. The air-driven rotating brush effectively removes lint and pet hair.
 - **Parquet Twister Floorhead:** Designed for effortless cleaning of hard floors. Its soft natural bristles glide gently and smoothly across delicate surfaces.
- **Integrated Accessories:** The vacuum includes three integrated attachments conveniently stored in a compartment on the top of the unit: upholstery nozzle, crevice nozzle, and dusting brush. These are always at hand for specialized cleaning tasks.




Integrated accessories

Always at hand

Figure 3.2: Integrated accessories for versatile cleaning.

- **Comfort Cable Rewind:** The power cord is easily wound with a foot control. Simply tap the foot switch to quickly retract the cord without bending down.
- **Parking System:** For quick breaks during cleaning, hook the floorhead onto the rear of the vacuum cleaner using the parking system.



Comfort cable rewind
Extra quick and convenient

Figure 3.3: Automatic cord rewind for convenient storage.

Official Product Video

Your browser does not support the video tag.

Video 3.1: An official Miele video showcasing the Complete C3 Calima vacuum cleaner's features and operation, including its powerful suction, streamlined airflow, foot controls, integrated accessories, and various floorheads.

4. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Miele vacuum cleaner:

- **Changing the Dustbag:** Replace the HyClean dustbag when the dustbag change indicator fills completely. The automatic sealing mechanism ensures hygienic disposal.



AirClean FilterBags

Multi-stage filtration for maximum hygiene

Figure 4.1: Replacing the HyClean dustbag.

- **Cleaning/Replacing Filters:**

- **Motor Protection Filter:** This filter protects the motor from dust. Check and clean it regularly according to the user guide.
- **HEPA Lifetime Filter:** This filter retains up to 99.999% of even the smallest particles, ideal for allergy sufferers. Replace as indicated by the filter change indicator or as recommended in the user manual.



HEPA AirClean filter

Ideal for allergy sufferers

Figure 4.2: The HEPA AirClean filter for maximum air hygiene.

- **Cleaning Floorheads:** Regularly check and clean the brushes of the Turbobrush floorhead to remove tangled hair or debris. The Parquet Twister floorhead may require occasional cleaning of its bristles.

5. TROUBLESHOOTING

If you encounter issues with your Miele Complete C3 Calima, refer to the following common troubleshooting tips:

- **No Suction/Reduced Suction:**
 - Check if the dustbag is full and needs replacement.
 - Inspect the filters (motor protection and HEPA) for blockages or if they need cleaning/replacement.
 - Ensure the hose, wand, and floorhead are free from blockages.
 - Verify all connections are secure.
- **Unusual Noise:**
 - Check for blockages in the hose or floorhead.
 - Ensure the dustbag is correctly inserted.

- If the noise persists, contact Miele customer support.

- **Vacuum Not Turning On:**

- Ensure the power cord is securely plugged into a working outlet.
- Check for tripped circuit breakers.

For more detailed troubleshooting or persistent issues, please consult the full User Guide (PDF) available via the provided link in the support section.

6. SPECIFICATIONS

Feature	Detail
Brand	Miele
Model Name	Complete C3 Calima Bagged Canister Vacuum Cleaner with Turbobrush floorhead
Item Model Number	10796510
Color	Curry Yellow
Form Factor	Canister
Special Feature	Bag
Filter Type	HEPA Filter
Included Components	Dusting Brush, Protection Filters, Hepa Filter, Dustbags, Upholstery Nozzle, Crevice Tool
Wattage	1200 watts
Capacity	4.5 Liters
Noise Level	81 dB
Number of Speeds	6
Item Weight	16 pounds
Product Dimensions	20" L x 12" W x 12" H
Recommended Uses	For bare Floor with Little or no carpet, NOT for Wall To Wall carpet or heavy pet fur.

7. WARRANTY AND SUPPORT

Warranty Information: This Miele product comes with a 3-year limited warranty.

User Guide: For comprehensive details, safety warnings, and advanced troubleshooting, please refer to the official User Guide in PDF format: [Download User Guide \(PDF\)](#)

Customer Support: For further assistance, technical support, or warranty claims, please visit the official Miele website or contact their customer service directly.