

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Rubbermaid](#) /

› [Rubbermaid Brilliance 4.7 Cup Food Storage Containers - Instruction Manual](#)

### Rubbermaid 4.7 cup (8-Piece)

# Rubbermaid Brilliance 4.7 Cup Food Storage Containers - Instruction Manual

## 1. INTRODUCTION

Thank you for choosing Rubbermaid Brilliance Food Storage Containers. These intelligently crafted and elegantly designed containers are perfect for daily use, offering a superior solution for storing and preserving your food. Made from durable, BPA-free plastic, they are designed to be leak-proof, stain-resistant, and odor-resistant, ensuring your food stays fresh and your containers look new for longer. This manual provides essential information on how to set up, use, and maintain your new food storage containers.

## 2. PRODUCT FEATURES

- **Airtight Lids:** Secure latches create an airtight seal to keep food fresh and prevent leaks.
- **Space Saving Design:** Modular design allows for perfect stacking, maximizing fridge and pantry space.
- **Durable Construction:** Thick-walled plastic ensures longevity and withstands everyday use.
- **Microwave Safe:** Lids feature built-in vents to allow steam to escape, enabling splatter-free microwaving without lid removal.
- **Safe Materials:** Containers are BPA-free, freezer-safe, and top-rack dishwasher-safe.
- **Crystal-Clear Visibility:** Clear lids and bases make it easy to identify contents.
- **Stain and Odor Resistant:** Designed to resist stains and odors, maintaining clarity and freshness.



Image: Four 4.7 cup Rubbermaid Brilliance containers, showcasing their clear design and stackability.

### 3. SETUP

Before first use, wash all containers and lids with warm, soapy water or place them on the top rack of your dishwasher. Ensure all components are thoroughly dry before storing food.

## 4. OPERATING INSTRUCTIONS

### 4.1. Sealing and Opening Lids

- To seal, align the lid with the container and press down firmly on the center. Engage the four latches on the sides until they click securely into place.
- To open, unlatch the four side clips and gently lift the lid.

## 4.2. Microwave Use

Rubbermaid Brilliance containers are designed for convenient microwaving. To use in the microwave:

1. Ensure the lid is securely latched onto the container.
2. Lift the two smaller latches on the sides of the lid to open the built-in vents. This allows steam to escape during heating, preventing pressure buildup and splatters.
3. Place the container in the microwave and heat as desired.
4. After heating, carefully remove the container from the microwave. Close the vents before transporting or storing.



Image: Splatter-Free Microwaving. The innovative lid design with built-in vents allows for convenient microwaving.

## 4.3. Freezer Use

These containers are freezer-safe. Ensure the lid is securely latched to prevent freezer burn and maintain food freshness.

## 5. CARE AND MAINTENANCE

### 5.1. Dishwasher Cleaning

All components (containers and lids) are top-rack dishwasher-safe. For best results and to maintain the integrity of the seals, place them on the top rack.



Image: Rubbermaid Brilliance containers are top-rack dishwasher safe for easy cleaning.

## 5.2. Hand Washing

For hand washing, use warm, soapy water and a soft sponge or cloth. Pay special attention to cleaning around the rubber gasket on the lid to prevent food particles from accumulating.

## 5.3. Stain and Odor Resistance

The containers are designed to be stain and odor-resistant. However, for heavily pigmented foods (e.g., tomato sauce, curry), rinse the container immediately after use to minimize potential staining.

## 6. STORAGE

The modular design of Rubbermaid Brilliance containers allows for efficient and organized storage. Containers and lids stack neatly together, saving valuable space in your cabinets, fridge, or pantry.



## VERSATILE, STACKABLE, AND LEAK-PROOF

Rubbermaid Brilliance Food Storage Containers are designed to be leak-proof, so you can easily transport sauces, soups, and stews. They stack for easy organization, letting you store meats, veggies, fruit and more in the fridge without clutter.

The stain-resistant construction maintains a spotless look, and the built-in microwave vents make for safe and simple heating. Plus, the containers are dishwasher- and freezer-safe!

Image: Versatile and Stackable. The modular design allows for efficient organization in your pantry or fridge.

## 7. TROUBLESHOOTING

### 7.1. Lid Not Sealing Properly

- Ensure the rubber gasket on the lid is clean and free of food debris.
- Verify that the lid is correctly aligned with the container before engaging the latches.
- Avoid overfilling the container, as this can prevent a proper seal.

### 7.2. Stains or Odors Persist

- For stubborn stains, try soaking the container in a mixture of warm water and baking soda.
- For persistent odors, place a crumpled piece of newspaper or a lemon wedge inside the container and seal it overnight.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Rubbermaid
Model	Brilliance 4.7 cup (8-Piece Set)
Material	BPA-Free Plastic
Capacity	4.7 Cups per container
Color	Clear, Grey
Dimensions (L x W x H)	7.9"L x 5.6"W x 3.4"H
Special Features	Airtight, Leak Resistant, Stackable, Dishwasher Safe (Top Rack), Microwave Safe (with vents open), Freezer Safe

Feature	Detail
Closure Type	Latch
UPC	071691515272

## 9. WARRANTY AND SUPPORT

Rubbermaid products are designed for durability and performance. For specific warranty information or customer support, please refer to the official Rubbermaid website or contact their customer service directly. Keep your purchase receipt for any warranty claims.