

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Samsung](#) /

› [Samsung 75NU7100 7 Series 4K UHD Smart TV User Manual](#)

Samsung UN75NU7100FXZA

Samsung 75NU7100 7 Series 4K UHD Smart TV User Manual

Model: UN75NU7100FXZA

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Samsung 75NU7100 7 Series 4K UHD Smart TV. Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury.

- Do not expose this apparatus to rain or moisture.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the box:

- Samsung 75NU7100 7 Series 4K UHD Smart TV
- Remote Control (requires 2 AAA batteries)
- Power Cable
- User Manual (this document)
- TV Stand Components

4. SETUP

4.1 Unpacking and Placement

Carefully remove the TV from its packaging. It is recommended to have at least two people for handling due to the size and weight of the unit. Place the TV on a stable, flat surface or prepare for wall mounting.



Figure 4.1: Front view of the Samsung 75NU7100 4K UHD Smart TV.

4.2 Attaching the Stand (Optional)

If not wall-mounting, attach the provided stand components to the bottom of the TV using the designated screws. Ensure the stand is securely fastened before placing the TV upright.

4.3 Wall Mounting (Optional)

For wall mounting, use a VESA-compatible wall mount kit (sold separately) that supports the TV's weight and dimensions. Consult a professional for installation to ensure safety and proper mounting.



Figure 4.2: Side profile of the TV, illustrating its slim design for wall mounting.

4.4 Connecting External Devices

Connect your external devices (e.g., cable box, Blu-ray player, gaming console) to the TV's input ports. The TV features multiple HDMI ports for high-definition connections.



Figure 4.3: Rear view of the TV, highlighting the available input ports for connectivity.

4.5 Power Connection

Plug the power cable into the TV's power input and then into a wall outlet. The TV is now ready for initial setup.

5. OPERATING THE TV

5.1 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process. This includes selecting your language, connecting to a Wi-Fi network, and tuning channels.

5.2 Remote Control Functions

The included remote control allows you to navigate the TV's interface, change channels, adjust volume, and access smart features. Dedicated buttons for popular streaming services may be present for quick access.

5.3 Smart TV Features

Your Samsung Smart TV provides access to a wide range of applications and streaming services. Use the remote to navigate the Smart Hub, download apps, and enjoy content. The TV supports 4K UHD content and upscales lower-resolution content to near 4K quality.

5.4 Picture and Sound Settings

Access the TV's settings menu to customize picture modes (e.g., Standard, Dynamic, Movie), adjust brightness, contrast, and color. Sound settings allow for adjustments to audio output, equalizer, and sound modes.

5.5 Relevant Product Video

The following video provides an overview of a Samsung NU7100 series TV, demonstrating some features and functionality. While the video features a 40-inch model, the core operating principles apply to the 75-inch model.

Video 5.1: Overview of a Samsung 40NU7100 TV, demonstrating features and operation. This video is provided by a merchant.

6. MAINTENANCE

6.1 Cleaning the TV

To clean the screen, gently wipe it with a soft, dry microfiber cloth. For the TV frame, use a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.

6.2 Software Updates

Periodically check for software updates through the TV's settings menu to ensure optimal performance and access to the latest features. Updates can be performed via Wi-Fi.

7. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common problems and solutions:

- **No Power:** Ensure the power cable is securely connected to both the TV and the wall outlet. Test the outlet with another device.
- **No Picture/Sound:** Verify that the correct input source is selected. Check all cable connections to external devices.
- **Remote Not Working:** Replace the AAA batteries in the remote control. Ensure there are no obstructions between the remote and the TV.
- **Poor Picture Quality:** Adjust picture settings. Ensure you are viewing high-quality content. For streaming, check your internet connection speed.
- **Wi-Fi Connection Issues:** Restart your router and the TV. Re-enter your Wi-Fi password in the TV's network settings.

For more complex issues, consult the full electronic manual available on the Samsung support website or contact Samsung customer support.

8. SPECIFICATIONS

| Feature | Specification |
|---------|---------------|
|---------|---------------|

| | |
|---------------------------------|--------------------------|
| Brand | Samsung |
| Model Number | UN75NU7100FXZA |
| Screen Size | 75 Inches |
| Display Technology | LED |
| Resolution | 4K (3840 x 2160) |
| Refresh Rate | 120 Hz |
| Connectivity Technology | Wi-Fi |
| Product Dimensions (with stand) | 66.3"W x 13.7"D x 41.6"H |
| Item Weight | 82.7 Pounds |
| Speaker Type | 2CH |
| Wattage | 105 watts |




Figure 8.1: Samsung 75NU7100 4K UHD Smart TV with key dimensions.

9. WARRANTY AND SUPPORT

Your Samsung TV comes with a limited manufacturer's warranty. For detailed warranty information, product registration, or technical support, please visit the official Samsung website or contact their customer service. Keep your purchase receipt as proof of purchase.

Online Support: www.samsung.com/us/support/