Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schleich 42416

Schleich Horse Club Lakeside Country House and Stable Instruction Manual

Model: 42416

1. Introduction

Welcome to the world of Schleich Horse Club! This instruction manual provides essential information for the assembly, use, and care of your Lakeside Country House and Stable playset. Designed for imaginative play, this detailed playset allows children aged 5-12 to explore the adventures of the Horse Club girls and their beloved horses.

The Schleich Horse Club Lakeside Country House and Stable is a comprehensive 70-piece playset that brings the vibrant world of Lakeside to life. It encourages creative storytelling and interaction with its various components, including the house, stable, figures, and numerous accessories.

2. Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

Please ensure all small parts are kept away from young children who may attempt to swallow them. Adult supervision is recommended during assembly and initial play to ensure all components are securely in place and understood.

3. What's in the Box

Your Schleich Horse Club Lakeside Country House and Stable playset includes the following components:

- 1 x house
- 1 x horse stable
- 1 x balcony
- 1 x girl figure
- 1 x mother figure
- 1 x father figure
- 1 x Quarter Horse Cayenne figure
- 1 x Hanoverian stallion Jupiter figure
- 2 x kitten figures

- 1 x double bed with mattress
- 2 x bunk beds with mattresses
- 1 x bunk bed ladder
- 4 x fabric blankets
- 6 x fabric cushions
- 1 x bedside table
- 1 x bedside lamp
- 1 x toilet
- 1 x sink
- 1 x shower
- 2 x benches
- 1 x kitchen unit
- 1 x fridge
- 1 x pot
- 1 x pan
- 1 x fruit box
- 4 x bottles
- 4 x plates
- 4 x cups
- 4 x pieces of apple pie
- 1 x dining table
- 1 x plate rack
- 1 x stairs
- 1 x chimney
- 1 x wood pile
- 1 x floor lamp
- 1 x case
- 1 x telescope
- 2 x balcony chairs
- 1 x balcony table
- 1 x sunshade
- 3 x flower boxes with flowers
- 1 x coffee table
- 1 x sofa
- 1 x flower pot
- 1 x bouquet of flowers
- 1 x cat bowl
- 1 x golden key
- 1 x carrot
- 1 x oven
- 2 x mangers
- 2 x troughs
- 2 x saddle holders

- 4 x paddocks
- 1 x grooming box
- 1 x curry comb
- 1 x horse brush
- 2 x apples
- 1 x pitchfork
- 1 x saddle
- 1 x bridle and reins
- 2 x hay bales
- 3 x rosettes
- 1 x trophy
- 2 x boxwood in a tub
- 1 x horse weathervane
- 2 x flags
- 1 x well
- 1 x hose holder with water hose
- 1 x sticker sheet
- 1 x assembly instructions booklet



Figure 1: Overview of the Lakeside Country House and Stable playset and its included accessories.

4. Setup and Assembly

Assembly of the Lakeside Country House and Stable is required before play. Please follow the detailed steps provided in the included assembly instructions booklet. Ensure you have a clear, flat surface for assembly.

1. **Unpack all components:** Carefully remove all pieces from the packaging and verify against the "What's in the Box" list.
2. **Refer to the Assembly Instructions:** The playset comes with a dedicated assembly instructions booklet. This booklet contains step-by-step diagrams and directions for constructing the house, stable, and attaching accessories.
3. **Connect structural pieces:** Begin by connecting the main structural elements of the house and stable as indicated in the booklet. Pieces are designed to fit together securely.
4. **Add smaller details and accessories:** Once the main structure is complete, attach the balcony, furniture, and other smaller accessories.
5. **Apply stickers:** Use the included sticker sheet to add decorative details as shown in the assembly instructions.

6. **Place figures and animals:** Arrange the figures, horses, and other animals within the playset to begin your imaginative adventures.




Figure 2: The fully assembled Lakeside Country House and Stable, ready for play.

5. Operating and Play Instructions

The Schleich Horse Club Lakeside Country House and Stable is designed for open-ended imaginative play. There are no specific "operating" procedures, but here are suggestions for maximizing play value:

- **Storytelling:** Use the included figures (Hannah, Sofia, Lisa, Sarah, mother, father, horses, kittens) to create various scenarios and stories around the Lakeside Country House and Stable.
- **Role-Playing:** Encourage children to role-play daily life at the stable, including feeding the horses, grooming, riding, and caring for the animals.
- **Exploration:** Utilize all areas of the playset, including the house with its various rooms (bedroom, bathroom, kitchen), the stable, and the outdoor areas with paddocks and the well.
- **Accessory Use:** Integrate all accessories into play, such as the furniture, kitchen items, grooming tools, and horse riding equipment, to enhance realism and detail in storytelling.
- **Expand the World:** This playset can be combined with other Schleich Horse Club figures and playsets to create an even larger and more diverse play world.



Figure 3: A child engaging in imaginative play with the Horse Club playset.

6. Maintenance and Care

To ensure the longevity and cleanliness of your Schleich playset, follow these simple care instructions:

- **Cleaning:** Wipe figures and playset components with a damp cloth. For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water and air drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a clean, dry environment away from direct sunlight and extreme temperatures to prevent material degradation or color fading.
- **Handling:** Handle figures and delicate parts with care to avoid breakage.
- **Inspection:** Periodically inspect all parts for any signs of wear or damage. Discontinue use if any part is broken or poses a safety risk.

7. Troubleshooting

Most issues with the playset can be resolved with simple checks. If you encounter any problems, please refer to the following:

Problem	Possible Cause	Solution
Missing parts upon unboxing	Packaging error or part overlooked.	Carefully re-check all packaging materials. If still missing, contact Schleich customer support.
Difficulty assembling a piece	Incorrect orientation or force applied.	Refer to the assembly instructions booklet for correct orientation. Ensure pieces are aligned properly before applying gentle pressure. Do not force parts.
Figures or accessories do not stand upright	Uneven surface or improper placement.	Ensure the playset is on a flat, stable surface. Adjust the pose of figures or placement of accessories for better balance.

8. Specifications

Attribute	Detail
Product Name	Schleich Horse Club Lakeside Country House and Stable
Model Number	42416
Brand	Schleich
Product Dimensions	6.3 x 13.58 x 14.76 inches
Item Weight	10.47 pounds
Manufacturer Recommended Age	5 - 12 years
Number of Pieces	70
Release Date	July 1, 2019

9. Warranty and Customer Support

Schleich is committed to manufacturing high-quality, realistic toys. While specific warranty details are not provided in this manual, Schleich products are built to last and meet or exceed strict toy safety requirements.
For any questions, concerns, or assistance with missing parts or product defects, please contact Schleich customer support directly. You can find contact information on the official Schleich website or through the retailer where the product was purchased.
Visit the official Schleich website for more information:www.schleich-s.com

© 2024 Schleich. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B079NKV4S1

More documents and user manuals: **https://manuals.plus/**