

Jam Audio HX-P101

JAM Audio Hang Up Bluetooth Speaker (Model HX-P101) Instruction Manual

Brand: JAM Audio | Model: HX-P101

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your JAM Audio Hang Up Bluetooth Speaker, Model HX-P101. Designed for portability and durability, this speaker features an IP67 waterproof, dust-proof, and drop-proof rating, making it suitable for various environments.



Figure 1: JAM Audio Hang Up Bluetooth Speaker (Red)

The JAM Audio Hang Up speaker is a compact, red portable Bluetooth speaker with a blue strap. It features a durable design, making it ideal for outdoor and wet environments.

SETUP

Charging the Speaker

The Hang Up speaker features an integrated USB charging cable.

1. Locate the integrated USB cable on the speaker.
2. Connect the USB cable to a compatible USB power source (e.g., computer, USB wall adapter).
3. The charging indicator light will illuminate.
4. Allow approximately 2-3 hours for a full charge. A full charge provides up to 8 hours of playtime.




Figure 2: Speaker features including the integrated USB cable

This image highlights key features of the speaker, including the integrated USB cable for charging, the speakerphone function, and its IP67 water and dust-proof rating. The blue 'X' and 'O' symbols are visible on the side.

Powering On/Off

- To power on, press and hold the power button (usually indicated by a circle with a vertical line).
- To power off, press and hold the power button again.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is charged and powered on. The Bluetooth indicator light will flash, indicating it's in pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "Hang Up" from the list of available devices.
4. Once paired, the speaker will emit a confirmation sound, and the Bluetooth indicator light will stop flashing and remain solid.

Your browser does not support the video tag.

Video 1: JAM Sizzle Video - Demonstrating speaker features and connectivity.

This video provides a general overview of the JAM Audio Hang Up speaker, showcasing its design, portability, and the process of

connecting it via Bluetooth to a mobile device. It also demonstrates the sound quality.

Using the Speakerphone

- When a call comes in, the music will pause, and the speaker will ring.
- Press the play/pause button (often integrated with the power button or a separate phone icon) to answer the call.
- To end the call, press the play/pause button again.
- To make a call, dial from your phone, and the speaker will automatically function as a hands-free device.

Aux-In Connection

- For non-Bluetooth devices, connect a 3.5mm audio cable (not included) to the Aux-In port on the speaker and your device.
- The speaker will automatically switch to Aux-In mode.

Using the Stick Pad

The innovative stick pad on the back of the speaker allows it to adhere to flat, smooth surfaces.

- Ensure the surface is clean and dry for optimal adhesion.
- Press the speaker firmly against the desired surface (e.g., shower wall, mirror, kitchen tiles).
- To remove, gently peel the speaker off the surface. The stick pad is reusable; clean it with water if it loses adhesion.



Figure 3: Speaker mounted on a shower wall

This image shows the JAM Audio Hang Up speaker in red, attached to a tiled shower wall, demonstrating its intended use in wet environments thanks to its stick pad and waterproof design.

MAINTENANCE

- **Cleaning:** The speaker is IP67 rated, meaning it is dirt-proof and submersible in water up to one meter for 30 minutes. To clean, wipe with a damp cloth. For the stick pad, rinse with water and let it air dry if it loses its stickiness.
- **Storage:** Store the speaker in a cool, dry place when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly.

TROUBLESHOOTING

Common Issues and Solutions:

- **Speaker not powering on:** Ensure the speaker is fully charged. Connect the integrated USB cable to a power source

- and allow it to charge for at least 30 minutes before attempting to power on again.
- **Unable to pair via Bluetooth:**
 - a. Ensure the speaker is in pairing mode (flashing Bluetooth indicator light).
 - b. Turn off and on Bluetooth on your device.
 - c. Move the speaker closer to your device (within 30 feet).
 - d. Forget "Hang Up" from your device's Bluetooth settings and attempt to pair again.
 - e. Restart both the speaker and your device.
 - **No sound or distorted sound:**
 - a. Check the volume levels on both the speaker and your connected device.
 - b. Ensure the speaker is properly paired or connected via Aux-In.
 - c. If using Aux-In, ensure the cable is fully inserted and not damaged.
 - d. Try playing audio from a different source or device to rule out source issues.
 - **Stick pad losing adhesion:** Rinse the stick pad with clean water and let it air dry to restore stickiness. Ensure the surface you are attaching it to is clean and dry.

Your browser does not support the video tag.

Video 2: Speaker exhibiting unusual behavior (repeated power-on sounds, failure to pair).

This video demonstrates a common issue where the speaker repeatedly attempts to power on or pair, producing unusual sounds without successfully connecting or functioning. This can indicate a battery or internal fault.

SPECIFICATIONS

Model Name	HX-P101
Brand	Jam Audio
Speaker Type	Built-in
Special Feature	Waterproof
Connectivity Technology	Auxiliary, Bluetooth, USB
Wireless Communication Technology	Bluetooth
Water Resistance Level	Waterproof (IP67 Rated)
Playtime	Up to 8 hours
Item Weight	8.8 ounces
Product Dimensions	5.12 x 2.2 x 5.12 inches
Power Source	Battery Powered (1 Lithium Ion battery required)
Mounting Type	Stick Mount

WARRANTY & SUPPORT

Warranty Information

The JAM Audio Hang Up Bluetooth Speaker comes with a **Limited Warranty**. For specific terms and conditions, please

refer to the warranty card included with your product or visit the official JAM Audio website.

Customer Support

For further assistance, technical support, or warranty claims, please contact JAM Audio customer service.

- **Website:** Visit the [JAM Audio Store on Amazon](#) for product information and support resources.
- **Contact:** Refer to your product packaging or the official JAM Audio website for direct contact information (phone, email).



Related Documents - HX-P101

	<p>Jam Plus HX-P240A Bluetooth Speaker User Guide and Warranty</p> <p>Official user guide and warranty information for the Jam Plus HX-P240A Bluetooth speaker by Jam Audio. Learn how to pair, charge, use features like speakerphone and stereo mode, and understand regulatory compliance.</p>
	<p>JAM Classic HX-P325 Wireless Speaker Quick Start Guide</p> <p>This document provides a quick start guide for the JAM Classic HX-P325 wireless speaker, including setup, operation, and specifications.</p>
	<p>Jam Audio Jam Plus HX-P240A Bluetooth Speaker User Manual</p> <p>User manual and warranty information for the Jam Audio Jam Plus HX-P240A portable Bluetooth speaker. Learn how to pair, charge, control, and troubleshoot your device.</p>
	<p>Jam "Been There" HX-HP202 Headphones Instruction Manual</p> <p>Comprehensive guide for Jam "Been There" HX-HP202 headphones, covering setup, charging, Bluetooth pairing, button functions, call handling, LED indicators, and warranty information.</p>
	<p>JAM HX-P400 Bluetooth Bookshelf Speaker Quickstart Guide</p> <p>A concise guide to setting up and using the JAM HX-P400 Bluetooth Bookshelf Speakers, covering Bluetooth pairing, AUX connection, and RCA line-in setup.</p>

