

Kaiser KBS-3080

Kaiser KBS-3080 2.1 Channel Home Theater Soundbar System User Manual

Model: KBS-3080

1. INTRODUCTION

Thank you for choosing the Kaiser KBS-3080 2.1 Channel Home Theater Soundbar System. This system is designed to enhance your audio experience with powerful sound and versatile connectivity options. This manual provides essential information for the safe and efficient use of your new soundbar system. Please read it thoroughly before operation and retain it for future reference.



Image 1.1: The Kaiser KBS-3080 Soundbar System, including the soundbar, external subwoofer, and remote control.

2. PRODUCT OVERVIEW

2.1 Key Features

- **2.1 Channel Audio:** Delivers 40W RMS with an integrated subwoofer for balanced and powerful sound.
- **KSR-Link Technology:** Allows connection with other compatible devices for an expanded audio experience.
- **Versatile Connectivity:** Supports Bluetooth, USB, Micro SD, and auxiliary input for playback from

various sources.

- **Included Remote Control:** Easily manage volume, modes, and functions from a distance.
- **Modern Design:** A sleek soundbar that integrates seamlessly with your television and home decor.

2.2 Components Included

- Soundbar Unit
- Subwoofer Unit
- Remote Control
- User Guide (this document)



Image 2.1: An angled perspective of the soundbar and subwoofer, highlighting their design and the included remote control.

3. SETUP INSTRUCTIONS

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Verify that all included components are present.
3. Retain packaging materials for future transport or service.

3.2 Placement

- **Soundbar:** Place the soundbar on a stable, flat surface directly in front of your television, ensuring it does not obstruct the TV's remote sensor. Alternatively, the soundbar supports wall mounting.
- **Subwoofer:** Position the subwoofer on the floor near the soundbar. For optimal bass performance, experiment with different locations in the room.



Image 3.1: Side view of the soundbar and subwoofer, illustrating their relative sizes and potential placement options.

3.3 Connections

1. Connect the soundbar to the subwoofer using the provided cable.
2. Connect the soundbar to your television or other audio source using one of the following methods:
 - **Auxiliary (AUX) Input:** Use a 3.5mm audio cable to connect the soundbar's AUX port to your device's audio output.
 - **USB Input:** Insert a USB flash drive containing audio files into the USB port.
 - **Micro SD Card:** Insert a Micro SD card containing audio files into the Micro SD slot.
3. Connect the power cable to the soundbar and then to a power outlet.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

Press the Power button on the soundbar or the remote control to turn the system on or off.

4.2 Source Selection

Press the 'Mode' button on the soundbar or remote control to cycle through available input sources: Bluetooth, USB, Micro SD, and AUX.

4.3 Bluetooth Pairing

1. Select Bluetooth mode on the soundbar. The display will show 'BLUE' or a similar indicator, and the unit will enter pairing mode.
2. On your Bluetooth-enabled device (e.g., smartphone, tablet), search for available Bluetooth devices.
3. Select 'KBS-3080' from the list. Once paired, the soundbar will indicate a successful connection.

4.4 KSR-Link Function

The KSR-Link feature allows you to connect this soundbar with other compatible Kaiser KSR-Link devices to create a synchronized audio experience. Refer to the specific instructions for your other KSR-Link devices for

detailed pairing procedures.

4.5 Remote Control Functions

The included remote control provides full command over your soundbar system. Functions include: Power On/Off, Volume Up/Down, Mode Selection, Play/Pause, Skip Tracks (for USB/Micro SD/Bluetooth), and Equalizer presets (if available).



Image 4.1: Top-down view showing the soundbar's control panel and the remote control, illustrating user interaction points.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar and subwoofer. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure that the ventilation openings on the subwoofer are not blocked to prevent overheating.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active	Ensure power cable is securely connected; Test power outlet with another device
No sound	Incorrect input source; Volume too low; Cables not connected properly	Select correct input source; Increase volume; Check all audio connections
Bluetooth disconnects frequently	Device too far; Interference; Low battery on connected device	Move device closer to soundbar; Avoid obstacles; Charge connected device
Remote control not working	Batteries depleted; Obstruction between remote and soundbar; Incorrect angle	Replace remote batteries; Remove obstructions; Point remote directly at soundbar's sensor

7. SPECIFICATIONS

Feature	Specification
Model Name	KBS-3080
Speaker Type	Soundbar with Subwoofer
Mounting Type	Wall Mount
Special Feature	Bluetooth
Recommended Use	For Televisions
Compatible Devices	Television, Bluetooth Devices
Surround Sound Channel Configuration	2.1
Product Dimensions (Subwoofer)	28.5 cm (Depth) x 15.5 cm (Width) x 31 cm (Height)
Product Weight	5.7 Kilograms
Control Method	Remote Control
Wireless Communication Technology	Bluetooth
Soundbar Length	96 Centimeters (approx. 1 meter)
Power Source	Electric Cable
Speaker Amplification Type	Active
Speaker Connectivity	USB
Wattage	40 Watts RMS
Max Speaker Output Power	40 Watts
Frequency Response (Subwoofer)	150 Hz (lower end)
Audio Output Mode	Surround (2.1 Channel)

8. WARRANTY AND SUPPORT





8.1 Warranty Information



This Kaiser KBS-3080 soundbar system comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. Retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Kaiser customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.

Related Documents - KBS-3080

 <p>KBS-3080 BARRA DE SONIDO BLUETOOTH <small>*Una conector de audio para conectar con una fuente de audio externa (opcional).</small></p>	<p>Kaiser KBS-3080 Bluetooth Soundbar User Manual</p> <p>This manual provides instructions for the Kaiser KBS-3080 Bluetooth Soundbar, including setup, operation, and specifications. Learn how to connect, use different modes (Bluetooth, Aux, FM Radio), and understand the remote control functions.</p>
 <p>KAISER <small>MODELO D. KBS-3040</small> BARRA DE SONIDO BLUETOOTH CON SUBWOOFER</p>	<p>Kaiser KBS-3040 Bluetooth Soundbar with Subwoofer User Manual</p> <p>Comprehensive user manual for the Kaiser KBS-3040 Bluetooth Soundbar with Subwoofer, detailing setup, operation, features, specifications, safety guidelines, and warranty information.</p>
 <p>KAISER <small>MODELO D. MSA-7618</small> Altavoz acústico montado en caja acústica (Bafle) boombox 18" (46,72 cm)</p>	<p>Kaiser MSA-7618 Boombox Speaker Manual</p> <p>User manual for the Kaiser MSA-7618 18-inch boombox speaker, covering setup, operation, features, and specifications. Learn how to connect, charge, and use the speaker with various audio sources and microphones.</p>
 <p>KAISER <small>MODELO D. KSW-5008</small> Altavoces acústicos montados en caja acústica (Bafle) boombox 8" (20,32 cm)</p>	<p>Altavoces Acústicos KAISER KSW-5008 Boombox 8" - Manual de Usuario y Garantía</p> <p>Manual completo para el altavoz acústico KAISER KSW-5008 boombox de 8 pulgadas. Incluye instrucciones de uso, carga, funcionamiento, especificaciones técnicas y póliza de garantía.</p>

 <p>KAISER MODELO KSW-7003</p> <p>Altavoces acústicos montados en caja acústica (Baffle) boombox 9" (23,2 cm)</p> <p>¡Cuidado! La información contenida en este documento depende del modelo de la Kaiser KSW-7003. Si usted utiliza otro modelo, consulte el manual correspondiente. Lea cuidadosamente las instrucciones y el diagrama antes de utilizar el producto. Este manual es propiedad de Kaiser. No se permite la reproducción o el uso no autorizado sin el consentimiento escrito de Kaiser.</p> <p>www.kaiser.com @KaiserUSA #KaiserUSA</p>	<p>Kaiser KSW-7003 Boombox Speaker: Manual, Specifications, and Warranty</p> <p>Comprehensive guide for the Kaiser KSW-7003 acoustic speaker boombox, including setup, operation, technical specifications, safety information, and warranty details from Mitzu.</p>
 <p>KAISER MODELO MSA-9908BT</p> <p>Altavoces acústicos montados en caja acústica (Baffle) boombox 8" (20,32 cm)</p> <p>¡Cuidado! La información contenida en este documento depende del modelo de la Kaiser MSA-9908BT. Si usted utiliza otro modelo, consulte el manual correspondiente. Lea cuidadosamente las instrucciones y el diagrama antes de utilizar el producto. Este manual es propiedad de Kaiser. No se permite la reproducción o el uso no autorizado sin el consentimiento escrito de Kaiser.</p> <p>www.kaiser.com @KaiserUSA #KaiserUSA</p>	<p>Kaiser MSA-9908BT Acoustic Speakers Boombox 8" - User Manual</p> <p>User manual for the Kaiser MSA-9908BT acoustic speakers boombox 8". Includes setup, operation, specifications, and warranty information.</p>

Documents - Kaiser – KBS-3080



[Kaiser KBS-3080 Bluetooth Soundbar User Manual](#)

This manual provides instructions for the Kaiser KBS-3080 Bluetooth Soundbar, including setup, operation, and specifications. Learn how to connect, use different modes (Bluetooth, Aux, FM Radio), and understand the remote control functions.

lang:es score:31 filesize: 210.46 K page_count: 6 document date: 2019-10-25