

[Manuals.plus](#) /

› [Seneca River Trading](#) /

› Seneca River Trading Presto Pressure Cooker Sealing Ring Gasket 09906 Instruction Manual

## Seneca River Trading 09906

# Seneca River Trading Presto Pressure Cooker Sealing Ring Gasket 09906 Instruction Manual

Model: 09906

## INTRODUCTION

This instruction manual provides essential information for the proper installation and maintenance of your Seneca River Trading Presto Pressure Cooker Sealing Ring Gasket, Part Number 09906. This 2-pack of gaskets is designed to restore the safe and efficient operation of compatible Presto 4-quart and 6-quart aluminum pressure cookers by ensuring a pressure-tight seal.

## PRODUCT OVERVIEW

The sealing ring gasket is a critical component of your pressure cooker, forming a seal between the lid and the cooker body to allow pressure to build safely. This product includes two replacement gaskets and an automatic air vent.



Image: The Presto Pressure Cooker Sealing Ring Gasket 09906, shown with its packaging and the included automatic air vent.

- **Quantity:** Two (2) sealing ring gaskets.
- **Material:** OEM-grade rubber for durability and flexibility.
- **Function:** Forms a secure, pressure-tight seal.
- **Safety Feature:** Includes an automatic air vent for safe steam release.

## COMPATIBILITY

This sealing ring gasket (Part #09906) is compatible with the following Presto 4-quart and 6-quart aluminum pressure cooker models:

- 01/PCS4
- 01/PCS6
- 02/PCS4
- 02/PCS6
- 803B
- 804
- 804B
- 833
- C301A
- C301B
- C401A
- C401B
- C601A
- C603A

*Always verify your pressure cooker's model number before purchasing replacement parts.*

## INSTALLATION INSTRUCTIONS

---

Follow these steps to replace the sealing ring gasket in your Presto pressure cooker:

1. **Ensure Safety:** Before beginning, ensure your pressure cooker is completely cool and fully depressurized. Never attempt to open or service a hot or pressurized cooker.
2. **Remove Old Gasket:** Carefully remove the old sealing ring gasket from the groove inside the pressure cooker lid. It may be stiff or brittle if it's old.
3. **Clean Lid Groove:** Thoroughly clean the gasket groove in the lid to remove any food particles, grease, or residue. A clean groove is essential for a proper seal.
4. **Inspect New Gasket:** Unpack the new Seneca River Trading gasket. Inspect it for any defects or damage.
5. **Install New Gasket:** Work the new gasket into the groove evenly. It is often easiest to start by seating the gasket at four equidistant points (top, bottom, left, right) and then working your way around the entire rim, pressing firmly to ensure it is securely seated.



Image: The replacement sealing ring gasket, ready for installation into the lid groove.

6. **Install Air Vent:** If your old air vent is worn or damaged, replace it with the new automatic air vent provided. Ensure it is seated correctly.



Image: Close-up of the automatic air vent, a small component that ensures safe steam release.

7. **Test Seal:** Close the pressure cooker lid and ensure it engages properly. Before cooking, perform a water test (fill with water, bring to pressure, and check for leaks) to confirm the new gasket forms a reliable seal.

## MAINTENANCE

---

Proper maintenance extends the life of your sealing ring gasket and ensures safe pressure cooking:

- **Cleaning:** After each use, remove the gasket from the lid and wash it with warm, soapy water. Rinse thoroughly and dry completely before storing.
- **Storage:** Store the gasket loosely in the pressure cooker or separately to prevent it from becoming compressed or distorted. Avoid hanging it or stretching it unnecessarily.
- **Inspection:** Regularly inspect the gasket for cracks, tears, hardening, or any signs of wear. A worn gasket can prevent the cooker from sealing properly.
- **Replacement:** Gaskets typically need replacement every 6-12 months, or sooner if signs of wear are present, to maintain optimal performance and safety.



Image: A close-up view of the rubber material of the sealing ring gasket, highlighting its flexibility and texture.

## TROUBLESHOOTING

---

If your pressure cooker is not sealing properly after gasket replacement, consider the following:

- **Gasket Seating:** Ensure the gasket is fully and evenly seated in the lid groove. Remove and re-seat it if necessary.
- **Lid Alignment:** Verify that the lid is correctly aligned and locked onto the cooker body according to your pressure cooker's specific instructions.
- **Cleanliness:** Check for any food debris or residue on the gasket or in the lid groove that might be preventing a seal.
- **Gasket Condition:** Even new gaskets can sometimes have minor imperfections. If issues persist, inspect the gasket closely for any manufacturing defects.
- **Cooker Rim:** Inspect the rim of your pressure cooker pot for any dents or damage that could prevent a proper seal.

SPECIFICATIONS

|                         |                                                      |
|-------------------------|------------------------------------------------------|
| Part Number             | 09906                                                |
| Quantity                | 2 per pack                                           |
| Material                | Rubber                                               |
| Color                   | Black                                                |
| Compatible Cooker Sizes | 4-quart and 6-quart Presto aluminum pressure cookers |
| Dishwasher Safe         | Yes                                                  |
| Dimensions (approx.)    | 9"D x 7"W x 2"H (packaged)                           |
| Item Weight             | 0.5 Pounds                                           |

WARRANTY INFORMATION

This product comes with a 30-day warranty from the date of purchase. This warranty covers manufacturing defects. For warranty claims or further details, please contact Seneca River Trading customer service.

CUSTOMER SUPPORT

For additional assistance, questions regarding compatibility, or troubleshooting, please refer to the official Presto website or contact Seneca River Trading customer support. Always refer to your specific pressure cooker's manual for detailed operating instructions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**