

Satisfyer Traveler

Satisfyer Traveler Vibrator Instruction Manual

Model: Traveler

1. INTRODUCTION

Thank you for choosing the Satisfyer Traveler. This compact and discreet device is designed for clitoral stimulation using innovative air pulse technology. Crafted from body-friendly silicone, it offers 11 intensity settings and is fully waterproof for versatile use. This manual provides essential information for the safe and effective operation, maintenance, and care of your device.



The Satisfyer Traveler features patented air pulse technology with 11 intensity programs for varied stimulation.

2. SAFETY INFORMATION

- **Material Safety:** The device is made from skin-friendly silicone. Clean thoroughly before and after each use.
- **Waterproof:** The Satisfyer Traveler is waterproof (IPX7 rated) and can be used in the shower or bath. Ensure the charging port is dry before charging.
- **Charging:** Use only the original magnetic charging cable provided. Do not use the device while charging.
- **Storage:** Store in a clean, dry place, away from direct sunlight and extreme temperatures. The magnetic cap provides hygienic storage.
- **Disposal:** Do not dispose of the device with household waste. Follow local regulations for electronic waste disposal.

- **Legal Disclaimer:** Statements regarding this product have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

3. SETUP

1. **Initial Charge:** Before first use, fully charge your Satisfyer Traveler. Connect the magnetic charging cable to the charging contacts on the device and plug the USB end into a suitable power source (e.g., computer USB port, USB wall adapter). The indicator light will show charging status.
2. **First Cleaning:** Clean the device thoroughly with warm water and a mild, toy-safe cleanser before its initial use. Rinse well and dry completely.

4. OPERATING INSTRUCTIONS

The Satisfyer Traveler features intuitive controls for easy operation.



Control buttons for power and intensity adjustment are located on the device.

- **Power On/Off:** Press and hold the power button (circle icon) for approximately 2 seconds to turn the device on or off.
- **Increase Intensity:** Press the '+' button to cycle through the 11 intensity programs.
- **Decrease Intensity:** Press the '-' button to reduce the intensity.
- **Application:** Place the stimulation head over the desired area. The device uses non-contact air pulse technology. Experiment with different positions and intensity levels to find what is most comfortable and effective for you.

Your browser does not support the video tag.

This video demonstrates the features and operation of the Satisfyer Traveler stimulator.

5. CLEANING AND MAINTENANCE

Proper cleaning and maintenance ensure the longevity and hygiene of your device.

Satisfyer



Why you will love it:



TRAVEL SIZE



AIR PULSE



EASY TO CLEAN



WATERPROOF



SILICONE



WHISPER MODE

The waterproof design allows for easy cleaning under running water.

- **Cleaning:** After each use, clean the device with warm water and a mild, toy-safe soap or specialized toy cleaner. Avoid harsh chemicals or abrasive cleaners.
- **Rinsing:** Rinse the device thoroughly to remove all soap residue.
- **Drying:** Pat dry with a lint-free cloth or allow it to air dry completely before storage.
- **Storage:** Store your Satisfyer Traveler in its original packaging or a clean, dry pouch. The magnetic cap helps keep the stimulation head protected and hygienic.

WHY SEXUAL WELLNESS?

Just like **leafy greens & sunscreen**, **sexual pleasure** is a key piece of overall **health & wellness**.

At Satisfyer, our mission is to blend **sexual health & tech innovation** that easily fits into your **self-care routine**. Orgasm is for everyone - all bodies, all levels of ability, no holds barred.

Satisfyer

The magnetic cap ensures discreet and hygienic storage, making it ideal for travel.

6. CHARGING

The Satisfyer Traveler is rechargeable for convenience.

- **Charging Method:** Use the included magnetic USB charging cable. Connect the magnetic end to the charging contacts on the device.

- **Charging Indicator:** The indicator light will illuminate during charging. It typically changes color or stops blinking when fully charged. Refer to the specific light behavior in your product's quick start guide if available.
- **Battery Life:** A full charge provides several hours of use, depending on the intensity setting.

7. TROUBLESHOOTING

If you encounter any issues with your Satisfyer Traveler, refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully.
	Power button not pressed correctly.	Press and hold the power button for 2 seconds.
Device is not charging.	Magnetic connection is poor.	Ensure the magnetic charger is securely attached to the charging contacts. Clean contacts if necessary.
	Charging cable or power source is faulty.	Try a different USB port or power adapter.
Reduced intensity or weak air pulses.	Battery is low.	Recharge the device.
	Stimulation head is blocked or dirty.	Clean the stimulation head thoroughly.

If problems persist, please refer to the Warranty and Support section.

8. SPECIFICATIONS

Feature	Detail
Model Name	Satisfyer Traveler
Item Model Number	S4049369015900
Product Dimensions	4.21 x 1.81 x 3.5 inches
Weight	5.29 ounces
Material	Silicone
Color	Aubergine With Rose Gold Accents
Intensity Settings	11
Waterproof Rating	IPX7
Battery	Rechargeable (2 AA batteries included, likely internal rechargeable type)
Manufacturer	Triple A Marketing GMBH

9. WARRANTY AND SUPPORT

Satisfyer stands by the quality of its products.

- **Warranty:** The Satisfyer Traveler comes with a **15-year product protection/warranty**. This warranty covers manufacturing defects and ensures long-lasting satisfaction. Please retain your proof of purchase.
- **Support:** For warranty claims, technical assistance, or any questions regarding your device, please contact Satisfyer customer support through their official website or the retailer where the product was purchased.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question