

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hape](#) /

› [Hape E4056 Beach Toys Set: 4-Piece Basic Equipment Instruction Manual](#)

## Hape E4056

# Hape E4056 Beach Toys Set: 4-Piece Basic Equipment Instruction Manual

Model: E4056 | Brand: Hape

## INTRODUCTION

The Hape E4056 Beach Toys Set provides essential tools for creative sand play. This 4-piece basic equipment set is designed for outdoor use, offering durable and safe components for children aged 18 months and older. The set includes a rake, a shovel, a strainer, and a bucket, all made from sturdy, UV-resistant plastic to ensure long-lasting fun. This manual provides instructions for the proper use, care, and maintenance of your Hape E4056 Beach Toys Set.

## PACKAGE CONTENTS

Your Hape E4056 Beach Toys Set includes the following items:

- 1 x Bucket (red)
- 1 x Shovel (orange)
- 1 x Rake (blue)
- 1 x Strainer (turquoise)




Image: The four components of the Hape E4056 Beach Toys Set, including a red bucket, an orange shovel, a blue rake, and a turquoise strainer, laid out on a white background.

## SETUP

The Hape E4056 Beach Toys Set requires no assembly. All components are ready for immediate use straight out of the packaging.

1. Remove all items from the packaging.
2. Inspect each piece for any signs of damage. If any item is damaged, do not use it and contact customer support.
3. The toys are now ready for use in sand or water.

## OPERATING INSTRUCTIONS

These beach toys are designed for imaginative play in sand and water environments. Encourage children to explore different ways to use each tool.



Image: Two young children are actively engaged in sand play on a beach. One child is using a shovel to transfer sand into a bucket, while the other child is observing. The ocean is visible in the background.

- **Bucket:** Use to carry sand or water, or as a mold for sandcastles.
- **Shovel:** Ideal for digging, scooping, and moving sand.
- **Rake:** Perfect for smoothing sand, creating patterns, or gathering small objects.
- **Strainer:** Use to sift sand, separating shells or pebbles, or to drain water.

#### **Safety Note:**

- Always supervise children during play, especially near water.
- Ensure children do not put small parts or sand into their mouths.
- Do not use the toys for purposes other than intended.

Your browser does not support the video tag.

Video: A demonstration of how the Hape beach toys can be used for sand play, showcasing the bucket, shovel, rake, and strainer in action. This video provides a closer look at the product's functionality.

## MAINTENANCE

Proper care will extend the life of your Hape E4056 Beach Toys Set.

- **Cleaning:** After each use, rinse all components thoroughly with fresh water to remove sand, salt, or dirt.
- **Drying:** Allow the toys to air dry completely before storing to prevent mildew or odors.
- **Storage:** Store the toys in a cool, dry place away from direct sunlight when not in use. Prolonged exposure to intense sunlight may cause slight fading over time, although the material is UV resistant.
- **Inspection:** Periodically check for any cracks, sharp edges, or damage. Discontinue use if any damage is found.

## TROUBLESHOOTING

The Hape E4056 Beach Toys Set is a simple product with minimal parts, so troubleshooting is generally straightforward.

Problem	Possible Cause	Solution
Sand sticking to toys	Toys are wet or sand is too moist.	Rinse toys thoroughly and allow to dry. Use drier sand if possible.
Toys appear faded	Prolonged exposure to direct sunlight.	This is normal wear over time. Store toys in a shaded area when not in use to minimize fading.
Cracks or damage on toys	Impact or excessive force during play.	Discontinue use immediately to prevent injury. Contact customer support for replacement options.

## SPECIFICATIONS

- **Model:** E4056
- **Brand:** Hape
- **Included Components:** 1 bucket, 1 shovel, 1 rake, 1 strainer
- **Material:** Artificial (Plastic)
- **Color:** Multi-colored (Red bucket, orange shovel, blue rake, turquoise strainer)
- **Item Dimensions (L x W x H):** 16.4 x 16.8 x 13 cm
- **Item Weight:** 0.29 Kilograms
- **Age Range:** 18 Months to 99 Years
- **Operation Mode:** Manual
- **Indoor/Outdoor Usage:** Outdoor
- **Assembly Required:** No
- **Batteries Required:** No
- **UV Resistant:** Yes

## WARRANTY INFORMATION

Hape products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Hape website. General warranty terms typically cover manufacturing defects under normal use.

## CUSTOMER SUPPORT

If you have any questions, concerns, or require assistance with your Hape E4056 Beach Toys Set, please contact Hape customer service through their official website or the retailer from whom you purchased the product. Please have your model number (E4056) available when contacting support.

© 2026 Hape. All rights reserved.