

[Manuals.plus](#) /

> [Hape](#) /

> Hape Baker's Trio Sand & Beach Molds Set (Model E4055) Instruction Manual

Hape E4055

Hape Baker's Trio Sand & Beach Molds Set (Model E4055) Instruction Manual

INTRODUCTION

Thank you for choosing the Hape Baker's Trio Sand & Beach Molds Set. This set is designed to provide an engaging and creative play experience for toddlers, allowing them to create imaginative sand "baked goods" at the beach or in a sandbox. This manual provides essential information for the safe and proper use and care of your product.

PRODUCT COMPONENTS

The Hape Baker's Trio Sand & Beach Molds Set includes 5 pieces:

- 3 x Cake Molds (various shapes)
- 1 x Plastic Knife
- 1 x Serving Tool



Image: The Hape Baker's Trio Sand & Beach Molds Set in use, showing two children creating sand cakes with the molds and tools on a sandy beach.

SETUP

The Hape Baker's Trio Sand & Beach Molds Set requires no assembly. Simply remove all packaging materials before use. Ensure all 5 components are present and undamaged.

OPERATING INSTRUCTIONS

1. **Prepare the Sand:** For best results, use damp sand. If the sand is too dry, it may not hold its shape. If it's too wet, it might be difficult to remove from the molds.
2. **Fill the Molds:** Press the cake molds firmly into the damp sand, ensuring they are completely filled.
3. **Compact the Sand:** Gently press down on the sand within the molds to compact it. This helps the sand hold its shape when inverted.
4. **Invert and Release:** Carefully lift the mold and invert it onto a flat sand surface. Gently tap the mold to release the sand cake.
5. **Decorate and Serve:** Use the plastic knife to "slice" the sand cakes and the serving tool to "serve" them. Encourage imaginative play and role-playing.

MAINTENANCE

To ensure the longevity and hygiene of your Hape Baker's Trio Sand & Beach Molds Set:

- **Cleaning:** After each use, rinse all components thoroughly with clean water to remove sand and debris.
- **Drying:** Allow all pieces to air dry completely before storing to prevent mold or mildew.

- **Storage:** Store the set in a clean, dry place away from direct sunlight when not in use.
- **Inspection:** Periodically inspect the toys for any signs of wear or damage. Discontinue use if any parts are broken or cracked.

TROUBLESHOOTING

This product is simple in design, and most issues relate to sand consistency.

- **Sand Not Holding Shape:** If sand cakes collapse or do not form properly, the sand may be too dry or not compacted enough. Add a small amount of water to the sand and ensure it is firmly pressed into the molds.
- **Sand Sticking to Molds:** If sand consistently sticks, the sand might be too wet, or the molds might not be clean. Rinse molds thoroughly and adjust sand moisture.

SPECIFICATIONS

Brand	Hape
Model Number	E4055
Age Range (Description)	18 months and up
Material	Polypropylene
Color	Multi-color
Educational Objective	Creative Thinking, Building Skills
Item Dimensions (LxWxH)	14.3 x 15.6 x 9.2 cm
Power Source	Manual
Assembly Required	No
Batteries Required	No
Country of Origin	China
UPC	689304181655

SAFETY INFORMATION

- This product is intended for children aged 18 months and older.
- Adult supervision is recommended during play, especially near water.
- All materials are non-toxic and child-safe.
- Do not use the toys for purposes other than intended.
- Keep packaging materials away from children to avoid choking hazards.

WARRANTY AND SUPPORT

Warranty: This product comes with no warranty as per manufacturer specifications.

Manufacturer Contact: For any inquiries or support, please contact:

Toynamics Europe

Scheffelstr. 41
35325 Giessen
Germany
Email: info@hapetoys.eu

