

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EGLO](#) /

› [EGLO Wymer Multi 4-Light Pendant Instruction Manual](#)

EGLO 202836A

EGLO Wymer Multi 4-Light Pendant Instruction Manual

Model: 202836A | Brand: EGLO

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your EGLO Wymer Multi 4-Light Pendant. Please read all instructions carefully before beginning installation and retain this manual for future reference.

The EGLO Wymer Multi 4-Light Pendant features a matte bronze finish and exposed bulbs, designed to complement various decor styles from rustic to contemporary. It is intended for indoor use only.

SAFETY INFORMATION

- Always turn off the main power supply at the circuit breaker before installing, servicing, or cleaning the fixture.
- Consult a qualified electrician if you are not familiar with electrical installations.
- Use only bulbs of the specified wattage and type (60 watts, A19 type). Exceeding the maximum wattage may cause overheating.
- Do not connect this fixture to an ungrounded electrical system.
- Ensure all connections are secure and properly insulated.
- This product is designed for 120 Volts.
- Keep flammable materials away from the light fixture.

PACKAGE CONTENTS

Verify that all components are present and undamaged before beginning installation.

- Pendant Fixture (1)
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

• Note: Bulbs are not included and must be purchased separately.

SETUP AND INSTALLATION

Follow these steps for proper installation of your pendant light. It is recommended to have two people for installation.

- 1. Turn Off Power:** Locate the circuit breaker controlling the light fixture's location and turn off the power. Verify power is off using a voltage tester.
- 2. Prepare Mounting:** Remove the existing fixture (if any) and its mounting bracket. Attach the new mounting plate to the electrical junction box using the provided screws. Ensure it is securely fastened.
- 3. Adjust Height (if applicable):** The pendant features an adjustable chain. Determine the desired hanging height and adjust the chain length by removing links as needed.
- 4. Wire Connections:**
 - Connect the fixture's ground wire (bare copper or green) to the ground wire from the junction box (bare copper or green) using a wire nut.
 - Connect the fixture's white wire (neutral) to the white wire from the junction box (neutral) using a wire nut.
 - Connect the fixture's black wire (hot) to the black wire from the junction box (hot) using a wire nut.
 - Ensure all connections are tight and secure.
- 5. Mount Fixture:** Carefully lift the fixture and attach the canopy to the mounting plate, securing it with the decorative nuts or screws provided.
- 6. Install Bulbs:** Screw in four A19 type bulbs (max 60 watts each) into the sockets.
- 7. Restore Power:** Turn the power back on at the circuit breaker.





Figure 1: The EGLO Wymer Multi 4-Light Pendant showing the chain and canopy for ceiling mounting.



Figure 2: Detailed view of the pendant's frame and exposed bulb sockets.

OPERATING INSTRUCTIONS

The EGLO Wymer Multi 4-Light Pendant operates like a standard light fixture. Once installed and wired correctly:

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Dimming (Optional):** If connected to a compatible dimmer switch and using dimmable bulbs, you can adjust the light intensity. Refer to your dimmer switch's instructions for specific operation.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your pendant light.

- **Cleaning:**
 - Always turn off the power and allow the fixture to cool before cleaning.
 - Wipe the fixture with a soft, dry cloth.
 - Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:**
 - Turn off the power at the circuit breaker and allow bulbs to cool completely.
 - Carefully unscrew the old bulb.
 - Screw in a new A19 type bulb, ensuring it does not exceed 60 watts.
 - Restore power.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty bulb. Faulty wall switch.	Check circuit breaker. Verify all wire connections are secure (with power off). Replace bulb. Test or replace wall switch.
Light flickers.	Loose bulb. Incorrect bulb type (not dimmable with dimmer). Loose wire connection.	Tighten bulb. Ensure dimmable bulbs are used with dimmer switches. Check wire connections (with power off).
Fixture hums.	Incompatible dimmer switch. Loose wiring.	Replace dimmer with a compatible LED/incandescent dimmer. Check wire connections (with power off).

SPECIFICATIONS

Feature	Detail
Brand	EGLO
Model Name	202836A

Feature	Detail
Color	Matte Bronze
Material	Alloy Steel, Glass (Shade)
Style	Modern
Light Fixture Form	Pendant
Power Source	corded electric
Number of Light Sources	4
Voltage	120 Volts
Wattage	60 watts (per bulb, max)
Light Source Type	A19
Product Dimensions	13 x 13 x 24 inches (L x W x H)
Item Weight	11.92 pounds
Mounting Type	Protruding
Special Feature	Adjustable
Specification Met	ETL




Figure 3: Diagram showing the length and height dimensions of the pendant fixture.

WARRANTY AND SUPPORT

Warranty Information: All products purchased have a 30-day replacement parts policy to ensure a fully working item. All products are covered under a 1-year warranty when purchased on Amazon. The warranty period begins on the day the product is originally shipped. The warranty covers all of the items and conditions identified in the original manufacturer's warranty. Some of the items specifically not covered by the warranty are loss and theft, water damage, customer abuse, and finish deterioration due to UV or coastal exposure.

Customer Support: For technical assistance, replacement parts, or warranty claims, please contact EGLO customer service. Refer to your purchase documentation or the EGLO website for contact details.

Your browser does not support the video tag.

Video 1: An official brand video from EGLO, showcasing various lighting products and the brand's commitment to design and innovation. This video provides an overview of the EGLO brand's offerings and philosophy.

© 2024 EGLO. All rights reserved.