

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [EGLO](#) /
- › [EGLO Tabanera Mini Pendant Light Model 96801A Instruction Manual](#)

EGLO 96801A

EGLO Tabanera Mini Pendant Light Instruction Manual

Model: **96801A** | Brand: **EGLO**

1. PRODUCT OVERVIEW

The EGLO Tabanera Mini Pendant Light is designed to provide focused illumination with a modern aesthetic. Featuring a classic black and white finish with white glass, this pendant light is height adjustable to suit various ceiling heights and design preferences. It is suitable for indoor use, particularly in dining rooms or similar spaces.






Image 1.1: The EGLO Tabanera Mini Pendant Light in a dining room environment, showcasing its design and application.

Key Features:

- Requires 1 E26 60W bulb (not included).
- Features a matte black finish.
- Adjustable hanging height for versatile installation.
- Dimmable functionality (dimmer not included).

2. SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries. Always consult a qualified electrician if you are unsure about any part of the installation process.

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electrical Code (NEC).

- Do not install this fixture in wet locations. It is designed for indoor use only.
- Use only the specified bulb type and wattage (1 E26 60W max). Exceeding the maximum wattage may cause overheating.
- Handle glass components with care to prevent breakage.
- Keep flammable materials away from the light fixture when in operation.

3. PACKAGE CONTENTS

Carefully unpack your new light fixture and lay out all parts on a clear area. Ensure all components listed below are present before discarding packaging materials.

- Pendant Light Fixture (1)
- Mounting Hardware (e.g., mounting bracket, screws, wire nuts)
- Instruction Manual (this document)

Note: Light bulb is not included and must be purchased separately.

4. SETUP AND INSTALLATION

Before starting, ensure the power is turned off at the circuit breaker. This fixture is designed for direct wiring to a standard electrical junction box.



Image 4.1: Dimensional diagram of the pendant light, indicating overall height and shade width.

1. **Turn Off Power:** Locate the circuit breaker or fuse box controlling the light fixture's power supply and turn it off. Verify power is off using a voltage tester.
2. **Prepare Mounting:** Attach the mounting bracket to the junction box using the provided screws. Ensure the bracket is securely fastened.
3. **Adjust Hanging Height:** The pendant light features an adjustable cord. Determine the desired hanging length and adjust the cord accordingly. Secure any excess cord within the canopy or trim as necessary, following local electrical codes.
4. **Make Electrical Connections:**
 - Connect the fixture's black wire to the house's black (hot) wire using a wire nut.
 - Connect the fixture's white wire to the house's white (neutral) wire using a wire nut.
 - Connect the fixture's ground wire (bare copper or green) to the house's ground wire and the mounting bracket's ground screw.

Ensure all connections are tight and secure.

5. **Mount Fixture:** Carefully tuck all wires into the junction box. Align the fixture's canopy with the mounting bracket and secure it with the provided screws or nuts.
6. **Install Bulb:** Screw one E26 base bulb (max 60W, not included) into the socket. Do not overtighten.

7. **Restore Power:** Turn the power back on at the circuit breaker. Test the light fixture.



Image 4.2: Detailed view of the pendant light's shade and adjustable cord mechanism.

5. OPERATING INSTRUCTIONS

The EGLO Tabanera Mini Pendant Light operates like a standard light fixture. Once installed and powered, it can be controlled via a wall switch.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Dimming:** If a compatible dimmer switch (not included) has been installed, you can adjust the light intensity by operating the dimmer switch according to its manufacturer's instructions. Ensure the installed bulb is also dimmable.

6. MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your pendant light.

- **Cleaning:** Always disconnect power before cleaning. Wipe the fixture with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:** Ensure the power is off and the bulb has cooled before attempting to replace it. Unscrew the old bulb and screw in a new E26 base bulb (max 60W).
- **Inspection:** Periodically check for any loose wiring or damaged components. If any damage is found, discontinue use and consult a qualified electrician.

7. TROUBLESHOOTING

If you encounter issues with your pendant light, refer to the following common problems and solutions:

- **Light does not turn on:**
 - Check if the power is on at the circuit breaker.
 - Ensure the light bulb is securely screwed into the socket and is not burnt out.
 - Verify electrical connections are secure (refer to Section 4).
- **Light flickers:**
 - Ensure the bulb is fully tightened.
 - If using a dimmer, ensure the bulb is dimmable and compatible with the dimmer switch.
 - Check for loose wiring connections.
- **Fixture makes humming noise:**
 - This can sometimes occur with certain dimmer switches or LED bulbs. Try a different bulb or dimmer.

If these steps do not resolve the issue, please contact customer support.

8. SPECIFICATIONS

Brand	EGLO
Model Number	96801A
Model Name	Tabanera
Color	Black & White
Material	Metal, Glass
Light Source	1 x E26 Base Bulb (A19 recommended)
Max Wattage	60 Watts
Voltage	120 Volts
Power Source	Corded Electric
Indoor/Outdoor Usage	Indoor
Mounting Type	Protruding (Ceiling)
Adjustable Height	Yes
Dimmable	Yes (with compatible dimmer and bulb)

Item Weight	3 Pounds
Manufacturer Warranty	1 year

9. WARRANTY INFORMATION

This EGLO Tabanera Mini Pendant Light (Model 96801A) is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, accident, misuse, abuse, or unauthorized modifications.

Please retain your proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

For further assistance, technical support, or warranty inquiries, please contact EGLO customer service. Refer to the EGLO official website or your purchase documentation for specific contact details.

When contacting support, please have your product model number (96801A) and proof of purchase readily available.