

[Manuals.plus](#) /

> [LuvLap](#) /

> LuvLap 4-in-1 Convertible Baby High Chair Instruction Manual (Model 18448)

LuvLap 18448

LuvLap 4-in-1 Convertible Baby High Chair Instruction Manual (Model 18448)

Comprehensive guide for assembly, operation, and maintenance of your LuvLap Convertible High Chair.

INTRODUCTION

The LuvLap 4-in-1 Convertible Baby High Chair is designed to provide a safe and comfortable feeding solution for your child from 6 to 36 months, supporting up to 20 kg. This versatile chair adapts to your child's growth, converting into a high chair, low chair, booster seat on a chair, and a low seating booster on the floor. It is certified as per European Standard EN 71, ensuring quality and safety.

COMPONENTS OVERVIEW

Before assembly, ensure all components are present. Refer to the installation video for a visual guide.

Your browser does not support the video tag.

Video: Product Installation Guide. This video demonstrates the unboxing and assembly of the LuvLap 4-in-1 Convertible Baby High Chair, showing each component and step-by-step installation.

- Seat unit with 3-point safety harness
- Food tray and removable food tray cover
- Footrest
- 8 Metal legs (4 short, 4 long)
- Rubberized grips for legs
- User Manual (this document)

SETUP AND ASSEMBLY

Follow these steps to assemble your LuvLap 4-in-1 Convertible Baby High Chair. Refer to the installation video in the "Components Overview" section for visual assistance.

1. Assembling the Low Chair / Booster Seat Base

1. **Install Short Legs:** Turn the seat unit upside down. Insert the four short metal legs into the designated slots on the underside of the seat. Ensure they click securely into place.

2. **Attach Rubberized Grips:** Place the rubberized grips onto the ends of the short legs to prevent slipping and protect surfaces.



Image: The LuvLap 4-in-1 Convertible Baby High Chair shown in its high chair, low chair, booster seat on floor, and booster seat on chair configurations.

2. Assembling the High Chair

3. **Connect Long Legs:** For the high chair configuration, connect the long metal legs to the short legs. Ensure the slots align and the connection is firm.
4. **Install Footrest:** Attach the footrest to the lower section of the long legs. Secure it by tightening the provided screws.
5. **Attach Food Tray:** Align the food tray with the slots on the armrests of the seat unit. Slide the tray into one of the three adjustable positions until it clicks securely.
6. **Place Tray Cover:** Position the removable food tray cover onto the food tray.



Image: A child seated in the LuvLap High Chair, illustrating the comfortable seating position and overall dimensions (88cm height, 56cm width).

OPERATING INSTRUCTIONS

The LuvLap 4-in-1 Convertible Baby High Chair offers multiple modes to suit your child's needs. Watch the product features video for a demonstration of its versatility.

Your browser does not support the video tag.

Video: Product Features Overview. This video highlights the key features and convertible modes of the LuvLap 4-in-1 Convertible Baby High Chair, including the safety harness, adjustable tray, and various configurations.

1. High Chair Mode

Use this mode for feeding at standard table height. Ensure the long legs and footrest are securely attached as described in the setup section.

- **Safety Harness:** Always secure your child with the 3-point safety harness. Adjust the straps for a snug fit.
- **Adjustable Tray:** The food tray has 3 positions. Press the release buttons on the sides of the tray and slide it forward or backward to adjust the distance from your child.



Image: A detailed view of the 3-point safety harness and the leg rest, emphasizing safety features for the child.

2. Low Chair Mode

To convert to a low chair, detach the long leg extensions from the short legs. The seat unit with short legs provides a stable, low-height chair suitable for toddlers.

3. Booster Seat on Chair Mode

The seat unit (with or without short legs) can be securely attached to an adult dining chair using the integrated straps. Ensure the straps are tightly fastened around the backrest and under the seat of the adult chair.

4. Low Seating on Floor Mode

Use the seat unit with short legs directly on the floor for independent play or feeding. Always ensure a stable, flat surface.

Versatile & Convenient

4-in-1 Convertible Modes



Image: This visual demonstrates the four versatile modes of the LuvLap high chair: High Chair, Booster Seat (on adult chair), Short Chair (low chair), and Play Chair (booster seat on floor).

MAINTENANCE AND CLEANING

- **Food Tray:** The removable food tray and its cover are washable. Detach them from the armrests for easy cleaning. They are dishwasher-safe for convenience.
- **Seat Pad:** The cushioned seat pad is removable for cleaning. Wipe with a damp cloth and mild soap, then air dry.
- **Chair Frame:** Wipe down the plastic and metal components of the chair frame with a damp cloth and mild soap. Do not use abrasive cleaners.
- **Storage:** For compact storage or travel, the chair can be easily disassembled. The legs can be removed, and the food tray detached.



Image: The removable food tray is shown being detached from the high chair, highlighting its easy-to-clean design for better hygiene.

Safety Information

- Always use the 3-point safety harness to secure your child in the chair.
- Ensure all legs and components are securely attached before placing your child in the chair.
- Never leave your child unattended in the high chair or booster seat.
- Do not use the product if any parts are damaged or missing.
- Keep the chair on a stable, flat surface.
- The maximum weight recommendation for this chair is 20 kg.
- Recommended for children aged 6 to 36 months.

Specifications

Feature	Detail
Model Number	18448
Brand	LuvLap
Convertible Modes	4-in-1 (High Chair, Low Chair, Booster Seat on Chair, Low Seating on Floor)
Recommended Age	6 to 36 months
Maximum Weight	20 Kilograms
Material	Metal (legs), Plastic (seat, tray)

Product Dimensions	45.6 x 45.6 x 25.8 cm (assembled dimensions vary by mode)
Item Weight	3.42 kg
Safety Features	3-point safety harness, non-slip base, European Standard EN 71 certified
Tray Features	Removable, 3-position adjustable, washable, includes removable cover
Portability	Compact foldable design for easy carry and storage
Included Components	High Chair (main unit), Footrest

TROUBLESHOOTING

If you encounter any issues with your LuvLap 4-in-1 Convertible Baby High Chair, please review the assembly instructions and ensure all parts are correctly installed. For further assistance, contact LuvLap customer support.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your product packaging or visit the official LuvLap website. Keep your purchase receipt for warranty claims.

© 2025 LuvLap. All rights reserved. Model 18448.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B079S9JX3S>

More documents and user manuals: <https://manuals.plus/>