

[Manuals.plus](#) /

› [Accessory USA](#) /

› Accessory USA AC/DC Adapter for RadioShack 21-1846 Instruction Manual

Accessory USA KTAUB-180213063

Accessory USA AC/DC Adapter for RadioShack Cat.No. 21-1846

Model: KTAUB-180213063

Brand: Accessory USA

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your Accessory USA AC/DC Adapter. This adapter is designed to provide reliable power to compatible devices, specifically RadioShack models Cat.No. 21-1846 and 211846. Please read this manual thoroughly before use.

Important: Before connecting, verify that your device's power requirements match the specifications of this adapter, particularly for RadioShack Cat.No. 21-1846 or 211846.

SAFETY INFORMATION

Your Accessory USA AC/DC Adapter is designed with multiple safety features to protect your devices and ensure safe operation.

- **Certifications:** This product is CE, FCC, and RoHS certified, meeting international safety and environmental standards.
- **Protection Features:**
 - OVP (Over Voltage Output Protection): Safeguards against excessive output voltage.
 - OCP (Over Current Output Protection): Prevents damage from overcurrent conditions.
 - SCP (Short Circuit Output Protection): Protects against short circuits.

Warnings:

- Do not expose the adapter to water or excessive moisture.
- Do not disassemble or attempt to repair the adapter.
- Use only with compatible devices as specified.
- Ensure proper ventilation; do not cover the adapter during use.
- Keep out of reach of children.

SETUP

1. **Verify Compatibility:** Confirm that your device is a RadioShack Cat.No. 21-1846 or 211846 and that its power input requirements match the adapter's output.
2. **Connect to Device:** Insert the barrel connector of the adapter firmly into the power input port of your RadioShack device.
3. **Connect to Power Outlet:** Plug the 2-pin main power connector into a standard wall outlet (100-240V AC).
4. **Power On:** Once connected, your device should receive power.



Image Description: A visual representation of the Accessory USA AC/DC Adapter, showing its barrel connector and 2-pin plug, ready for connection to a compatible device and a wall outlet.

OPERATING INSTRUCTIONS

This AC/DC adapter operates automatically once connected to a power source and a compatible device. No additional user interaction is required for its basic function.

- Ensure the adapter is securely plugged into both the wall outlet and your device.
- Disconnect the adapter from the wall outlet when not in use for extended periods.

MAINTENANCE

The Accessory USA AC/DC Adapter requires minimal maintenance.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a dry, soft cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly winding the cord to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cord for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

TROUBLESHOOTING

If you experience issues with your adapter, refer to the following common solutions:

- **Device not powering on:**
 - Ensure the adapter is fully plugged into both the wall outlet and the device.
 - Check if the wall outlet is functional by plugging in another device.
 - Verify that your device is indeed compatible with this adapter (RadioShack Cat.No. 21-1846 or 211846).
 - Inspect the adapter cord and connectors for any visible damage.

- **Adapter feels warm:**
 - It is normal for the adapter to feel slightly warm during operation. If it becomes excessively hot or emits a burning smell, disconnect it immediately and cease use.

SPECIFICATIONS

Feature	Detail
Brand	Accessory USA
Model Number	KTAUB-180213063
Compatible Devices	RadioShack Cat.No. 21-1846, 211846
Input Voltage	100-240 Volts AC
Connector Type	Barrel Connector
Main Power Connector Type	2 Pin
Safety Certifications	CE, FCC, RoHS
Protection Features	OVP, OCP, SCP
Special Feature	Travel
Mounting Type	Wall Mount

WARRANTY AND SUPPORT

Accessory USA stands behind the quality of its products.

- **Money Back Guarantee:** 30 Days
- **Free Exchange:** 60 Days (with paid return label)
- **Worry-Free Warranty:** 365 Days

For warranty claims or technical support, please contact Accessory USA customer service through the retailer where the product was purchased. Please have your model number (KTAUB-180213063) and purchase details ready.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question