

Lorus RM329EX9

Lorus RM329EX9 Chronograph Watch Instruction Manual

Model: RM329EX9

1. INTRODUCTION

This manual provides detailed instructions for the proper use and care of your Lorus RM329EX9 Sports Quartz Chronograph Watch. This timepiece features a precise quartz movement, chronograph functionality, a tachymeter scale, and is water resistant to 100 meters. Please read this manual thoroughly to ensure optimal performance and longevity of your watch.



Image of the Lorus RM329EX9 chronograph watch, featuring a blue dial with a checkered pattern, three sub-dials, a date window, and a silver-tone stainless steel bracelet. The bezel includes a tachymeter scale.

2. SETUP AND INITIAL ADJUSTMENT

Before using your watch, it is important to set the time and date correctly. Familiarize yourself with the crown and pushers.

2.1 Setting the Time

1. Pull the crown out to the second click position (position 3).
2. Turn the crown to move the hour and minute hands to the desired time. Consider AM/PM when setting the time if your watch has a date function that changes at midnight.
3. Push the crown back in to the normal position (position 1).

2.2 Setting the Date

1. Pull the crown out to the first click position (position 2).
2. Turn the crown to set the date. Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the date change mechanism.
3. Push the crown back in to the normal position (position 1).

2.3 Chronograph Hand Zero Position Adjustment

If the chronograph hands (1/10 second, second, or minute) do not return to the zero position after resetting, they may need adjustment.

1. Pull the crown out to the second click position (position 3).
2. Press pusher A (top pusher) to advance the 1/10 second chronograph hand. Press pusher B (bottom pusher) to advance the chronograph second hand. Pressing and holding the pushers will move the hands continuously.
3. Once all chronograph hands are aligned to the zero position, push the crown back in to the normal position (position 1).

3. OPERATING THE CHRONOGRAPH AND TACHYMETER

3.1 Using the Chronograph

The chronograph measures elapsed time up to 60 minutes in 1/10 second increments.

1. **Start:** Press pusher A to start the chronograph measurement. The chronograph second hand, 1/10 second hand, and minute hand will begin moving.
2. **Stop:** Press pusher A again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping, press pusher B to reset all chronograph hands to the zero position.
4. **Split Time (if applicable):** This model supports standard start/stop/reset. For split time functionality, refer to specific model variations if available.

3.2 Using the Tachymeter

The tachymeter scale on the bezel can be used to measure speed over a known distance (e.g., 1 kilometer or 1 mile) or to measure production rates.

1. Start the chronograph at the beginning of the measured distance (e.g., start of a kilometer).
2. Stop the chronograph when the distance is completed.
3. The number on the tachymeter scale indicated by the chronograph second hand shows the average speed per hour (e.g., if the second hand points to '120', the speed is 120 units per hour).

4. MAINTENANCE AND CARE

4.1 Water Resistance

Your Lorus RM329EX9 watch is water resistant to 100 meters (10 BAR). This means it is suitable for swimming and snorkeling. However, it is crucial to:

- **Never operate the crown or pushers when the watch is wet or submerged in water.**This can compromise the water resistance.
- Ensure the crown is fully pushed in before any contact with water.
- Avoid exposing the watch to hot water, steam, or sudden temperature changes, which can affect seals.

4.2 Cleaning

To maintain the appearance of your watch:

- Wipe the case and bracelet periodically with a soft, dry cloth.
- For stainless steel bracelets, a soft brush with mild soapy water can be used, followed by thorough rinsing and drying.
- Avoid using harsh chemicals or abrasive materials.

4.3 Battery Replacement

The watch is powered by one LR44 battery. When the battery is depleted, it should be replaced by a qualified watch technician to ensure proper sealing and function. Do not attempt to replace the battery yourself.

5. TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Chronograph hands not resetting to zero:** Perform the chronograph hand zero position adjustment as described in Section 2.3.
- **Date not changing:** Ensure the time is set correctly, considering AM/PM. Avoid setting the date during the restricted hours (9 PM - 3 AM).

For issues not resolved by these steps, please contact an authorized Lorus service center.

6. SPECIFICATIONS

Feature	Detail
Model Number	RM329EX9
Brand	Lorus
Display Type	Analog
Movement	Quartz
Water Resistance	100 meters (10 BAR)

Case Material	Stainless Steel
Band Material	Stainless Steel
Dial Case Diameter	L (40 - 48 mm)
Product Dimensions	1 x 1 x 1 cm
Item Weight	149 g
Battery Type	1 LR44 (included)



7. WARRANTY AND SUPPORT

Warranty information for your Lorus RM329EX9 watch is typically provided with your purchase documentation. Please refer to these documents for details regarding coverage, duration, and terms.

For further assistance, service, or to locate an authorized service center, please visit the official Lorus website or contact their customer support directly. Keep your proof of purchase for any warranty claims.

© 2023 Lorus. All rights reserved.

Related Documents - RM329EX9

 <p>The image shows the cover of the Lorus VJ22 Analogue Quartz Watch Instruction Manual. It features the Lorus logo at the top, followed by the text 'A Watch You Can Trust' and 'INSTRUCTION MANUAL FOR WATCH CALIBRE VJ22'. Below this is a yellow warning box with a triangle icon and the text 'WARNING' and 'THIS PRODUCT CONTAINS A BUTTON BATTERY'. The warning text states: 'If swallowed or placed inside any part of the body, the battery can cause severe or fatal injury. If swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian Poisons Information Centre immediately on 13 11 26. (New Zealand 0800 136 363 for 24/7 help, expert advice)'</p>	<p>Lorus VJ22 Analogue Quartz Watch Instruction Manual</p> <p>Official instruction manual for the Lorus VJ22 analogue quartz watch. Learn how to set the time, day, and date, understand Lumibrite features, battery care, water resistance, and adjust the band length.</p>
 <p>The image shows the cover of the Lorus VX51 Watch Instruction Manual. It features the Lorus logo at the top, followed by the text 'A Watch You Can Trust' and 'INSTRUCTION MANUAL FOR WATCH CALIBRE VX51'. Below this is a yellow warning box with a triangle icon and the text 'WARNING' and 'THIS PRODUCT CONTAINS A BUTTON BATTERY'. The warning text states: 'If swallowed or placed inside any part of the body, the battery can cause severe or fatal injury. If swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian Poisons Information Centre immediately on 13 11 26. (New Zealand 0800 136 363 for 24/7 help, expert advice)'</p>	<p>Lorus VX51 Watch Instruction Manual - Operation, Care, and Features</p> <p>This instruction manual provides detailed guidance for operating and maintaining your Lorus VX51 analogue quartz watch. It covers setting the time and date, understanding Lumibrite technology, battery replacement, water resistance guidelines, and general care instructions.</p>



INSTRUCTION MANUAL FOR
WATCH CALIBRE
V782



THIS PRODUCT CONTAINS A BUTTON BATTERY.
If swallowed or placed inside any part of the body, the battery can cause serious or long-term injury within 24 hours or less. Button batteries are hazardous whether new or used. Keep batteries out of reach of children.
If you think the battery may have been swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian Poisons Information Centre immediately on 01 91 26 (New Zealand 0800 764 866 for 24/7 help, in-patient advice).

[Lorus Watch Calibre V782 Instruction Manual - Setup, Care, and Operation Guide](#)

Comprehensive instruction manual for the Lorus Watch Calibre V782. Learn how to set the time and date, understand Lumibrite features, battery safety, water resistance ratings, and how to adjust the band length. Essential guide for Lorus watch owners.



INSTRUCTION MANUAL FOR
WATCH CALIBRE
PC33



THIS PRODUCT CONTAINS A BUTTON BATTERY.
If swallowed or placed inside any part of the body, the battery can cause severe or long-lasting effects within 2 hours or less.
Button batteries are hazardous to health if not used. Keep batteries out of reach of children.
If you think the battery may have been swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian Poisons Information Centre immediately on 13 11 26.
Poisons Information Centre: 0800 006 006, 0800 006 006, or visit www.poc.org.au

Lorus PC33 Watch Instruction Manual: Setting Time, Date, and Care Guide

Detailed instruction manual for the Lorus PC33 analogue quartz watch. Learn how to set time and date, understand Lumibrite features, water resistance, and proper care.



INSTRUCTION MANUAL FOR
WATCH CALIBRE
7N32



THIS PRODUCT CONTAINS A BUTTON BATTERY.
If swallowed or placed inside any part of the body, the battery can cause serious or irreversible damage within hours or less.
Batteries become more hazardous whether new or used. Keep batteries out of reach of children.
If you think the battery may have been swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian Poisons Information Centre immediately on 13 11 26.

Lorus Calibre 7N32 Watch Instruction Manual

This instruction manual provides detailed guidance for operating and maintaining the Lorus Calibre 7N32 analogue quartz watch. It covers setting the time and date, features like Lumibrite, water resistance information, battery care, and band adjustment.



INSTRUCTION MANUAL FOR
WATCH CALIBRE
1N00



THIS PRODUCT CONTAINS A BUTTON BATTERY.
If swallowed or placed inside any part of the body, the battery can cause serious or lasting damage within 2 hours or less.
Button batteries are hazardous whether new or used. Keep batteries out of reach of children.
If you think the battery may have been swallowed or placed inside any part of the body, seek immediate medical attention. Contact the Australian Poisons Information Centre immediately on 13 11 26.

Lorus 1N00 Watch Instruction Manual: Operation, Care, and Features

Comprehensive instruction manual for the Lorus 1N00 watch calibre. Learn how to set time, date, day, understand LUMIBRITE features, water resistance, battery care, and band adjustment.