

VIVO DESK-V133E

VIVO DESK-V133E Electric Motor Sit-Stand Height Adjustable Corner 3-Leg Desk Frame User Manual

Model: DESK-V133E

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before use. Failure to follow these instructions may result in injury or damage to the product.

- Always follow the assembly instructions carefully.
- Use caution when adjusting the desk height to prevent injury.
- Ensure the desk is properly anchored to the floor to prevent tipping.
- Do not exceed the maximum weight recommendation of **330 pounds (149.6 kg)** to maintain stability and safety.
- This product requires assembly. It is recommended that **two people** assemble the desk.

2. PRODUCT OVERVIEW

The VIVO DESK-V133E is an electric motor sit-stand height adjustable corner desk frame designed to transform your workspace into an ergonomic L-shaped workstation. This frame allows for smooth transitions between sitting and standing positions, promoting a healthier work environment.



Figure 2.1: Assembled VIVO DESK-V133E frame with a desktop, monitors, and accessories.

Key Features:

- **Electric Height Adjustment:** Telescopic height range from 24.4" to 50.4" (62 cm to 128 cm).
- **Multi-Motor Lift System:** Provides smooth, quiet transitions at 1.5" (3.8 cm) per second lift speed.
- **Sturdy 3-Leg System:** All-steel construction supports up to 330 lbs (149.6 kg).
- **Touch Screen Control Panel:** Features 3 customizable memory settings and programmable alarms.
- **Cable Management:** Includes a cable management rack to keep cords organized.

POWERFUL LIFT SYSTEM

quiet and smooth motor for simple height adjustment



HEIGHT RANGE
24.4" to 50.4"



MULTI MOTOR LIFT
Power Input: 100 - 240V
Lift Speed: 1.5" per second



WEIGHT CAPACITY
330lbs

Figure 2.2: Visual representation of the desk's height range (24.4" to 50.4") and 330 lbs weight capacity.

3. SETUP AND ASSEMBLY

This section provides guidance for assembling your VIVO DESK-V133E desk frame. A desktop must be purchased separately.


Recommended Tabletop Sizes:

- **Main Desk (24" Width):** 46.1" to 89.7" Length
- **Main Desk (30" Width):** 49.1" to 92.7" Length
- **Return Desk (24" Width):** 23" to 59" Length
- **Return Desk (30" Width):** 20" to 56" Length
- Recommended desktop thickness: 3/4" (1.9 cm) or greater.

The desk frame is designed to be assembled with the main and return frames in a fixed L-shape configuration. They are not reversible.

ADJUSTABLE FRAME

Minimum Desktop Dimensions



Maximum Desktop Dimensions




Figure 3.1: Minimum and maximum desktop dimensions for the VIVO DESK-V133E frame.

ALL STEEL CONSTRUCTION

RETURN LENGTH
extends 46.3" to 71.1"



Figure 3.2: All-steel construction of the desk frame, highlighting adjustable main and return lengths.

ATTENTION!

this desk purchase will arrive in two boxes

Please NOTE these may arrive 1 or 2 days apart!



BOX 1



BOX 2

Figure 3.3: The desk frame ships in two separate boxes, which may arrive on different days.

Assembly Video:


Your browser does not support the video tag.

Video 3.1: Official VIVO assembly video for the DESK-V133E. This video provides a visual guide to the assembly process.

For detailed step-by-step instructions, refer to the included user guide. Pay close attention to screw lengths to avoid damaging your desktop. It is recommended to plan cable management before installing the desktop.

4. OPERATING INSTRUCTIONS

The VIVO DESK-V133E features an intuitive touch screen control panel for easy height adjustment and personalized settings.



TIMER REMINDER

set a timer to remind yourself to stand throughout your day

PROGRAMMABLE SETTINGS

3 memory presets to easily find your ideal height

POWER SAVING MODE

indicated by: "---" and activates after 60 seconds of inactivity...to use panel again, press anywhere

SMART CONTROL PANEL

Figure 4.1: Smart touch screen control panel for the desk frame.

Control Panel Functions:

- **Height Adjustment:** Use the up and down arrow buttons to manually adjust the desk height.
- **Memory Settings (1, 2, 3):**
 1. Adjust the desk to your desired height.
 2. Press the "M" button.
 3. Press the desired memory button (1, 2, or 3) to save the height.
 4. To recall a saved height, simply press the corresponding memory button.
- **Timer Reminder (T):** Set a timer to remind yourself to switch between sitting and standing positions.
- **Power Saving Mode:** Indicated by "---" on the display. Activates after 60 seconds of inactivity. Press any button to wake the panel.

Operation Videos:

Your browser does not support the video tag.

Video 4.1: Official VIVO video demonstrating the touch control pad features and operation.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your desk frame.

- **Cleaning:** Wipe down the desk frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Cable Management:** Periodically check and organize cables to prevent tangles and ensure smooth operation during height adjustments.
- **Fasteners:** Ensure all screws and fasteners remain tight. Re-tighten if necessary to maintain stability.
- **Weight Distribution:** Distribute weight evenly across the desktop to prevent strain on the motors and frame.

6. TROUBLESHOOTING

If you encounter issues with your desk frame, refer to the following common troubleshooting steps.

Common Issues and Solutions:

- **Desk Not Adjusting / Error Code (e.g., E06):**
 - Check all cable connections to ensure they are secure.
 - Ensure no obstacles are blocking the desk's movement path.
 - Perform a reset procedure: Unplug the desk from the power outlet for 10-15 seconds, then plug it back in. Follow any specific reset instructions in the full manual if available.
 - If an error code persists, contact customer support.
- **Desk Wobbles at Standing Height:**
 - Ensure all assembly screws are securely tightened.
 - Verify the desktop is properly affixed to the frame.
 - Check that the floor is level and adjust the desk's leveling feet if necessary.
- **Noise During Operation:**
 - A slight motor sound is normal during adjustment.
 - If the noise is excessive or unusual, check for any obstructions or loose components.

7. SPECIFICATIONS

Feature	Detail
Brand	VIVO
Model Number	DESK-V133E
Shape	L-Shape
Minimum Height	24.4 inches (62 cm)
Maximum Height	50.4 inches (128 cm)
Maximum Weight Recommendation	330 pounds (149.6 kg)

Base Material	Alloy Steel
Lifting Mechanism	Electric Multi-Motor
Lift Speed	1.5 inches (3.8 cm) per second
Color	Black
Item Weight	61.1 pounds (27.7 kg)
Recommended Assembly	2 people