

Ingenuity 10845-3

Ingenuity Comfort 2 Go Compact Portable Baby Swing User Manual

Model: 10845-3 | Brand: Ingenuity

INTRODUCTION

This manual provides essential information for the safe and effective use of your Ingenuity Comfort 2 Go Compact Portable 6-Speed Cushioned Baby Swing. Designed for portability and comfort, this swing offers automatic swinging motions, soothing melodies, and engaging toys for infants aged 0-9 months, weighing between 6-20 lbs. Please read all instructions carefully before assembly and use.

KEY FEATURES

- Compact and portable design for easy transport and storage.
- Six-speed automatic swinging motion.
- Integrated music player with soothing melodies.
- Plush hanging toys for entertainment.
- Ultra-soft cushioned seat pad with removable head support.
- 5-point harness and non-slip feet for enhanced safety.
- Weight-sensing technology to maintain consistent swing speed.
- Machine washable seat pad and headrest for convenient cleaning.

SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the detailed instructions provided in the included user manual PDF for proper setup. Ensure all components are securely fastened before placing an infant in the swing.

For visual guidance on the product's compact nature and ease of storage, refer to the image below:



Image: The Ingenuity Comfort 2 Go Baby Swing shown in a folded position, highlighting its compact design for easy storage and portability.

OPERATING INSTRUCTIONS

The Ingenuity Comfort 2 Go swing features intuitive controls for swing speed, music, and timer settings. Power is supplied by 4 C batteries (not included).

- **Power On/Off:** Press the power button located on the control panel to turn the swing on or off.
- **Swing Speed Adjustment:** Use the speed control buttons to select one of the six available swing speeds. The weight-sensing technology will help maintain a consistent speed.
- **Music Playback:** Activate the music feature using the dedicated music button. Adjust the volume as desired.
- **Timer Function:** Set a timer for automatic shut-off if desired. Refer to the full user manual for specific timer intervals.
- **Harness System:** Always secure your infant using the 5-point harness system. Ensure the harness is snug but comfortable.



Image: An infant comfortably seated and secured in the Ingenuity Comfort 2 Go Baby Swing, demonstrating the secure harness system and plush seating.



Image: A side view of the Ingenuity Comfort 2 Go Baby Swing, illustrating its recline feature for enhanced infant comfort.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and safety of your baby swing.

- **Seat Pad & Headrest:** Remove from frame. Fasten buckles on seat restraint and seat pad. Fasten all hook-and-loop patches to the corresponding patch. Machine wash with cold water, gentle cycle. Do not use bleach. Tumble dry on low heat.
- **Frame & Components:** Wipe clean with a damp cloth and mild soap. Air dry. Do not immerse the frame or electronic components in water.
- **Battery Replacement:** Replace 4 C batteries as needed. Ensure correct polarity when inserting new batteries.

SPECIFICATIONS

Brand	Ingenuity
Model Number	10845-3
Product Dimensions	22.5"D x 28.5"W x 23"H

Weight Range	6-20 lbs (3-9 kg)
Maximum Age	9 months
Frame Material	Metal
Fabric Type	56% Metal, 34% Plastic, 10% Fabric
Batteries Required	4 C batteries



Image: A visual representation of the Ingenuity Comfort 2 Go Baby Swing's dimensions (22.64 in W, 26.77 in H, 28.74 in D) and recommended usage limits (6-20 lbs / 3-9 kg, Max Age: 9 mos).

TROUBLESHOOTING

If you encounter issues with your Ingenuity Comfort 2 Go Baby Swing, consider the following common solutions:

- **Swing Not Operating:** Check that 4 C batteries are correctly installed and not depleted. Ensure the power button is pressed.

- **Swing Speed Inconsistent:** Verify that the swing is on a flat, stable surface. The weight-sensing technology adjusts for the baby's weight, but extreme unevenness can affect performance.
- **Music Not Playing/Low Volume:** Check battery levels. Adjust volume settings on the control panel.
- **Squeaking Noises:** Ensure all assembly points are secure. Lubrication may be required on moving parts if squeaking persists after checking connections.
- **Folding Difficulty:** Ensure the seat is in the correct position for folding. Refer to the assembly instructions for the proper folding mechanism.







For further assistance, please consult the full user manual or contact customer support.




WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official user manual or visit the Ingenuity website. The manufacturer is Kids2, Inc.
You can download the complete User Manual (PDF)[here](#).

© 2025 Ingenuity. All rights reserved.

Related Documents - 10845-3

<div><div>10845-3</div><div>Comfort 2 Go Portable Swing™ - Fanciful Forest™ Portable Swing - Cakupan Portable - Bercakap Forest Ingenuity Comfort 2 Go Portable Swing - Fanciful Forest Ingenuity.com</div></div>	<p>Ingenuity Comfort 2 Go Portable Swing - Fanciful Forest User Manual</p> <p>Comprehensive guide for the Ingenuity Comfort 2 Go Portable Swing in Fanciful Forest design, covering safety warnings, assembly instructions, battery information, care and cleaning, and operational details.</p>
<div><div>11149-MEES</div><div>SimpleComfort Compact Soothing Swing™ - Everston™ Swing - Mendorong - Bercakap - Schauder - Mendorong - Mendorong Ingenuity.com</div></div>	<p>Ingenuity SimpleComfort Compact Soothing Swing - Everston User Manual</p> <p>User manual and instructions for the Ingenuity SimpleComfort Compact Soothing Swing - Everston model (11149-MEES). Includes safety warnings, assembly, battery information, care, and usage details for this baby swing by Ingenuity (Kids2).</p>
<div><div>13230-MEES</div><div>By Ingenuity™ Swingity Swing™ - Easy-Fold Portable Swing - Goji™ Portable Swing - Cakupan Portable - Bercakap Portable Trangkasan Schauder - Bercakap Portable - Mendorong Portable Ingenuity.com</div></div>	<p>Ingenuity Swingity Swing Easy-Fold Portable Swing - Goji User Manual</p> <p>User manual and safety guide for the Ingenuity Swingity Swing Easy-Fold Portable Swing in the Goji pattern. Includes assembly, usage, care, and battery information.</p>

<div><p>SimpleComfort™ Compact Soothing Swing - Chambray</p><p>Swing • Woodstock • Black/White</p><p>ingenuitybaby.com</p></div> <div>10001 / 17194 / 17195-000</div>	<p>Ingenuity SimpleComfort Compact Soothing Swing - Chambray User Manual</p> <p>This manual provides instructions for the Ingenuity SimpleComfort Compact Soothing Swing in Chambray. It includes safety warnings, assembly instructions, care and cleaning guidelines, and usage information for the swing's features.</p>
<div><p>SimpleComfort™ Compact Soothing Swing - Parker™</p><p>Swing • Woodstock • Black/White</p><p>ingenuitybaby.com</p></div> <div>10001-001</div>	<p>Ingenuity SimpleComfort Compact Soothing Swing - Parker User Manual</p> <p>This user manual provides instructions for the Ingenuity SimpleComfort Compact Soothing Swing - Parker. It includes safety warnings, assembly instructions, care and cleaning guidelines, and information on the swing's features.</p>
<div><p>SimpleComfort Compact Soothing Swing & Rocker™ - Raylan™</p><p>Swing • Woodstock • Black/White • Wicker • Rocker • Rocker • Rocker</p><p>ingenuitybaby.com</p></div> <div>17195-000</div>	<p>Ingenuity SimpleComfort Compact Soothing Swing & Rocker - Raylan User Manual</p> <p>This user manual provides essential safety information, assembly instructions, battery guidelines, and care tips for the Ingenuity SimpleComfort Compact Soothing Swing & Rocker™ in the Raylan™ design.</p>