

Acer E5-576-392H

Acer Aspire E 15 E5-576-392H Laptop Instruction Manual

Model: E5-576-392H | Brand: Acer

1. PRODUCT OVERVIEW

The Acer Aspire E 15 E5-576-392H is a versatile laptop designed for everyday computing tasks. It features an 8th Generation Intel Core i3-8130U Processor, a 15.6-inch Full HD (1920 x 1080) widescreen LED-backlit display, and runs on Windows 10 Home. This model includes 6GB Dual Channel Memory, a 1TB 5400RPM SATA Hard Drive, and an 8x DVD Double-Layer Drive RW (M-DISC enabled). Connectivity options include 802.11AC Wi-Fi with MU-MIMO technology, Bluetooth 4.1, and various USB and HDMI ports. The laptop is equipped with an HD Webcam (1280 x 720) supporting High Dynamic Range (HDR) and Acer True Harmony audio with two built-in stereo speakers.

Key Features:

- 8th Generation Intel Core i3-8130U Processor (Up to 3.4GHz)
- 15.6" Full HD (1920 x 1080) Widescreen LED-lit Display
- 6GB Dual Channel Memory, 1TB HDD & 8x DVD
- Up to 13.5-Hours of battery life
- Windows 10 Home Operating System

2. WHAT'S IN THE Box

- Acer Aspire E 15 E5-576-392H Laptop
- Power Adapter
- Power Cord

3. SETUP

3.1 Initial Power-On

1. Unpack the laptop and all accessories from the box.
2. Connect the power adapter to the laptop's power port and plug it into a power outlet.
3. Open the laptop lid and press the power button, usually located on the top-right of the keyboard or on the side.
4. Follow the on-screen instructions to complete the initial Windows 10 Home setup, including language selection, network connection, and user account creation.

3.2 Connecting to Wi-Fi

1. During initial setup, you will be prompted to connect to a Wi-Fi network. Select your network from the list and enter the password.
2. If setting up later, click the Wi-Fi icon in the taskbar, select your network, and connect.

4. OPERATING INSTRUCTIONS

4.1 Basic Usage

The Acer Aspire E 15 features a full-size keyboard with a numeric keypad and a responsive touchpad for navigation. Use the touchpad for cursor control, single-finger tap for left-click, and two-finger tap for right-click. Multi-touch gestures are also supported for scrolling and zooming.

4.2 Ports and Connectivity

The laptop offers a variety of ports for connecting external devices:

- 1 x USB 3.1 Type C Gen 1 port (up to 5 Gbps)
- 2 x USB 3.0 ports (one with power-off charging)
- 1 x USB 2.0 port
- 1 x HDMI Port with HDCP support
- Secure Digital (SD) card reader
- Ethernet (RJ-45) port
- Headphone/microphone combo jack



Image: Side view of the Acer Aspire E 15 laptop, highlighting the various connectivity ports including USB, HDMI, and audio jack. This image illustrates the physical layout of the ports for easy identification.

4.3 Display and Audio

The 15.6-inch Full HD display provides clear visuals for work and entertainment. Acer True Harmony and built-in stereo speakers deliver enhanced audio quality. The HD Webcam supports High Dynamic Range (HDR) for improved video call quality.



Image: The Acer Aspire E 15 laptop open, displaying a vibrant Full HD screen. A graphic indicating '1920x1080 Full HD Resolution' is visible, emphasizing the display's clarity and detail.

4.4 Battery Life

The 6-cell Li-ion battery provides up to 13.5 hours of battery life, allowing for extended use on a single charge.

5. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and exterior. Avoid harsh chemicals.
- **Software Updates:** Regularly check for and install Windows updates to ensure optimal performance and security.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Store the laptop in a cool, dry place.
- **Storage Management:** Periodically clean up unnecessary files and programs to maintain system performance.

6. TROUBLESHOOTING

- **Laptop not powering on:** Ensure the power adapter is securely connected and the battery has sufficient charge. Try a different power outlet.
- **Slow performance:** Close unnecessary applications, check for malware, and ensure sufficient free space on the hard drive.
- **Wi-Fi connectivity issues:** Restart your router and modem. Ensure Wi-Fi is enabled on the laptop and drivers are up to date.
- **Screen issues:** If the screen is blank or flickering, try restarting the laptop. Check display settings for proper resolution.

For further assistance, refer to the official Acer support website or contact customer service.

7. SPECIFICATIONS

Feature	Specification
Processor	8th Generation Intel Core i3-8130U (2.2GHz with Turbo Boost up to 3.4GHz)
Operating System	Windows 10 Home
Display	15.6" Full HD (1920 x 1080) Widescreen LED-backlit
Graphics	Intel UHD Graphics 620
RAM Memory	6GB Dual Channel Memory (DDR3 SDRAM)
Hard Drive	1TB 5400RPM SATA Hard Drive
Optical Drive	8x DVD Double-Layer Drive RW (M-DISC enabled)
Wireless Connectivity	802.11AC Wi-Fi featuring MU-MIMO technology (Dual-Band 2.4GHz and 5GHz), Bluetooth 4.1
Ports	1 x USB 3.1 Type C Gen 1, 2 x USB 3.0, 1 x USB 2.0, 1 x HDMI, SD Card Reader, Ethernet
Webcam	HD Webcam (1280 x 720) supporting HDR
Audio	Acer True Harmony, Two Built-in Stereo Speakers
Battery	6-cell Li-ion Battery (2800 mAh)
Battery Life	Up to 13.5 Hours
Weight	5.27 lbs (2.39 kg)
Dimensions (LxWxH)	15.02 x 10.2 x 1.19 inches

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official Acer support website. Keep your purchase receipt and product serial number handy for any warranty claims or service requests.