

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LG](#) /

› **LG 65SK8000 65-Inch 4K UHD Smart LED TV User Manual**

LG 65SK8000

LG 65SK8000 65-Inch 4K UHD Smart LED TV User Manual

PRODUCT OVERVIEW

This manual provides essential information for the setup, operation, and maintenance of your LG 65SK8000 65-Inch 4K UHD Smart LED TV. Please read thoroughly before use.

The LG 65SK8000 is a 65-inch 4K Ultra HD Smart LED TV designed to enhance your viewing experience. It features an Intelligent Processor that optimizes color, depth, and sharpness for a realistic picture. With Dolby Atmos support, it delivers theater-quality audio.

WHAT'S IN THE Box

Verify that all items are present before proceeding with setup:

- LG 65SK8000 65-Inch 4K UHD Smart LED TV
- Power Cable
- TV Stand (components for assembly)
- Remote Control
- 2 AA Batteries (for remote control)

SETUP

1. Unpacking and Placement

Carefully remove the TV from its packaging. It is recommended to have at least two people for safe handling due to the size and weight of the unit.




Figure 1: Product dimensions for placement planning. The TV measures approximately 12.5"D x 57.3"W x 36.1"H.

Choose a stable, flat surface or a suitable wall mount location. Ensure adequate ventilation around the TV.

2. Attaching the Stand (if not wall-mounting)

Follow the instructions provided with the stand components to securely attach the stand to the TV. Ensure all screws are tightened properly.

3. Connecting Peripherals

Connect your external devices (e.g., cable box, Blu-ray player, gaming console) to the appropriate ports on the back of the TV. The LG 65SK8000 features multiple HDMI and USB ports, along with Ethernet connectivity.



Figure 2: Rear view of the LG 65SK8000 TV, highlighting the various input ports for connecting external devices.



Figure 3: A closer look at the input ports on the LG 65SK8000, including HDMI, USB, and Ethernet connections.

4. Power Connection

Connect the power cable to the TV and then to a wall outlet. Insert the supplied AA batteries into the remote control.

5. Initial Power On and Setup Wizard

Press the power button on the remote control or the TV. The TV will guide you through an initial setup wizard to configure language, network settings, and channel scanning.

OPERATING INSTRUCTIONS

Picture Quality Features

- **High Dynamic Range (HDR10, HLG, Dolby Vision, Advanced HDR by Technicolor):** This feature extends picture contrast and brightness, providing a more vivid and detailed image when viewing HDR content from connected sources or built-in apps.
- **TruMotion 240 Blur Reduction (120Hz Refresh Rate):** Enhances motion clarity, reducing blur in fast-moving scenes for a smoother viewing experience.
- **IPS (In-Plane Switching) LCD Panel:** Provides wide viewing angles, ensuring consistent picture quality even when viewed from the side.
- **Expanded Color Range with Billion Rich Colors:** Utilizes an 8-bit panel with 10-bit dithering to display a broader spectrum of colors, resulting in richer and more accurate hues.
- **4K Upscaler:** Automatically upconverts standard-definition and high-definition video content to near-4K quality, improving clarity and detail for non-4K sources.

Audio Features

The LG 65SK8000 supports Dolby Atmos, delivering immersive, theater-quality audio. Adjust audio settings via the TV's on-screen menu to optimize your sound experience.

Smart TV Functionality

Access a variety of streaming services and apps directly from your TV. The intuitive interface allows for easy navigation. Connect to your home network via Wi-Fi or Ethernet to utilize smart features.

MAINTENANCE

Cleaning the Screen

Gently wipe the screen with a soft, dry microfiber cloth. For stubborn smudges, lightly dampen the cloth with water or a screen-specific cleaning solution (avoid harsh chemicals).

Cleaning the TV Body

Use a soft, dry cloth to clean the frame and back of the TV. Do not use abrasive cleaners or solvents.

Software Updates

Periodically check for and install software updates to ensure optimal performance and access to the latest features. This can usually be done through the TV's settings menu under "Support" or "Software Update."

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable disconnected; outlet issue	Ensure power cable is securely connected to TV and a working outlet. Test outlet with another device.
No picture, but sound is present	Incorrect input selected; faulty HDMI cable	Verify correct input source. Try a different HDMI cable or port.
No sound, but picture is present	Volume muted/low; external audio system issue	Check TV volume and mute status. If using external audio, ensure it's powered on and correctly configured.
Remote control not working	Dead batteries; obstruction; pairing issue	Replace batteries. Remove obstructions. Re-pair the remote if it's a smart remote (refer to TV's on-screen guide).
Smart features not working/slow	Network connectivity issues; outdated software	Check Wi-Fi connection or Ethernet cable. Restart router. Update TV software.

SPECIFICATIONS

Feature	Detail
Brand	LG
Model Number	65SK8000
Screen Size	65 Inches
Display Technology	LED
Resolution	4K (3840 x 2160)
Refresh Rate	120 Hz (TruMotion 240)
Special Feature	Flat, Smart TV, HDR (HDR10, HLG, Dolby Vision, Advanced HDR by Technicolor)
Connectivity Technology	Ethernet, HDMI, USB
Aspect Ratio	16:9

Feature	Detail
Product Dimensions (D x W x H)	12.5" x 57.3" x 36.1"
Item Weight	57.8 Pounds
Wattage	100 watts
Included Components	Power Cable, Remote Control, Stand

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official LG website or contact LG customer service directly. Keep your purchase receipt and product serial number handy for any inquiries. Online resources and FAQs are available on the [LG Support website](#).

© 2024 LG Electronics. All rights reserved. Information in this manual is subject to change without notice.