

Lisciani 66070

Lisciani Miraculous Ladybug Game of the Goose Board Game 66070 Instruction Manual

Model: 66070

1. PRODUCT OVERVIEW

The Lisciani Miraculous Ladybug Game of the Goose is a traditional board game set in the world of Ladybug and Chat Noir. This game offers two distinct play modes: a classic version and a variant that incorporates tokens, making it suitable for young players.

Included Components:

- Game Board
- 6 Character Pawns
- 12 Tokens
- 6 Card Stands
- Spinner with Soft-Dart
- Instruction Manual

Player Information:

- Number of Players: 2 to 6
- Recommended Age: 4 to 83 years



Image 1.1: The complete Lisciani Miraculous Ladybug Game of the Goose board game, showing the game path, character pawns, spinner, and various tokens.

2. SETUP

1. **Unpack Components:** Carefully remove all game components from the box. Verify that all listed items are present.
2. **Place Game Board:** Unfold the game board and place it on a flat, stable surface, ensuring the entire path is visible to all players.
3. **Choose Pawns:** Each player selects one character pawn and places it on the "Start" space of the game board.
4. **Prepare Spinner:** Ensure the soft-dart is securely attached to the spinner. The spinner will be used to determine movement.
5. **Tokens and Card Stands:** Place the 12 tokens and 6 card stands near the game board, accessible to all players. These will be used for the variant game mode.

3. OPERATING INSTRUCTIONS (HOW TO PLAY)

3.1. Classic Game Mode

1. **Starting the Game:** The youngest player typically starts the game. Play proceeds clockwise.
2. **Player's Turn:** On your turn, spin the spinner. The number indicated by the soft-dart determines how many spaces you move your pawn forward along the game path.
3. **Landing on Spaces:** Follow the instructions on the space where your pawn lands. These instructions may include:
 - Moving forward or backward a certain number of spaces.
 - Skipping a turn.
 - Moving to a specific space on the board (e.g., a "Goose" space, which often allows for an extra move).
 - Other special actions related to the Miraculous Ladybug theme.
4. **Winning the Game:** The first player to reach the "Finish" space (space 63) exactly wins the game. If you spin a number that would take you past the "Finish" space, you must move forward to the "Finish" space and then move backward the remaining number of spaces.

3.2. Token Variant Game Mode

This variant introduces the 12 tokens and 6 card stands for an enhanced gameplay experience. Specific rules for token usage and interaction with card stands will be detailed in the included printed instructions. Generally, tokens may grant special abilities, bonus moves, or require specific actions when landing on certain spaces.

4. MAINTENANCE

- **Cleaning:** To clean the game board and plastic components, gently wipe them with a dry, soft cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the printed surfaces.
- **Storage:** After playing, ensure all components are returned to the game box. Store the box in a cool, dry place away from direct sunlight and extreme temperatures to prevent warping or fading of the board and pieces.
- **Handling:** Handle game pieces and the spinner with care to prevent breakage or loss.

5. TROUBLESHOOTING

- **Missing Components:** If any components are missing upon opening the box, please refer to the manufacturer's contact information provided on the packaging for assistance.
- **Damaged Components:** If any game pieces or the board are damaged, contact the manufacturer for potential replacements or solutions.
- **Spinner Malfunction:** Ensure the soft-dart is properly seated in the spinner mechanism. If the spinner does not function correctly, check for any obstructions or damage.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	6 x 25.5 x 25.5 cm
Item Weight	460 g
Manufacturer Recommended Age	4 - 83 years
Model Number	66070

ASIN	B079W2X2X1
Brand	Liscianigiocchi
Material	Cardboard
Number of Players	2 - 6
Main Character	Goose (Miraculous Ladybug theme)
Sub-brand	Miraculous: Tales of Ladybug & Cat Noir
GTIN	08008324066070

7. SAFETY WARNINGS

Please observe the following safety warnings:

- For external use only. This product is a board game and not intended for consumption.
- Avoid contact with eyes.
- Keep away from naked flame or direct heat sources to prevent damage to the cardboard components.
- Small parts may be present. Not suitable for children under 3 years due to choking hazard. Adult supervision is recommended for young children.

8. WARRANTY AND SUPPORT

Specific warranty information for the Lisciani Miraculous Ladybug Game of the Goose 66070 is typically provided within the product packaging or on the manufacturer's official website. For support regarding missing parts, defects, or general inquiries, please refer to the contact details provided by Lisciani on the game box or their official customer service channels.