

[manuals.plus](#) /› [INTEMPO](#) /› [INTEMPO Shower Speaker Model 5054061082067 User Manual](#)**INTEMPO 5054061082067**

INTEMPO Shower Speaker Model 5054061082067 User Manual

Your guide to setting up and using your waterproof Bluetooth speaker.

1. INTRODUCTION

Thank you for purchasing the INTEMPO Shower Speaker. This portable, waterproof Bluetooth speaker is designed to provide high-quality audio in environments where traditional speakers might be unsuitable, such as bathrooms. Please read this manual carefully to ensure proper use and maintenance of your device.

2. PACKAGE CONTENTS

- INTEMPO Shower Speaker (Blue)
- USB Charging Cable

3. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your INTEMPO Shower Speaker.



Image 3.1: Top view of the blue INTEMPO Shower Speaker, highlighting the control panel. The panel includes buttons for power, play/pause, skip track forward/backward, volume up/down, and call answer/end.

Control Buttons:

- **Power Button ():** Press and hold to power on/off.
- **Play/Pause Button (▶||):** Press to play or pause music.
- **Previous Track / Volume Down (/ -):** Press to go to the previous track. Press and hold to decrease volume.
- **Next Track / Volume Up (/ +):** Press to go to the next track. Press and hold to increase volume.
- **Call Button ():** Press to answer or end a phone call.

Other Components:

- **Microphone:** For hands-free calling.
- **Charging Port:** Located under a protective flap.
- **Suction Cup:** On the base for mounting to smooth surfaces.

4. SETUP

4.1. Charging the Speaker

Before first use, fully charge the speaker. The charging port is located under a protective rubber flap to maintain its waterproof seal.

1. Open the protective flap covering the charging port.
2. Connect the small end of the supplied USB charging cable to the speaker's charging port.
3. Connect the larger end of the USB cable to a USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light will illuminate (color may vary) to show the speaker is charging.
5. Once fully charged, the indicator light will change or turn off. Disconnect the cable and ensure the protective flap is securely closed to maintain waterproofing.

4.2. Mounting the Speaker

The speaker features a suction cup on its base, allowing it to be securely attached to smooth, non-porous surfaces like tiles, glass, or shower walls.



Image 4.1: A blue INTEMPO Shower Speaker attached to a white tiled wall using its suction cup, demonstrating its intended use in a shower environment.

1. Ensure the surface is clean, dry, and smooth.

2. Press the suction cup firmly against the desired surface.
3. Check that the speaker is securely attached before releasing it.

Note: For best adhesion, occasionally clean the suction cup and the mounting surface.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

- **To Power On:** Press and hold the Power button () for approximately 3 seconds. You will hear an audible tone, and an indicator light will flash.
- **To Power Off:** Press and hold the Power button () for approximately 3 seconds. You will hear an audible tone, and the indicator light will turn off.

5.2. Bluetooth Pairing

To connect your speaker to a Bluetooth-enabled device (e.g., smartphone, tablet, computer):

1. Ensure the speaker is powered on and within 10 meters (33 feet) of your device.
2. The speaker will automatically enter pairing mode, indicated by a flashing blue LED light.
3. On your device, go to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. The speaker will appear as "INTEMPO Shower Speaker" or a similar name.
5. Select the speaker from the list to connect.
6. Once successfully paired, you will hear a confirmation tone, and the LED light will stop flashing and remain solid blue.

Note: The speaker will attempt to reconnect to the last paired device automatically when powered on.

5.3. Music Playback

Once paired, you can control music playback directly from the speaker or your connected device:

- **Play/Pause:** Press the Play/Pause button (▶||).
- **Next Track:** Press the Next Track button ().
- **Previous Track:** Press the Previous Track button ().
- **Volume Up:** Press and hold the Volume Up button (↑).
- **Volume Down:** Press and hold the Volume Down button (↓).

5.4. Call Handling

When connected to a smartphone, you can manage phone calls:

- **Answer Call:** When a call comes in, press the Call button () once.
- **End Call:** During a call, press the Call button () once.
- **Reject Call:** Press and hold the Call button () for approximately 2 seconds.

6. MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.

- **Waterproofing:** Always ensure the charging port's protective flap is securely closed when using the speaker in wet environments to maintain its waterproof rating.
- **Storage:** Store the speaker in a cool, dry place when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the provided USB cable.
Cannot pair with Bluetooth device.	Bluetooth is off on your device; speaker is too far; speaker is already paired to another device.	Ensure Bluetooth is enabled on your device. Move speaker closer. Disconnect from other devices or restart the speaker.
No sound or low volume.	Volume is too low on speaker or connected device; speaker is not properly paired.	Increase volume on both the speaker and your device. Re-pair the speaker if necessary.
Suction cup does not stick.	Surface is not clean, dry, or smooth; suction cup is dirty.	Clean the surface and the suction cup. Ensure the surface is smooth and non-porous.

8. SPECIFICATIONS

- **Model:** 5054061082067
- **Brand:** INTEMPO
- **Connectivity:** Bluetooth, Wireless
- **Wireless Range:** Up to 10 meters (33 feet)
- **Speaker Output:** 3 Watts
- **Power Source:** Battery Powered
- **Waterproof:** Yes
- **Color:** Blue
- **Dimensions:** 18.1 x 17 x 6.6 cm (approximate package dimensions)
- **Weight:** 207 grams (approximate package weight)

9. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures or direct sunlight for extended periods.
- Do not attempt to disassemble or modify the speaker. This will void the warranty and may cause damage.
- Keep the speaker away from sharp objects.
- Ensure the charging port flap is sealed when using in wet conditions.
- Dispose of the product responsibly according to local regulations. Do not dispose of with

household waste.

- Use only the provided charging cable or a certified equivalent.

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or contact the manufacturer directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Intempo

Related Documents - 5054061082067

	<p>Intempo Duo Speaker Quick Start Guide</p> <p>Quick start guide for the Intempo Duo Speaker, covering charging, pairing, Bluetooth mode, TF card, Aux mode, volume control, and specifications.</p>
	<p>Intempo EE2221 Karaoke Microphone Instruction Manual</p> <p>User guide and safety instructions for the Intempo EE2221 Karaoke Microphone, covering setup, operation, Bluetooth, Aux mode, and troubleshooting.</p>
	<p>Intempo EE4874 Tempo Bluetooth LED Speaker User Manual</p> <p>User manual for the Intempo EE4874 Tempo Bluetooth LED Speaker, providing instructions on setup, operation, and safety. Learn how to connect your device via Bluetooth and enjoy your music.</p>
	<p>Intempo WDS485 Bluetooth Speaker: User Manual and Specifications</p> <p>Comprehensive guide for the Intempo WDS485 Bluetooth Speaker, covering setup, usage, safety, troubleshooting, and technical specifications. Learn how to pair devices, use AUX mode, and care for your speaker.</p>
	<p>Intempo EE7036BLKKFLDIR TWS Earphones with Charging Case - User Manual</p> <p>Comprehensive user manual for Intempo EE7036BLKKFLDIR True Wireless Stereo (TWS) earphones. Includes setup, pairing, controls, specifications, safety, and troubleshooting information.</p>
	<p>Intempo Wireless Pod Speaker EE6154 User Manual</p> <p>This user manual provides instructions for the Intempo Wireless Pod Speaker EE6154, covering setup, operation, safety guidelines, and troubleshooting.</p>