

[manuals.plus](#) /

› [Relaxdays](#) /

› [Relaxdays TV Stand White, Portable Entertainment Unit on 4 Wheels, Model 10021865 Instruction Manual](#)

Relaxdays 10021865

Relaxdays TV Stand White - Model 10021865 Instruction Manual

Portable Entertainment Unit on 4 Wheels

INTRODUCTION

Thank you for choosing the Relaxdays TV Stand. This portable entertainment unit is designed to complement most interior decorations with its seamless white finish and high-quality stainless steel accents. It features three tiers for versatile storage of your television, Hi-Fi system, game consoles, or other media devices. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.



Image: The Relaxdays TV Stand, white, with a television placed on its top surface. The stand features two lower shelves, one of which holds books. The unit is positioned in a modern living space with light-colored walls and a patterned curtain.

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- This product contains small parts and sharp edges. Handle with care during assembly.
- Always assemble and use the product strictly according to the instructions provided.
- Keep all components and tools out of reach of children.
- Ensure the TV stand is placed on a stable, level surface.
- Do not overload the shelves. Refer to the specifications for maximum weight capacity.
- Do not allow children to climb on the unit.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x TV Stand (disassembled parts)
- Assembly materials (screws, connectors, etc.)
- Instruction manual

Note: Decorative items shown in product images are not included with the TV stand.

SETUP AND ASSEMBLY

Assembly is straightforward with the provided illustrated instructions. A screwdriver is required for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in the included instruction manual to identify each component. Panels are typically numbered.
3. **Assemble Frame:** Attach the stainless steel bars to the main panels using the provided screws. Ensure all connections are secure.
4. **Install Shelves:** Insert the middle shelves into their designated slots or attach them using the appropriate hardware. Ensure they are level and stable.
5. **Attach Wheels:** Securely attach the four swivel wheels to the bottom panel of the stand. Ensure they are firmly screwed in. The wheels can be manually locked for stability.
6. **Final Check:** Once assembled, gently shake the unit to ensure all connections are tight and the stand is stable.



Image: A technical diagram illustrating the overall dimensions of the TV stand: 41.5 cm in height, 80 cm in width, and 40 cm in depth. This image is helpful for understanding the product's size during assembly and placement.

OPERATING INSTRUCTIONS

The Relaxdays TV Stand is designed for versatile use as a television stand or a Hi-Fi unit.

- **Placement:** Position your television or Hi-Fi system on the top surface. The top surface provides ample space for most standard TVs.
- **Storage:** Utilize the two middle shelves for storing game consoles, DVD/Blu-ray players, media boxes, remote controls, books, or other accessories.
- **Mobility:** The four swivel wheels allow for easy movement of the stand. To move the unit, unlock the wheels if they are engaged. Guide the stand to your desired location.
- **Stability:** Once the stand is in its desired position, engage the locks on the wheels to prevent accidental movement and ensure stability.



Image: The white Relaxdays TV Stand positioned beside a grey sofa in a contemporary living room. A television is on the top shelf, and a media player is visible on one of the lower shelves, demonstrating its functional use.

MAINTENANCE

Proper care will ensure the longevity and appearance of your Relaxdays TV Stand.

- **Cleaning:** Wipe the surfaces with a dry cloth only.
- **Avoid Harsh Chemicals:** Do not use harsh chemical cleaners, abrasive materials, or polishes, as these can damage the finish of the MDF and stainless steel.
- **Spills:** In case of spills, wipe immediately with a dry or slightly damp cloth to prevent staining or damage.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Tighten if necessary.



Image: A close-up view highlighting the smooth white finish of the top panel and the reflective stainless steel support bar, demonstrating the quality of materials and design.



Image: A detailed view of the bottom section of the TV stand, showing the stainless steel support bar connecting to the base, and one of the black swivel wheels, emphasizing the mobility feature.

TROUBLESHOOTING

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Wobbly Stand:** Ensure all screws and connections are tightened. Check that the stand is on a level surface. Adjust the wheels if necessary.
- **Difficulty Moving:** Verify that the wheel locks are disengaged. Clean any debris from the wheels.
- **Damaged Parts:** If any part is damaged during assembly or use, cease use and contact customer support for

replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	Relaxdays
Model Number	10021865
Color	White
Material	MDF, Stainless Steel, Plastic
Overall Dimensions (H x W x D)	Approx. 41.5 x 80 x 40 cm
Smaller Shelf Dimensions (W x D)	Approx. 45 x 36.5 cm
Distance Between Tiers	Approx. 16.5 cm
Bar Length	Approx. 33.5 cm
Distance to Floor	Approx. 5 cm
Item Weight	Approx. 12.8 kg
Maximum Capacity	Approx. 20 kg
Special Features	Portable, 4 Swivel Wheels, 3 Tiers, Stainless Steel Accents
Assembly Required	Yes
Product Care Instructions	Wipe with a dry cloth only

WARRANTY INFORMATION

Relaxdays products are manufactured to high-quality standards. For specific warranty details, please refer to the documentation included with your purchase or contact Relaxdays customer service. Keep your proof of purchase for any warranty claims.

SUPPORT

For further assistance, missing parts, or questions regarding your Relaxdays TV Stand, please contact the retailer where you purchased the product or visit the official Relaxdays website for customer support information.

