

**WOFI 8069.01.06.7000**

# WOFI Maya 1 Plate Table Lamp Instruction Manual

Model: 8069.01.06.7000

[Overview](#)

[Safety](#)

[Contents](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty](#)

[Supp](#)

## 1. PRODUCT OVERVIEW

This manual provides instructions for the safe and efficient use of your WOFI Maya 1 Plate Table Lamp, model 8069.01.06.7000. This table lamp is designed to provide ambient lighting and features a distinctive design suitable for various indoor settings. It is compatible with light sources of energy efficiency classes A++ to E.



Figure 1: WOFI Maya 1 Plate Table Lamp (Model 8069.01.06.7000)

## 2. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure the power supply is disconnected before installation, cleaning, or replacing the light bulb.
- This product is for indoor use only. Do not expose to moisture or extreme temperatures.
- Do not exceed the maximum wattage specified for the light bulb (60 watts).
- Use only light bulbs with an E27 cap type.
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- Do not attempt to modify the lamp in any way.
- Keep out of reach of children and pets.
- The lamp is rated IP20, meaning it is protected against solid objects larger than 12.5mm, but not against water.

### 3. PACKAGE CONTENTS

Verify that all components are present and undamaged before proceeding with installation.

- WOFI Maya 1 Plate Table Lamp (1 unit)
- Instruction Manual (this document)

*Note: Light bulb is not included and must be purchased separately.*

### 4. SETUP AND INSTALLATION

Follow these steps to set up your table lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Select Location:** Place the lamp on a stable, flat surface indoors, away from moisture and direct heat sources.
3. **Install Light Bulb:**
  - Ensure the lamp is unplugged from the power outlet.
  - Gently unscrew the decorative shade to access the bulb socket, if necessary.
  - Screw an E27 base light bulb (max 60W) into the socket until it is secure.
  - Reattach the decorative shade, ensuring it is properly aligned and secured.
4. **Connect to Power:** Insert the power plug into a standard electrical outlet.



Figure 2: Lamp Dimensions (Height: 43cm, Width: 42cm)



Figure 3: Energy Efficiency Label (Compatible with E27 bulbs, A++ to E)

## 5. OPERATING INSTRUCTIONS

The WOFI Maya 1 Plate Table Lamp is equipped with a convenient switch for easy operation.

- **Turning On:** Locate the switch on the power cord or lamp base. Toggle the switch to the "ON" position.
- **Turning Off:** Toggle the switch to the "OFF" position.

This lamp provides a variable lighting effect depending on the chosen E27 bulb, including compatibility with LED lamps.

## 6. CARE AND MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your lamp.

- **Cleaning:**
  - Always unplug the lamp before cleaning.
  - Wipe the lamp base and shade with a soft, dry cloth.
  - Do not use abrasive cleaners, solvents, or polishes as they may damage the finish.
- **Bulb Replacement:**
  - Ensure the lamp is unplugged and the bulb has cooled completely.
  - Gently unscrew the old E27 bulb counter-clockwise.
  - Screw in a new E27 bulb (max 60W) clockwise until secure.
  - Dispose of old bulbs according to local regulations.

## 7. TROUBLESHOOTING

If you encounter issues with your lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	<ul style="list-style-type: none"> <li>• Lamp not plugged in.</li> <li>• Light bulb is loose or faulty.</li> <li>• Power outlet is not functioning.</li> <li>• Switch is in "OFF" position.</li> </ul>	<ul style="list-style-type: none"> <li>• Ensure the lamp is securely plugged into a working outlet.</li> <li>• Tighten or replace the light bulb.</li> <li>• Test the outlet with another appliance.</li> <li>• Toggle the switch to the "ON" position.</li> </ul>

Problem	Possible Cause	Solution
Light flickers.	<ul style="list-style-type: none"> <li>Loose light bulb.</li> <li>Faulty light bulb.</li> <li>Unstable power supply.</li> </ul>	<ul style="list-style-type: none"> <li>Tighten the light bulb.</li> <li>Replace the light bulb.</li> <li>Check if other appliances on the same circuit are causing fluctuations.</li> </ul>

If the problem persists after trying these solutions, please contact customer support.

## 8. PRODUCT SPECIFICATIONS

<b>Brand:</b>	WOFI
<b>Model Number:</b>	8069.01.06.7000
<b>Manufacturer:</b>	WOFI Leuchten Wortmann & Filz GmbH
<b>Dimensions (H x W x D):</b>	43 cm x 42 cm x 42 cm
<b>Weight:</b>	0.96 Kilograms
<b>Material:</b>	Metal
<b>Colour:</b>	White
<b>Number of Lights:</b>	1
<b>Cap Type:</b>	E27
<b>Max Wattage:</b>	60 watts
<b>Energy Efficiency Class:</b>	Suitable for A++ to E
<b>Area Lighting Classification:</b>	IP20
<b>Power Source:</b>	Male Connector (Mains Powered)
<b>Batteries Required:</b>	No

## 9. WARRANTY INFORMATION

WOFI products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact WOFI customer support. This warranty typically covers manufacturing defects under normal use.

## 10. CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report a problem with your WOFI Maya 1 Plate Table Lamp, please contact WOFI customer support.

Contact information can typically be found on the WOFI official website or on your purchase receipt.