

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 15V AC/DC Adapter Instruction Manual for TEKA TEKA060-1501600

UPBRIGHT TEKA060-1501600

UpBright 15V AC/DC Adapter Instruction Manual

Model: TEKA TEKA060-1501600 Power Charger

INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your UpBright 15V AC/DC Adapter. Please read this manual thoroughly before using the product and retain it for future reference. This adapter is designed to provide stable 15V DC power to compatible devices, specifically TEKA TEKA060-1501600 models.

IMPORTANT SAFETY INFORMATION

- Ensure the adapter's voltage and current ratings match your device's requirements.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not disassemble or attempt to repair the adapter. Refer to qualified service personnel.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.
- This adapter features OVP (Over Voltage Protection), OCP (Over Current Protection), and SCP (Short Circuit Protection) for enhanced safety.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x UpBright 15V AC/DC Power Adapter (2-Pin)

Note: Depending on your region, an appropriate international outlet adapter may be included.

PRODUCT OVERVIEW

The UpBright 15V AC/DC Adapter is a compact and efficient power supply designed for various electronic devices

requiring 15V DC input. It features a standard barrel connector for compatibility with a wide range of equipment.



Image 1: The UpBright 15V AC/DC Power Adapter, showing the main unit with a US-style plug and the attached DC output cable terminating in a barrel connector.

UpBright AC Adapter Power Supply Compatible with:



Image 2: A detailed view of the barrel connector, which is the output plug that connects to your electronic device.

SETUP INSTRUCTIONS

1. **Verify Compatibility:** Before connecting, ensure your device requires a 15V DC input and that the barrel connector size matches. Refer to your device's manual for power specifications.
2. **Connect to Device:** Insert the barrel connector of the UpBright adapter firmly into the DC input port of your electronic device.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard 100-240VAC 50/60Hz wall outlet.
4. **Power On Device:** Once connected, power on your device as usual.



Image 3: The UpBright AC/DC adapter with its cable neatly coiled, ready for connection to a power source and a compatible device.

OPERATING INSTRUCTIONS

Once properly connected, the adapter will supply continuous 15V DC power to your device. No further user interaction is required for its operation. The adapter is designed for continuous use within its specified operating parameters.

- Ensure adequate ventilation around the adapter during operation to prevent overheating.
- If your device has an on/off switch, use that to control power to the device, not by repeatedly plugging and unplugging the adapter.

MAINTENANCE

- **Cleaning:** Disconnect the adapter from both the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use and replace the adapter.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly plugged in. Device's power switch is off. Incompatible voltage/current. Faulty adapter or device.	Ensure adapter is fully plugged into both wall outlet and device. Turn on device's power switch. Verify adapter specifications match device requirements. Test with another compatible adapter if available, or contact support.
Adapter feels hot.	Normal operation under load. Poor ventilation. Overload or short circuit.	A slight warmth is normal. Ensure adapter is in a well-ventilated area. Disconnect immediately if excessively hot or emitting smoke/smell. Contact support.
Intermittent power.	Loose connection. Damaged cable/connector.	Check all connections are secure. Inspect cable and connector for damage. Replace if damaged.

SPECIFICATIONS


Feature	Detail
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	15V DC
Output Current	1.6A (1600mA)
Wattage	15 Watts
Connector Type	Barrel Connector
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Product Dimensions	Approximately 4 x 3 x 2 inches
Item Weight	Approximately 3.52 ounces
Compatible Devices	TEKA TEKA060-1501600, TEKA0601501600, TEKA060 1501600

WARRANTY AND SUPPORT

UpBright products are tested and designed for reliability. This product comes with a limited warranty.

- **Warranty Period:** UpBright offers a 30-day refund policy and a 24-month exchange warranty for this product.
- **Claiming Warranty:** For warranty claims or technical support, please contact your retailer or visit the official UpBright website for contact information.

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY




Image 4: This image illustrates the potential inclusion of international outlet adapters (AU, EU, UK) for global compatibility, alongside a representation of the UpBright Limited Warranty Certificate.

© 2026 UpBright. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question