

## Sharp HT-SB140(MT)

# Sharp HT-SB140MT 2.0 150W Soundbar User Manual

Model: HT-SB140(MT) | Brand: Sharp

## 1. INTRODUCTION

Thank you for purchasing the Sharp HT-SB140MT 2.0 150W Soundbar. This soundbar is designed to enhance your audio experience, providing clear and powerful sound for your television, music, and other media. With its sleek design and versatile connectivity options, including Bluetooth, HDMI ARC/CEC, Optical, and Auxiliary inputs, it integrates seamlessly into any home entertainment setup. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.

## 2. SAFETY INFORMATION

- **Power Source:** Ensure the power supply voltage matches the requirements specified on the soundbar. Use only the provided power cable.
- **Ventilation:** Do not block any ventilation openings. Maintain adequate space around the soundbar for proper airflow.
- **Water and Moisture:** Do not expose the soundbar to dripping or splashing water. Do not place objects filled with liquids, such as vases, on the apparatus.
- **Heat:** Do not place the soundbar near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Cleaning:** Unplug the soundbar from the power outlet before cleaning. Use a dry, soft cloth for cleaning. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.
- **Batteries:** The remote control uses a CR2 battery. Ensure correct polarity when inserting batteries. Do not mix old and new batteries.

## 3. PACKAGE CONTENTS

Please check that all items are present in the package:

- Sharp HT-SB140MT Soundbar

- Remote Control
- Power Cable
- User Manual (this document)

## 4. PRODUCT OVERVIEW



**Figure 4.1: Front View**

The front of the soundbar features the Sharp logo and LED indicators for source selection and status. Control buttons for power, input, and volume are located on the top panel.



**Figure 4.2: Rear View (Connections)**

The rear panel provides all necessary connection ports: HDMI ARC, Optical (S/PDIF), and Auxiliary (3.5mm) input, along with the power input.



**Figure 4.3: Remote Control**

The included remote control allows for convenient operation of the soundbar, including power, input selection, volume, bass, and treble adjustments.

## 5. SETUP

### 5.1 Placement

The Sharp HT-SB140MT Soundbar can be placed on a flat surface, such as a TV stand, or wall-mounted. Its slim profile of 6 cm allows it to fit easily under most TV screens without obstructing the view.



**Figure 5.1: Soundbar Placement**

The soundbar is ideally positioned directly in front of your television for optimal sound projection.

## 5.2 Connecting to Your TV

Choose one of the following connection methods:

1. **HDMI ARC/CEC (Recommended):** Connect an HDMI cable (not included) from the HDMI ARC port on your TV to the HDMI ARC port on the soundbar. This allows your TV remote to control the soundbar's volume and power. Ensure HDMI ARC/CEC is enabled in your TV's settings.
2. **Digital Optical Audio (S/PDIF):** Connect an optical cable (not included) from the Optical Out port on your TV to the OPTICAL IN port on the soundbar. Select the Optical input on the soundbar.
3. **Auxiliary (AUX):** Connect a 3.5mm audio cable (not included) from the headphone jack or AUX Out port on your TV to the AUX IN port on the soundbar. Select the AUX input on the soundbar.

## 5.3 Power Connection

After connecting the audio cable, plug the power cable into the soundbar's power input and then into a wall outlet (220-240V / 50Hz).

# 6. OPERATING INSTRUCTIONS

## 6.1 Power On/Off

Press the Power button on the soundbar or the remote control to turn the unit on or off.

## 6.2 Source Selection

Press the Input button on the soundbar or the remote control repeatedly to cycle through the available input sources: HDMI ARC, Optical, AUX, and Bluetooth. The LED indicator on the soundbar will change to reflect the selected source.

### 6.3 Volume Adjustment

Use the Volume Up (+) and Volume Down (-) buttons on the soundbar or the remote control to adjust the sound level.

### 6.4 Bluetooth Pairing

To connect a Bluetooth device:

1. Select Bluetooth input on the soundbar. The Bluetooth LED indicator will flash, indicating pairing mode.
2. On your smart device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "SHARP HT-SB140MT" from the list of devices.
4. Once connected, the Bluetooth LED indicator will stop flashing and remain solid. You can now stream audio wirelessly to the soundbar.

### 6.5 Sound Modes (Equalizer)

The soundbar features an equalizer with different sound modes to optimize audio for various content types. Use the EQ button on the remote control to cycle through these modes (e.g., Movie, Music, News). You can also adjust Bass and Treble levels using dedicated buttons on the remote.

## 7. MAINTENANCE

### 7.1 Cleaning

To clean the soundbar, unplug it from the power outlet. Use a soft, dry, lint-free cloth to wipe down the surfaces. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

### 7.2 Storage

If you plan to store the soundbar for an extended period, disconnect it from the power supply and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

## 8. TROUBLESHOOTING

If you encounter issues with your soundbar, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from the soundbar.	Soundbar is off or muted. Incorrect input source selected. Cables are not connected properly. TV audio output settings are incorrect.	Ensure the soundbar is powered on and not muted. Select the correct input source (HDMI ARC, Optical, AUX). Check all cable connections (HDMI, Optical, AUX). Verify your TV's audio output settings are set to external speakers or the correct digital output.
Bluetooth device cannot connect.	Soundbar is not in pairing mode. Device is out of range. Interference from other devices.	Ensure the soundbar is in Bluetooth input mode and the LED is flashing. Move your Bluetooth device closer to the soundbar (within 10 meters). Turn off other Bluetooth devices nearby. Try unpairing and re-pairing.

Problem	Possible Cause	Solution
Remote control is not working.	Battery is low or inserted incorrectly. Obstruction between remote and soundbar. Remote control is faulty.	Replace the CR2 battery and ensure correct polarity. Remove any obstructions between the remote and the soundbar's sensor. If issues persist, contact customer support.






## 9. SPECIFICATIONS

Model Name	HT-SB140(MT)
Speaker Type	Soundbar
Surround Sound Channel Configuration	2.0
Maximum Speaker Output Power	150 Watts
Frequency Response	60 Hz
Connectivity Technology	Bluetooth, HDMI ARC/CEC, Digital Optical Audio (S/PDIF), 3.5mm Auxiliary (AUX)
Wireless Communication Technology	Bluetooth
Maximum Range (Bluetooth)	10 Meters
Control Method	Remote Control
Power Source	AC (Mains)
Input Voltage	220-240 Volts
Color	Black
Material	Plastic, Metal
Mounting Type	Wall Mount, Tabletop
Product Dimensions (L x W x H)	95 x 6 x 6 cm
Item Weight	1.5 Kilograms
Included Components	Remote Control
Battery Required	1 CR2 battery
Waterproof	No
Spare Parts Availability	5 Years
Software Updates Guaranteed Until	Information not available

## 10. WARRANTY AND SUPPORT

The Sharp HT-SB140MT Soundbar comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms and conditions. Spare parts are available for up to 5 years from the date of purchase. For technical support, service, or warranty claims, please contact Sharp customer service through their official website or the contact information provided in your product documentation. When contacting support, please have your product model number (HT-SB140(MT)) and purchase details ready.

### Related Documents - HT-SB140(MT)

	<p><a href="#">Sharp HT-SB145, HT-SB146 2.0 Soundbar User Manual</a></p> <p>User manual for the Sharp HT-SB145 and HT-SB146 2.0 Soundbar, covering setup, operation, safety instructions, and troubleshooting.</p>
	<p><a href="#">Sharp HT-SBW110 2.1 Soundbar Home Theatre System User Manual</a></p> <p>Comprehensive user manual for the Sharp HT-SBW110 2.1 Soundbar Home Theatre System, covering setup, operation, connections, Bluetooth, and troubleshooting.</p>
	<p><a href="#">Sharp HT-SB100 User Manual: Setup and Operation Guide</a></p> <p>Comprehensive user manual for the Sharp HT-SB100 2.0 Soundbar Home Theatre System. Learn about setup, connections, remote control operation, troubleshooting, and safety instructions.</p>
	<p><a href="#">Sharp HT-SBW800 User Manual: Dolby Atmos Soundbar Guide</a></p> <p>Comprehensive user manual for the Sharp HT-SBW800 5.1.2ch Dolby Atmos Home Theatre System with wireless subwoofer. Learn about setup, connections, operation, and troubleshooting.</p>
	<p><a href="#">SHARP HT-SB140(MT) 2.0 Slim Soundbar: Features &amp; Specifications</a></p> <p>Explore the SHARP HT-SB140(MT) 2.0 Slim Soundbar. This document details its 150W power, Bluetooth streaming, HDMI ARC/CEC control, audio features, design, and comprehensive logistic information. Ideal for TVs 43 inches and above.</p>

**SHARP**



User manual  
HT-SB110

© 2016 Sharp Corporation

EN | ES | PT | FR | DE

### [Sharp HT-SB110 User Manual](#)

Comprehensive user manual for the Sharp HT-SB110 2.0 Soundbar Home Theatre System, covering safety instructions, controls, connections, operation, and troubleshooting.