Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JACKPOT! JP-EL-Bed

JACKPOT! Princess Low Loft Bed with Slide Instruction Manual

Model: JP-EL-Bed

Introduction

This manual provides essential instructions for the assembly, safe use, and maintenance of your JACKPOT! Princess Low Loft Bed with Slide, Pink and White Tent and Tower. Please read all instructions carefully before assembly and retain this manual for future reference.



Figure 1: Fully assembled JACKPOT! Princess Low Loft Bed with slide, pink and white tent, and tower, in a cherry finish.

Important Safety Information

Failure to follow these warnings could result in serious injury.

- Always follow the information on the warning labels located on the upper loft bed end and on the product carton. Do not remove these warning labels from the bed.
- This loft bed is designed for children aged 6 years and older.
- The maximum weight capacity for this bed is 175 lbs (approximately 79 kg).
- Ensure all connections are securely tightened after assembly and periodically check for tightness.
- Use only a twin-size mattress. An 8-inch thick mattress is recommended for optimal safety and fit.
- This is a loft-style bed, not a bunk bed. It is designed for single occupancy on the upper sleeping surface.
- Do not allow children to hang from any part of the bed structure.
- Keep the area around the slide clear of obstructions.

Package Contents

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact customer support immediately.

- Guardrails
- Headboard
- Installation Manual (physical copy)
- Slide
- Tower
- Tent (Pink and White Curtains, Top Tent)
- All necessary assembly hardware and tools

Setup and Assembly

Assembly of the JACKPOT! Princess Low Loft Bed is required. Please refer to the detailed physical installation manual included in your package for step-by-step instructions and diagrams. A drill with proper bits may speed up the process, and assistance from another person is recommended.

Key Assembly Notes:

- The end ladder and slide can be positioned on either the right or the left side of the bed frame to best suit your room layout.
- The bed includes a complete set of slats, eliminating the need for a bunkie board or bunkie mattress.
- Ensure all bolts and screws are tightened securely, but do not overtighten.
- For a neater appearance, consider ironing the fabric tent and curtains before attaching them to the bed frame.




Figure 2: Overall dimensions of the assembled loft bed.



Figure 3: View of the loft bed with the slide and tower positioned.

Operating Guidelines

The JACKPOT! Princess Low Loft Bed is designed for both sleeping and play. Adhere to the following guidelines for safe and enjoyable use:

- **Recommended Age:** This bed is suitable for children 6 years and older.
- **Weight Limit:** Do not exceed the maximum weight capacity of 175 lbs (approximately 79 kg) on the sleeping surface.
- **Mattress:** Use a standard twin-size mattress. An 8-inch thick mattress is ideal for proper guardrail height.
- **Slide Use:** Ensure the slide is used one person at a time and that the landing area is clear.
- **Play Area:** The space underneath the bed, enclosed by the tent, provides a designated play area. Supervise children during play.



Figure 4: The play area beneath the loft bed with tent curtains.

Maintenance

Regular maintenance will help prolong the life and safety of your loft bed.

- **Cleaning the Frame:** Wipe the wood frame with a damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Fabric Care:** The pink and white tent and curtains can be spot cleaned with a mild detergent and water. For deeper cleaning, follow care instructions on the fabric tags, if available.
- **Hardware Check:** Periodically inspect all bolts, screws, and connections to ensure they remain tight. Retighten as necessary to maintain structural integrity.
- **General Inspection:** Regularly check for any signs of wear, damage, or loose parts. Address any issues promptly.

Troubleshooting

If you encounter issues during assembly or use, consider the following common solutions:

- **Difficulty with Assembly:** Review the included physical instruction manual carefully. Ensure all parts are oriented correctly as shown in the diagrams. Sometimes, a fresh look or assistance from another person can help identify overlooked steps.

- **Wobbly Bed:** This usually indicates loose hardware. Systematically check and tighten all bolts and screws throughout the entire bed frame. Ensure the bed is placed on a level surface.
- **Missing Parts:** If you believe parts are missing, compare your inventory against the parts list in the physical manual. Contact JACKPOT! customer support for assistance.
- **Tent/Curtain Fit Issues:** Ensure the fabric components are attached according to the manual. Minor adjustments may be needed for a smooth fit.

Specifications

Feature	Detail
Model Number	JP-EL-Bed
Bed Type	Low Loft Bed
Mattress Size Compatibility	Twin
Overall Product Dimensions (L x W x H)	80" x 84.75" x 87.5" (approximate)
Loft Bed Dimensions (L x W x H)	80" x 41.75" x 49.25" (approximate, without slide/tower)
Space Under Bed (H x W x D)	32" x 75" x 38.25" (approximate)
Material	Solid New Zealand Pine Wood
Finish Type	Stained, Child-Safe Painted
Color	Cherry with Pink and White Tent
Item Weight	125 lbs
Assembly Required	Yes
Included Components	Guardrails, Headboard, Installation Manual, Slide, Tower, Tent

Warranty and Support

For specific warranty details, please refer to the documentation included with your product at the time of purchase. Warranty terms typically cover manufacturing defects for a specified period.
If you require assistance, have questions about assembly, or need to report missing/damaged parts, please contact JACKPOT! customer support. Contact information is usually provided in the product packaging or on the official JACKPOT! website.
Manufacturer: Maxwood

© 2023 JACKPOT! All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07B119K38

More documents and user manuals: **https://manuals.plus/**