

Citizen EQ2002-91P

Citizen Quartz Women's Watch EQ2002-91P Instruction Manual

INTRODUCTION

This manual provides instructions for the proper use and care of your Citizen Quartz Women's Watch, Model EQ2002-91P. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

PRODUCT OVERVIEW





Figure 1: Front view of the Citizen Quartz Women's Watch, Model EQ2002-91P, showcasing the gold-tone stainless steel case, champagne dial, and expansion band.

The Citizen Quartz Women's Watch EQ2002-91P is a classic timepiece featuring a gold-tone stainless steel case and expansion band. It is equipped with a quartz movement, displaying time with three hands (hour, minute, second) and a day/date complication. The watch is designed for everyday wear with a mineral crystal and 50 meters water resistance.

SETUP AND INITIAL OPERATION

1. Setting the Time

1. Pull the crown out to the second click position.
2. Rotate the crown to advance or reverse the hands to the desired time.
3. Push the crown back to the normal position to start the watch.

2. Setting the Day and Date

1. Pull the crown out to the first click position.
2. Rotate the crown clockwise to set the date.
3. Rotate the crown counter-clockwise to set the day.
4. Once the day and date are set, push the crown back to the normal position.

Note: Avoid setting the date between 9:00 PM and 4:00 AM, as this may interfere with the automatic date change mechanism.

3. Adjusting the Band

This watch features an expansion band designed for comfort. If further adjustment is required, it is recommended to consult a professional jeweler or authorized Citizen service center.

OPERATING YOUR WATCH

Timekeeping

Once the time, day, and date are set, the watch will operate continuously. The quartz movement ensures accurate timekeeping.

Water Resistance

Your Citizen EQ2002-91P watch is water resistant to 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, but not for diving or snorkeling. Avoid operating the crown while the watch is wet.

MAINTENANCE AND CARE

Cleaning

Wipe the watch case and band periodically with a soft, dry cloth to remove dirt and moisture. For the metal band, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials.

Battery Replacement

This watch is powered by a quartz battery. When the watch stops or the second hand begins to jump in two-second intervals, it indicates a low battery. Battery replacement should be performed by an authorized Citizen service center or a qualified watch technician to ensure proper sealing and maintain water resistance.

General Care

- Avoid exposing the watch to extreme temperatures or sudden temperature changes.
- Keep the watch away from strong magnetic fields.
- Avoid dropping the watch or subjecting it to strong impacts.
- Ensure the crown is always pushed in completely to maintain water resistance.



Figure 2: The Citizen EQ2002-91P watch displayed on a wrist, illustrating its fit and appearance.




Figure 3: The Citizen watch presentation box, designed to protect your timepiece when not in use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch has stopped	Depleted battery	Replace battery at an authorized service center.

Problem	Possible Cause	Solution
Incorrect time/date	Time/date not set correctly or crown is not fully pushed in.	Refer to "Setting the Time" and "Setting the Day and Date" sections. Ensure crown is fully pushed in.
Water inside watch	Crown not fully pushed in, or watch exposed to water beyond its resistance rating.	Immediately take the watch to an authorized service center for inspection and repair.

SPECIFICATIONS

- **Model Number:** EQ2002-91P
- **Movement:** Quartz
- **Case Material:** Gold-Tone Stainless Steel
- **Band Material:** Gold-Tone Stainless Steel Expansion Band
- **Crystal:** Mineral Crystal
- **Water Resistance:** 50 Meters (5 ATM)
- **Functions:** 3-Hand (Hour, Minute, Second), Day/Date Display
- **Caseback:** Snap-on, Stainless Steel
- **Dimensions:** Approximately 4.37 x 3.15 x 2.44 inches (Package)
- **Weight:** Approximately 1.2 ounces

WARRANTY AND SUPPORT

Your Citizen EQ2002-91P watch comes with a 5-Year Limited Warranty. For detailed warranty information, service, or support, please visit the official Citizen website or contact an authorized Citizen service center. For more information, visit the [Citizen Store](#).

© Citizen Watch Company. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question