



[Manuals.plus](#) /

> [ndliulei](#) /

> New Laptop Keyboard Replacement for Acer Aspire MS2286 MS2278 MS2261 MS2265 MS2309 MS2310 MS2277 US Black Color

ndliulei MS2286, MS2278, MS2261, MS2265, MS2309, MS2310, MS2277

ndliulei Laptop Keyboard Replacement User Manual

Model: Acer Aspire MS2286, MS2278, MS2261, MS2265, MS2309, MS2310, MS2277

1. INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your new ndliulei Laptop Keyboard Replacement. This keyboard is designed for specific Acer Aspire models, ensuring a precise fit and functionality.

Please read this manual thoroughly before attempting any installation to ensure proper handling and to avoid damage to your device or the new keyboard.

2. SAFETY INFORMATION

Always observe the following safety precautions when handling and installing electronic components:

- **Power Off:** Ensure your laptop is completely powered off and disconnected from all power sources (AC adapter and battery) before beginning any installation.
- **Static Electricity:** Discharge any static electricity from your body by touching a grounded metal object before handling the keyboard. Consider using an anti-static wrist strap.
- **Handle with Care:** Electronic components, especially ribbon cables, are delicate. Handle the new keyboard and your laptop's internal components with extreme care.
- **Professional Assistance:** If you are unsure about any step, seek assistance from a qualified technician.

3. INSTALLATION GUIDE

This section outlines the general steps for replacing your laptop keyboard. Specific disassembly procedures may vary slightly by laptop model. Refer to your laptop's service manual for detailed instructions on removing the old keyboard.

3.1. Pre-Installation Check

Before proceeding with installation, compare the new keyboard with your original keyboard. Pay close attention to the layout (US Layout), the presence and position of the ribbon cable, and any mounting points. Ensure the model numbers match or are listed as compatible.



Figure 1: ndliulei Laptop Keyboard Replacement (Front and Back View)

This image displays the new laptop keyboard. The top portion shows the keyboard's face with all keys, including function keys, alphanumeric keys, and the numeric keypad, in a US layout. The bottom portion reveals the underside of the keyboard, highlighting the metallic backing and the flexible ribbon cable connector, which is essential for connecting the keyboard to the laptop's motherboard.

3.2. Required Tools (Not Included)

- Small Phillips head screwdriver
- Plastic pry tool (spudger)
- Anti-static wrist strap (recommended)

3.3. Installation Steps

1. **Prepare Laptop:** Power off your laptop completely. Disconnect the AC adapter and remove the battery.
2. **Access Old Keyboard:** Depending on your Acer Aspire model, you may need to remove screws from the bottom of the laptop, or pry open clips around the keyboard bezel. Consult your laptop's service manual for precise instructions.
3. **Disconnect Old Keyboard:** Carefully lift the old keyboard. Locate the ribbon cable connector on the motherboard. Gently flip up the small retaining clip on the connector and slide the ribbon cable out.
4. **Install New Keyboard:**
 - Align the ribbon cable of the new keyboard with the connector on the motherboard.
 - Gently slide the ribbon cable into the connector until it is fully seated.
 - Carefully push down the retaining clip to secure the ribbon cable. Ensure it is firmly locked in place.
5. **Secure New Keyboard:** Position the new keyboard into its slot, ensuring all clips and mounting points align. Gently press down around the edges until it clicks into place. Reinstall any screws that secured the keyboard or bezel.

6. **Reassemble Laptop:** Reinstall the battery and reconnect the AC adapter.
7. **Test Functionality:** Power on your laptop and test all keys to ensure proper operation.

4. OPERATION

Once installed, your new ndliulei keyboard operates identically to your original laptop keyboard. It features a standard US layout, providing full functionality for typing and system control.

- **Standard Keys:** All alphanumeric, symbol, and modifier keys (Shift, Ctrl, Alt, Fn) function as expected.
- **Function Keys (F1-F12):** These keys perform their standard functions. Many also have secondary functions (e.g., volume control, brightness adjustment, Wi-Fi toggle) when pressed in combination with the **Fn** key. Refer to your laptop's user manual for specific Fn key combinations.
- **Numeric Keypad:** If present on your model, the numeric keypad provides quick entry for numbers and mathematical operations. Ensure Num Lock is enabled if you wish to use the numeric functions.

5. MAINTENANCE AND CARE

Proper care will extend the lifespan of your keyboard:

- **Cleaning:** Use a soft, lint-free cloth slightly dampened with water or a mild, non-abrasive cleaning solution. Avoid spraying liquids directly onto the keyboard. Compressed air can be used to remove dust and debris from between keys.
- **Avoid Spills:** Liquids are highly damaging to keyboards. Keep beverages away from your laptop. In case of a spill, immediately power off the laptop, disconnect it from power, and dry it thoroughly before attempting to power it on again.
- **Gentle Use:** Avoid excessive force when typing.

6. TROUBLESHOOTING

If you encounter issues with your new keyboard, consider the following troubleshooting steps:

- **Keyboard Not Responding:**
 - Ensure the ribbon cable is securely connected to the motherboard. Power off the laptop, disconnect power, and re-seat the cable.
 - Verify that the keyboard is correctly seated in its housing and all clips are engaged.
 - Restart your laptop.
- **Certain Keys Not Working:**
 - Check for any physical obstructions or debris under the non-functioning keys.
 - Re-seat the ribbon cable as described above. A loose connection can cause intermittent key failures.
 - Ensure correct keyboard drivers are installed (usually handled automatically by the operating system).
- **Incorrect Key Output:**
 - Verify that the correct keyboard layout (US) is selected in your operating system settings.

If problems persist after attempting these steps, it may indicate a more complex issue with the keyboard or your laptop's motherboard. Contact customer support for further assistance.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	ndliulei
Compatible Models	Acer Aspire MS2286, MS2278, MS2261, MS2265, MS2309, MS2310, MS2277
Layout	US Layout
Color	Black
Material	Acrylonitrile Butadiene Styrene
UPC	693545615640
Manufacturer	ndliulei

8. WARRANTY INFORMATION

Specific warranty details for this product are not provided in this manual. For information regarding warranty coverage, terms, and conditions, please refer to the product listing on the retailer's website or contact the seller directly.

9. CUSTOMER SUPPORT

If you require further assistance or have questions not covered in this manual, please contact the seller, **Jiuleicomputer**, through the platform where you purchased the product. Provide your order details and a clear description of the issue for prompt support.

For general inquiries or to explore other products, you may visit the brand's page or the retailer's website.

© 2025 ndliulei. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.