

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hape](#) /

› [Hape Kid's Flame First Musical Guitar E0602 Instruction Manual](#)

## Hape E0602

# Hape Kid's Flame First Musical Guitar E0602 Instruction Manual

Model: E0602

## INTRODUCTION

The Hape Kid's Flame First Musical Guitar is designed to introduce young children to the world of music. This 26-inch wooden guitar features four tunable nylon strings and a scaled-down body, making it suitable for small hands. It encourages musical aptitude and creative expression.

## SAFETY INFORMATION

This product is recommended for children aged 36 months and older. All Hape products sold in North America meet or exceed applicable safety standards. The guitar features durable, child-safe paint finishes and non-toxic materials.

**Warning:** Small parts may be present. Adult supervision is recommended during play.

## PACKAGE CONTENTS

- 1 x Hape Kid's Flame First Musical Guitar (Model E0602)

## SETUP

1. **Unpacking:** Carefully remove the guitar from its packaging. Inspect for any damage.
2. **Initial Inspection:** Ensure all four nylon strings are securely attached to the bridge and tuning pegs.
3. **Tuning the Strings:** The guitar features tunable nylon strings. Gently turn the tuning pegs located on the headstock to adjust the tension of each string. Adjust until the desired pitch is achieved. For best results, use a digital tuner (not included) or a reference tone.







Image: The Hape Kid's Flame First Musical Guitar in red, showcasing its design and strings.

**Learn guitar basics easily with labeled instructions and simple melodies**

**Durable child-proof paint finish and solid wood construction make it a safe**

Image: A close-up view of the guitar's headstock and strings, illustrating the tuning mechanism.

## OPERATING INSTRUCTIONS

- Holding the Guitar:** Encourage the child to hold the guitar comfortably, with the body resting against their chest and the neck supported by their left hand (for right-handed players).
- Strumming:** Use the right hand to gently strum the strings over the soundhole. Experiment with different strumming patterns and speeds.
- Pressing Strings:** Use the fingers of the left hand to press down on the strings against the fretboard to change the pitch and create different notes.

4. **Exploring Sounds:** Encourage free play and exploration of various sounds and melodies.



Image: A young girl smiling while holding and playing the Hape musical guitar, demonstrating a comfortable playing posture.



Image: A young boy with a joyful expression, actively playing the Hape musical guitar.

Your browser does not support the video tag.

Video: A product overview demonstrating the Hape Kid's Flame First Musical Guitar, including its features and how it can be played.

## MAINTENANCE

---

- **Cleaning:** The guitar's surface is finished with safe, water-based paint. Do not use alcohol or harsh cleaning agents. Wipe gently with a dry or slightly damp cloth. Avoid washing the guitar directly with water.
- **String Care:** Nylon strings are durable but can wear over time. If a string breaks, it can be replaced with a suitable nylon guitar string.
- **Storage:** Store the guitar in a dry place away from direct sunlight and extreme temperatures to prevent damage to the wood and finish.


## TROUBLESHOOTING

---

- **Strings go out of tune frequently:** Nylon strings may stretch initially. Tune the guitar regularly before each play session. Over time, they will stabilize.
- **String breaks:** Replace the broken string with a new nylon guitar string of appropriate gauge.
- **Dull sound:** Ensure strings are properly tuned and not too loose. Check for any debris in the soundhole.

## SPECIFICATIONS

Feature	Detail
Model Number	E0602
Product Dimensions	8.43 x 2.36 x 25.67 inches
Item Weight	1.3 pounds
Materials	Basswood, Pinewood, ABS, Nylon
Recommended Age	36 months - 3 years
Strings	4 Tunable Nylon Strings
Color	Red






Image: The Hape musical guitar with its key dimensions (length, width, depth) indicated.


## WARRANTY AND SUPPORT

Hape products are known for their durable construction and child-safe materials, designed for long-lasting play. For specific warranty details or support inquiries, please visit the official Hape website or contact their customer service. You can find more information about Hape products and support at the [Hape Store on Amazon](#).



© 2025 Hape. All rights reserved.

## Related Documents - E0602

	<p><a href="#">Hape Busy City Rail Set - Toy Train Track Assembly Instructions and Warnings</a> Comprehensive guide to the Hape Busy City Rail Set, including assembly notes, multilingual warnings about choking hazards, manufacturer details, and a visual description of the toy train track layout. Suitable for children aged 3 and up.</p>
--	---

	<p><a href="#"><b>Hape Red Excavator Toy (E8207) - Sand &amp; Garden Play, Ages 24 Months+</b></a></p> <p>Information about the Hape Red Excavator toy (Model E8207), designed for sand and garden play for children aged 24 months and older. Complies with European and American safety standards EN 71 and ASTM F963. Includes manufacturer details for TOYNAMICS IBERIA, S.L.U.</p>
	<p><a href="#"><b>LMNOP Magazine Issue 6: Kids Lifestyle, Fashion, Toys &amp; Home</b></a></p> <p>Explore LMNOP Magazine Issue 6, featuring articles on small-space living, children's fashion, innovative toys, home decor, NYC family guides, and creative craft ideas. Discover brands like Threadless Kids, Weego Baby, Bilibio, and more.</p>
	<p><a href="#"><b>BonoboBox Baby Toys for 9 Months: Rattles, Books, and Teethers</b></a></p> <p>This brochure from BonoboBox showcases a selection of developmental toys suitable for babies aged 9 months. It features rattles, a bath book, a wooden insect book, geo rattles, and teething toys, highlighting their benefits for coordination, sensory development, and learning.</p>