

## KERBL 29698

# KERBL All-Purpose Shovel Instruction Manual

Model: 29698

## 1. INTRODUCTION

Thank you for choosing the KERBL All-Purpose Shovel. This manual provides essential information for the safe and effective use, assembly, and maintenance of your shovel. Please read this manual thoroughly before first use and retain it for future reference.

This versatile shovel is designed for various tasks, including snow removal and grain handling. Its robust construction and detachable handle ensure durability and ease of storage.

## 2. SAFETY INFORMATION

Always prioritize safety when using any tool. Adhere to the following guidelines:

- Inspect Before Use:** Before each use, check the shovel for any signs of damage, loose parts, or wear. Do not use if damaged.
- Proper Grip:** Always maintain a firm grip on the handle to prevent accidental slips.
- Lift Safely:** When lifting heavy materials, bend your knees and lift with your legs, not your back, to prevent injury.
- Clear Work Area:** Ensure your work area is clear of obstructions and other people to avoid accidents.
- Storage:** Store the shovel in a dry, secure location, out of reach of children and pets.
- Intended Use:** Use the shovel only for its intended purpose (shoveling snow, grain, etc.). Do not use it as a pry bar or for digging hard, compacted earth.

## 3. PRODUCT OVERVIEW

The KERBL All-Purpose Shovel features a durable design with a detachable handle for convenient storage and transport.

### Components:

- Shovel Blade:** Reinforced edge for durability.
- Handle Sections:** Three-part handle for assembly and disassembly.
- D-Handle Grip:** Ergonomic D-handle for comfortable and secure grip.
- Connecting Screws:** Used to secure handle sections.







Figure 3.1: Fully assembled KERBL All-Purpose Shovel. This image shows the complete shovel, featuring a red blade and a black, multi-part handle with a D-grip at the top.






Figure 3.2: Detachable handle components. This image illustrates the separate parts of the shovel's handle: the D-handle grip and three distinct shaft sections, designed for easy assembly and disassembly.

## 4. SETUP AND ASSEMBLY

---

The KERBL All-Purpose Shovel features a 3-part handle that is robustly inserted and screwed together. Follow these steps for assembly:

1. **Identify Components:** Lay out all handle components: the D-handle, the middle shaft section, and the lower shaft section (which connects to the blade).
2. **Connect Lower Shaft:** Insert the lower shaft section firmly into the designated slot on the shovel blade. Ensure it is fully seated.
3. **Secure Lower Shaft:** Use the provided screws to secure the lower shaft section to the blade. Tighten securely but do not overtighten.
4. **Connect Middle Shaft:** Insert the middle shaft section into the top of the lower shaft section. Align the holes.
5. **Secure Middle Shaft:** Insert and tighten the screws to secure the middle shaft section.
6. **Attach D-Handle:** Insert the D-handle grip into the top of the middle shaft section. Align the holes.
7. **Secure D-Handle:** Insert and tighten the screws to secure the D-handle.

Ensure all connections are tight before use. To disassemble, reverse these steps.

## 5. OPERATING INSTRUCTIONS

---

The KERBL All-Purpose Shovel is designed for efficient material handling. Follow these general operating guidelines:

- **Grip:** Hold the D-handle firmly with one hand and the shaft with the other for optimal control and leverage.
- **Shoveling Technique:**
  - For snow: Push the blade into the snow, then lift and toss or push the snow to the side.
  - For grain or loose materials: Scoop the material with the blade, then lift and pour into the desired container or area.
- **Ergonomics:** Maintain a straight back and use your leg muscles when lifting to minimize strain. Avoid twisting your

body while lifting.

- **Blade Edge:** The reinforced blade edge is designed for durability. Avoid striking hard surfaces or using excessive force that could damage the blade.

## 6. MAINTENANCE

---

Proper maintenance will extend the life of your KERBL All-Purpose Shovel:

- **Cleaning:** After each use, especially when used with wet or sticky materials, clean the blade and handle with water. Dry thoroughly to prevent rust or material buildup.
- **Inspection:** Regularly inspect all screws and connections for tightness. Tighten any loose screws to ensure the handle remains secure.
- **Storage:** Store the shovel in a clean, dry place away from direct sunlight and extreme temperatures. The detachable handle allows for compact storage.
- **Damage:** If any part of the shovel becomes damaged, discontinue use and replace the affected component if possible, or replace the entire shovel.

## 7. TROUBLESHOOTING

---

This section addresses common issues you might encounter:

Problem	Possible Cause	Solution
Handle feels wobbly or loose.	Screws connecting handle sections are loose.	Inspect all connecting screws and tighten them securely.
Difficulty assembling handle sections.	Misalignment of sections or debris in connection points.	Ensure sections are aligned correctly. Check for and remove any debris from the connection points.
Blade appears bent or damaged.	Excessive force applied or impact with hard objects.	Discontinue use. The blade is reinforced but not indestructible. Replace the shovel if damage affects functionality or safety.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	29698
Brand	KERBL
Dimensions (L x W x H)	17.32 x 12.6 x 4.33 inches (44 cm x 32 cm x 11 cm approx.)
Blade Size	29 cm x 36 cm
Weight	4.24 pounds (1.92 kg approx.)
Material	Glass reinforced handle, durable blade material
Handle Type	3-part detachable with D-handle

## 9. SUPPORT AND CONTACT INFORMATION

For further assistance, questions, or to report issues with your KERBL All-Purpose Shovel, please contact KERBL customer support.

Please refer to the official KERBL website or your purchase documentation for the most current contact details.

*Note: Warranty information is typically provided with your purchase receipt or on the manufacturer's official website.*

*Please retain your proof of purchase for warranty claims.*

© 2025 KERBL. All rights reserved.  
This manual is subject to change without notice.

## Related Documents

	<p><a href="#"><u>KERBL EasyProtect Automatische Hühnertür Bedienungsanleitung</u></a></p> <p>Die KERBL EasyProtect Automatische Hühnertür automatisiert das Öffnen und Schließen der Stalltür für Geflügelhalter. Sie funktioniert über Zeitsteuerung oder Lichtsensor und erhöht die Sicherheit und den Komfort im Hühnerstall. Dieses Handbuch bietet detaillierte Anleitungen zur Installation, Bedienung und Wartung.</p>
	<p><a href="#"><u>Kerbl Heat Lamp 22318: Operating Instructions and Safety Guide</u></a></p> <p>Comprehensive operating instructions and safety guidelines for the Kerbl Heat Lamp 22318, designed for chick rearing and young animal heating. Includes specifications, installation, recommended lamps, and safety precautions.</p>
	<p><a href="#"><u>Kerbl Pet Bug Collar for Dogs: Application and Safety Guide</u></a></p> <p>Comprehensive guide to applying and using the Kerbl Pet Bug Collar for dogs, including dosage, replacement intervals, storage, and first aid measures.</p>
	<p><a href="#"><u>EU Declaration of Conformity - Kerbl Nitrile Gloves Premium Plus</u></a></p> <p>Official EU Declaration of Conformity for Kerbl Nitrile Gloves Premium Plus, detailing compliance with EU regulations and harmonized standards.</p>

---

Documents - KERBL – 29698

no relevant documents