Perma Child Safety 3117

Perma Child Safety Ret retractable Baby Gate (Model 3117)

Instruction Manual

Introduction

This Perma Child Safety Ret retractable Baby Gate is designed to provide a secure barrier for children aged 6-24 months and pets weighing 10-40 pounds. It extends up to 55 inches wide and stands 33 inches tall, making it suitable for various openings including stairs, hallways, and doorways. The gate features a durable, UV-resistant mesh construction for both indoor and outdoor use, and a 3-way locking system for flexible operation.

Safety Information

- **Intended Use:** This gate is designed for children aged 6-24 months and pets weighing 10-40 pounds.
- **Installation:** Always install the gate according to the provided instructions. Ensure all components are securely fastened.
- **Location:** Can be mounted indoors or outdoors, at the top or bottom of stairs, in hallways, or doorways. Spacers are included to accommodate baseboards.
- **Mesh Durability:** The durable, stain-resistant mesh is UV resistant and designed to withstand outdoor conditions and pet claws. However, constant scratching or chewing by determined pets may cause damage.
- **Supervision:** Always supervise children and pets when the gate is in use.
- **Regular Checks:** Periodically check all parts and mountings to ensure they remain secure and in good working order.
- **Standards:** This product meets and exceeds ASTM International Safety Standards.

What's in the Box

The package includes:

- Extra wide baby gate
- Screws

- Catch mounts
- Wall spacer shims for baseboards
- Installation guide

Installation

Before You Begin

Ensure you have the necessary tools for installation, which typically include a drill, screwdriver, and pencil. Read the entire installation guide before starting.

Mounting Options

The gate can be installed inside or outside of openings. Wall spacer shims are provided to ensure proper fitment around baseboards.




Image: A person marking the wall for easy installation of the retractable baby gate.




Image: Visual guide for multi-use gate placement, illustrating installation inside a frame (55" wide) and outside a frame (53" wide).

Step-by-Step Installation Guide

For detailed installation instructions, refer to the included Installation Guide (PDF) or User Guide (PDF). You can also find video guides by scanning the QR code on the product packaging or visiting the Perma Child Safety website.

Operation

3-Way Locking System

The gate features a versatile 3-way locking system:

- **Locked:** The gate is securely locked in place, preventing retraction or extension.
- **Quick Unlock:** When the handle is released, the gate automatically locks the release mechanism, allowing for quick re-engagement.
- **Full Unlock:** This mode allows you to extend and retract the gate freely. You will need to manually re-engage the

lock to secure the gate.



Image: Visual representation of the 3-function locking mechanism, showing positions for Locked, Quick Unlock, and Full Unlock.

One-Handed Operation

To operate the gate, push and twist the button, then pull the handle to extend or retract the gate. The design allows for one-handed operation, making it convenient when carrying a child or other items.




Image: A woman with a baby demonstrates the one-handed operation of the retractable gate, showing how it easily retracts without trip hazards.

Maintenance

Cleaning

Clean the mesh and plastic components with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals that could damage the material.

Inspection

Regularly inspect the gate for any signs of wear, damage, or loose components. Ensure all screws and mounts are tight. If any part is damaged, discontinue use and contact customer support for replacement parts or advice.

Troubleshooting

Gate Not Retracting/Extending Smoothly

- Check for obstructions in the retraction mechanism.
- Ensure the gate is properly aligned in its mounts.
- Verify that the 3-way locking system is in the "Full Unlock" position for free movement.

Gate Not Locking Securely

- Ensure the gate is fully extended and engaged with the catch mounts.
- Check that the locking mechanism is set to "Locked" or "Quick Unlock" position.
- Inspect the catch mounts for any damage or misalignment.

Loose Mounting

- Re-tighten all mounting screws. Avoid over-tightening.
- If installed into drywall, ensure the anchors are secure. Consider using stronger anchors if the gate frequently becomes loose.

General Issues

If you encounter any other issues, refer to the detailed troubleshooting section in the User Guide (PDF) or contact Perma Child Safety customer support.

SPECIFICATIONS




Image: Dimensions of the Perma Child Safety Ret retractable Baby Gate.

Feature	Detail
Brand Name	Perma Child Safety
Model Number	3117
Item Dimensions (W x H)	55"W x 33"H
Item Weight	3 Pounds
Material Type	Mesh
Color	Black
Mounting Type	Hardware Mount

Closure Type	Ret retractable
Age Range Description	6-24 months
Target Species	Dog
Included Components	Catch mounts, Extra wide baby gate, Installation guide, Screws, Wall spacer shims for baseboards

Warranty and Support

Perma Child Safety stands behind the quality of its products. For any product support, installation assistance, or warranty inquiries, please contact Perma Child Safety customer service. Their team is available to provide guidance throughout the product's lifecycle.

© 2026 Perma Child Safety. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question