

## Beyution AKB72915239

# Beyution AKB72915239 TV Remote Control User Manual

Model: AKB72915239

## INTRODUCTION

This manual provides detailed instructions for the Beyution AKB72915239 TV Remote Control. This remote is designed as a direct replacement for various LG LCD LED TV models, offering immediate functionality without the need for programming. Please read this manual thoroughly to ensure proper use and maintenance of your remote control.

## PRODUCT OVERVIEW

The Beyution AKB72915239 remote control is a standard infrared remote designed for ease of use. It features a comprehensive set of buttons for controlling your LG TV's functions, including power, volume, channel selection, input, and menu navigation.





**Image 1:** Front view of the Beyution AKB72915239 TV Remote Control, showing all buttons and layout.

The remote is constructed from durable ABS material, designed to be drop-resistant and long-lasting. It operates effectively at a distance of up to 10 meters (approximately 30 feet) with a fast response time.



**Image 2:** A hand holding the remote control, illustrating its effective control range of 30 feet, 0.2-second induction speed, and the requirement for 2 AAA batteries.

## SETUP


### Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

The remote control does not require any programming. Once batteries are installed, it is ready for immediate use with compatible LG TV models.







**Image 3:** Rear view of the remote control with the battery cover removed, illustrating the correct placement for two AAA batteries.

## OPERATING INSTRUCTIONS

---

The Beyution AKB72915239 remote control functions identically to the original LG remote. Point the remote directly at your television's infrared receiver for optimal performance.

### Key Functions:

- **POWER** (●): Turns the television on or off.
- **ENERGY SAVING:** Adjusts the TV's energy saving mode.
- **AV MODE:** Selects audio/video modes.
- **INPUT:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **TV:** Switches to TV mode.
- **Number Buttons (0-9):** Directly select channels.
- **LIST:** Displays the channel list.
- **MARK / FAV:** Marks content or accesses favorite channels.
- **FLASHBK:** Returns to the previously viewed channel.
- **VOL (+/-):** Adjusts the volume level.
- **MUTE:** Mutes or unmutes the TV audio.
- **RATIO:** Changes the screen aspect ratio.
- **CH (▲/▼):** Changes channels up or down.
- **INFO:** Displays current program information.
- **Home:** Accesses the TV's home menu or smart features.
- **Q.MENU:** Opens the Quick Menu for common settings.
- **Navigation Pad (◀ ▲ ▶ ▼):** Navigates through menus and options.
- **ENTER (Ⓞ):** Confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **EXIT:** Exits the current menu or application.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and content.
- **Media Control Buttons (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback.

## COMPATIBLE LG TV MODELS

---

This remote control is compatible with a wide range of LG LCD LED TV models. A partial list of compatible models includes:

- 22LV255C-UA
- 26LK330U
- 26LV2500-UA
- 32LK330-UB
- 32LK330-UH
- 32LK450-UB

- 32LV2500-UA
- 32LV255C
- 32LV3400-UA
- 37LK450-UB
- 37LK450-UH
- 37LV3500-UA
- 37LV3500-UG
- 42LK450-UB
- 42LK450-UH
- 42LK451C-UB
- 42LK520-UA
- 42LK520UB
- 42LV3500-UA
- 42LW5000UC
- 42LW5300
- 47LK450UB
- 47LK450-UB
- 47LK520-UA
- 47LW5300UC
- 55LK520-UA
- 55LV5300-UA
- 55LW5000UC
- 55LW5300UC
- 42PJ350
- 42PJ350C
- 42PJ350CUB
- 42PJ350UB
- 42PT350
- 50PJ340
- 50PJ340UC
- 50PJ350
- 50PJ350C
- 42LK453C
- 42pW350
- 42LK451C
- 50pW350
- 42PW350R
- 50PW350R
- 50PZ200
- 60PZ200
- 19LV2500
- 42LK430
- 42PW340
- 42PW350U

- 50PW340
- 50PW350U
- 22LV2500UA
- 22LV2500UG
- 26LV2500UA
- 26LV2500UG
- 32LK330UB
- 32LK330UH
- 32LK450UB
- 32LK450UH
- 32LV2500UA
- 32LV2500UG
- 32LV3400UA
- 37LK450UB
- 37LV3500UG
- 42LK450UB
- 42LK450UH
- 22LV255CUA
- 50PJ350CUB
- 50PJ350UB
- 50PW350
- 22LV2500
- 26LV2500
- 32LK330
- 32LK450
- 32LV2500
- 32LV3400
- 32LV3500
- 37LK450
- 37LV3500
- 42LK450
- 42LK451
- 42LK520
- 42LV3500
- 47LK450
- 47LK520
- 55LK520
- 55LV5300
- 47LV3500
- 19LV2520
- 55LV3500
- 22LV2520
- 32LV3520

- 26LV2520
- 42LV3520
- 26LK330
- 6LV2520
- 32LV2520
- 22LV255C
- 26LV255C
- 42LW5000
- 47LW5000
- 55LW5000
- 47LW5300
- 55LW5300
- 42LV355C
- 55LV355C
- 32LK430
- 42PW350
- 42PW350r
- 50PW350r
- 47LK451C
- 32LK453C
- 37LK453C

If your LG TV model is not listed, please refer to the product packaging or contact customer support for compatibility verification.

## SPECIFICATIONS

Feature	Detail
Model Number	AKB72915239
Brand	Beyution
Compatible Devices	LG LCD LED Televisions
Power Source	2 x AAA Batteries (not included)
Remote Distance	Up to 10 meters (approx. 30 feet)
Material	High-quality ABS
Color	Black
Product Dimensions	7 x 2 x 0.7 inches
Item Weight	2.47 ounces

## MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's performance diminishes or if it stops responding. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Environment:** Avoid exposing the remote to extreme temperatures, direct sunlight, or high humidity.

## TROUBLESHOOTING

---

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old or depleted batteries with new AAA batteries.
  - Check for any obstructions between the remote and the TV's infrared receiver.
  - Ensure the remote is pointed directly at the TV.
- **Limited range or intermittent response:**
  - Replace batteries.
  - Ensure there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the infrared signal.
  - Reduce the distance between the remote and the TV.
- **Specific buttons not working:**
  - Clean the remote control, especially around the buttons, to remove any dirt or debris that might be causing sticking.
  - If only a few buttons are unresponsive after trying new batteries, the remote may be damaged and require replacement.

## WARRANTY AND SUPPORT

---

The Beyution AKB72915239 remote control comes with a **1-year return policy**. If you encounter any issues or have questions regarding the product, please contact the seller or manufacturer directly.

Customer support aims to provide a satisfactory answer within 24 hours.

For further assistance, please refer to the contact information provided with your purchase or visit the Beyution official support channels.