

## Keter 17206371

# Keter Denali 100 Grey 380L Cushion Box User Manual

Model: 17206371 | Brand: Keter

## INTRODUCTION

The Keter Denali 100 Grey 380L Cushion Box is a robust and durable outdoor storage solution designed to protect your cushions and garden accessories from the elements. Featuring a stable double-wall construction, this box is both weather and UV resistant, ensuring longevity and reliability. Its generous 380-liter capacity provides ample space for various items, while the integrated gas spring mechanism allows for easy and smooth opening and closing of the lid. The box is also lockable, offering enhanced security for your stored belongings (lock not included).



Image: The Keter Denali 100 Grey 380L Cushion Box, showcasing its closed design and grey finish.

## SAFETY INFORMATION

- Read all instructions carefully before assembly and use.
- Ensure all parts are securely fastened before placing items inside or using the box.
- Do not allow children to play inside the box to prevent suffocation.

- Do not climb or stand on the box.
- Keep hands and fingers clear of the lid when opening or closing to avoid pinching.
- Do not store hazardous materials, flammable liquids, or chemicals inside the box.
- Place the box on a flat, stable surface to prevent tipping.

## PARTS LIST

---

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact Keter customer support.

- Side Panels (2)
- Front Panel (1)
- Back Panel (1)
- Base Panel (1)
- Lid (1)
- Gas Struts (2)
- Hinges and Mounting Brackets
- Fasteners (Screws, bolts, nuts)
- Assembly Tool (e.g., Allen key, if provided)

*Note: The exact number and type of fasteners may vary. Refer to the included assembly diagram for precise details.*

## SETUP AND ASSEMBLY

---

Assembly typically requires two people and takes approximately 45 minutes. A Phillips head screwdriver and possibly a rubber mallet may be useful.

1. **Prepare the Base:** Place the base panel on a clean, flat, and stable surface.
2. **Attach Side and Back Panels:** Connect the side panels and back panel to the base panel by aligning the grooves and pressing firmly until they click into place. Ensure the panels are oriented correctly according to the assembly diagram.
3. **Install Front Panel:** Attach the front panel to the assembled side and base panels. This step may require gentle tapping with a rubber mallet to ensure a snug fit.
4. **Secure Panels with Screws:** Once all four wall panels are connected to the base, secure them using the provided screws. There are approximately 50 screws to ensure structural stability. Tighten all screws firmly but do not overtighten.
5. **Attach Hinges:** Mount the hinges to the back panel and the lid using the designated screws. Ensure they are aligned properly for smooth lid operation.
6. **Install Gas Struts:** Attach the gas struts to their respective mounting points on the lid and the side panels. Ensure the struts are installed with the correct orientation as shown in the diagram. These struts assist in opening and holding the lid.
7. **Final Check:** Verify that all connections are secure and the lid opens and closes smoothly.



Image: Detail of the gas strut mechanism, which facilitates easy opening and closing of the lid.

## OPERATING INSTRUCTIONS

---

- **Opening the Lid:** Gently lift the lid. The integrated gas springs will assist in raising the lid and holding it open, preventing it from slamming shut.
- **Closing the Lid:** To close, gently pull the lid downwards. The gas springs will provide a controlled descent. Ensure no objects or body parts are in the way of the closing lid.
- **Locking Mechanism:** The box is designed to be lockable. A padlock (not included) can be inserted through the designated eyelet on the front of the lid to secure your belongings.
- **Storage Capacity:** The 380-liter capacity is ideal for storing garden cushions, tools, toys, and other outdoor accessories. Distribute weight evenly inside the box.



Image: The Keter Denali box with its lid open, demonstrating its spacious interior suitable for various outdoor items.

## MAINTENANCE

- Cleaning:** Clean the box regularly with a soft cloth, mild soap, and water. Avoid abrasive cleaners or harsh chemicals, as these can damage the plastic. Rinse thoroughly with clean water.
- Weather Protection:** While the box is weather and UV resistant, regular cleaning helps maintain its appearance and protective qualities. Ensure the lid is fully closed during rain or snow to keep contents dry.
- Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary. Inspect the gas struts for any signs of wear or damage.
- Winter Storage:** If storing the box empty during winter, ensure it is clean and dry. While designed for outdoor use, extreme conditions may warrant additional protection.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lid does not close properly.	Obstruction inside the box; uneven surface; misaligned hinges.	Remove any obstructions. Move the box to a flat, level surface. Check hinge alignment and adjust if necessary.
Difficulty during assembly.	Panels not aligned correctly; insufficient force applied; incorrect part orientation.	Refer to the assembly diagram. Ensure grooves are perfectly aligned. Apply firm, even pressure or use a rubber mallet for snug fits. Verify part orientation.

Problem	Possible Cause	Solution
Lid does not stay open.	Gas struts incorrectly installed or damaged.	Check the installation of the gas struts according to the assembly instructions. If damaged, contact customer support for replacement parts.
Water inside the box.	Lid not fully closed; seal compromised; extreme weather conditions.	Ensure the lid is fully and securely closed. Inspect the lid's sealing edges for damage. While weatherproof, in extreme conditions, consider additional cover.

## SPECIFICATIONS

**Model Number:** 17206371

**Brand:** Keter

**Material:** Durable Plastic

**Color:** Grey

**Exterior Dimensions (L x W x H):** 122.9 cm x 62.1 cm x 70.6 cm (48.4 in x 24.4 in x 27.8 in)

**Interior Dimensions (L x W x H):** Approximately 113.8 cm x 53 cm x 63.9 cm (44.8 in x 20.9 in x 25.2 in)

**Capacity:** 380 Liters (100 Gallons approx.)

**Weight:** 16.6 Kilograms (36.6 lbs)

**Special Features:** Lockable (padlock not included), Weatherproof, UV Resistant, Double-wall construction, Gas spring mechanism for easy opening.


## WARRANTY AND SUPPORT

Keter products are manufactured to high-quality standards. For specific warranty information regarding your Denali 100 Cushion Box, please refer to the warranty card included with your purchase or visit the official Keter website. For technical support, missing parts, or any inquiries, please contact Keter customer service. Contact details can typically be found on the Keter website or on the product packaging.

**Online Support:** [www.keter.com](http://www.keter.com)

## Related Documents

	<p><a href="#">Keter Denali 100 US Gal / 380L Storage Box Assembly Instructions and Care Guide</a></p> <p>Comprehensive assembly instructions and safety guidelines for the Keter Denali 100 US Gal / 380L storage box. Learn how to assemble, use, and maintain your durable outdoor storage solution.</p>
	<p><a href="#">Keter 150 US GAL   570L Outdoor Storage Box - Assembly and User Manual</a></p> <p>Comprehensive assembly instructions and user guide for the Keter 150 US GAL   570L outdoor storage box. Learn how to build, care for, and maintain your durable Keter storage solution.</p>



### [Keter 511L / 135 US GAL Outdoor Storage Box Assembly and Care Guide](#)

Comprehensive assembly instructions, features, and care guide for the Keter 511L (135 US GAL) outdoor storage box. Learn how to assemble, use, and maintain your durable Keter storage solution.



### [Keter Westwood 570L / 150 US GAL Outdoor Storage Box Assembly and Care Guide](#)

Detailed assembly instructions, safety precautions, and warranty information for the Keter Westwood 570L (150 US Gallon) outdoor storage box. Learn how to build and care for your durable resin deck box.