

Magic Sing 7539525793

Magic Sing Mariachi Spanish Song Chip Instruction Manual

Model: 7539525793

INTRODUCTION

This manual provides instructions for the Magic Sing Mariachi Spanish Song Chip. This chip expands your karaoke song library with 150 Mariachi and Spanish songs, compatible with various Magic Sing and Leadsinger karaoke microphone systems. Please read this manual carefully to ensure proper installation and use of your song chip.

PRODUCT OVERVIEW



Image: The Magic Sing Mariachi Spanish Song Chip, designed to expand your karaoke song selection.

The Mariachi Spanish Song Chip is a specialized accessory for Magic Sing and Leadsinger karaoke microphones. It contains 150 Spanish songs, primarily in the Mariachi genre, to enhance your karaoke experience. The chip is designed for easy insertion and immediate use with compatible devices, providing a seamless addition to your existing song library.

COMPATIBILITY

This song chip is compatible with the following Magic Sing and Leadsinger karaoke microphone models:

- **Magic Sing ED Series:** ED-11000, ED-8000, ED-7000, ED-6000, ED-3000, ED-9000
- **Magic Sing ET/MT Series:** ET23KH, ET31K, ET25K, ET25KHC, ET21KV, ET19KV, ET18KV, ET-18K, MT-15K, ET12000, ET13000
- **Leadsinger LS Series:** LS-2100, LS-2700, LS-3000, LS-3700

Ensure your karaoke microphone model is listed above for proper functionality. Using the chip with an incompatible model may result in non-functionality or damage.

SETUP INSTRUCTIONS

1. **Power Off:** Before inserting or removing the song chip, ensure your Magic Sing or Leadsinger karaoke microphone is completely powered off and disconnected from any power source. This prevents potential damage to the chip or the device.
2. **Locate Chip Slot:** Identify the song chip slot on your karaoke microphone. This is typically a small port designed to accept expansion chips, often found on the side or bottom of the microphone unit.
3. **Insert Chip:** Gently insert the Mariachi Spanish Song Chip into the designated slot. Ensure the chip is oriented correctly, aligning the gold contacts on the chip with the contacts in the slot. Do not force the chip; it should slide in smoothly without excessive pressure.
4. **Secure Chip:** Once fully inserted, the chip should sit securely in the slot. Some models may have a latch or cover to secure it further. Ensure it is firmly in place to maintain a stable connection.
5. **Power On:** Reconnect your karaoke microphone to its power source and power it on. The system should automatically detect the new song chip and integrate its song library.

If the chip is not detected after powering on, power off the device, carefully re-insert the chip, and power on again. If issues persist, refer to the Troubleshooting section.

OPERATING INSTRUCTIONS

1. **Accessing Songs:** After the chip is successfully installed and the microphone is powered on, navigate to the song selection menu on your karaoke system. The songs from the Mariachi Spanish Song Chip will be integrated into your existing song library or accessible via a specific category for expansion chips, depending on your microphone model.
2. **Song Search:** Use the search function on your karaoke microphone to find specific songs by title or artist. Refer to the included song list (see Song List section) for song numbers and titles to quickly locate desired tracks.
3. **Selecting and Playing:** Select your desired song from the list using your microphone's controls and follow your karaoke system's on-screen instructions to begin playback.

For detailed operation of your specific karaoke microphone model, including advanced features and settings, please refer to its primary instruction manual.

MAINTENANCE

- **Handling:** Always handle the song chip by its edges to avoid touching the gold contacts. Oils and dirt from fingers can interfere with connectivity and performance.
- **Cleaning:** If the gold contacts appear dirty or dusty, gently wipe them with a clean, dry, lint-free cloth. Do not use liquids, solvents, or abrasive materials, as these can damage the chip.

- **Storage:** Store the song chip in a dry, cool place, away from direct sunlight, high humidity, and extreme temperatures. When not in use, keep it in its original packaging or a protective case to prevent physical damage.
- **Avoid Force:** Never force the chip into or out of the slot. Excessive force can damage both the chip's connectors and the microphone's port, leading to malfunction.

Proper maintenance ensures the longevity and reliable performance of your Magic Sing Mariachi Spanish Song Chip.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Chip not detected by karaoke system.	Chip not fully inserted; dirty contacts; incompatible microphone model; system software issue.	Ensure microphone is powered off, then carefully remove and re-insert the chip firmly. Gently clean gold contacts with a dry, lint-free cloth. Verify your microphone model is listed in the Compatibility section. Restart the karaoke system.
Songs from the chip are not appearing in the song list.	Chip not recognized; song library not refreshed; incorrect menu navigation.	Confirm the chip is securely inserted. Restart the karaoke system. Consult your microphone's main manual for instructions on how to refresh the song library or navigate to expansion chip content.
Intermittent song playback or freezing.	Loose connection; dirty contacts; chip damage.	Power off the device, remove, and re-insert the chip to ensure a secure connection. Clean the gold contacts. If the problem persists, inspect the chip for visible damage.

SPECIFICATIONS

- **Item Weight:** 1.72 ounces
- **Package Dimensions:** 9.61 x 5.04 x 0.35 inches
- **Item Model Number:** 7539525793
- **Compatible Devices:** MAGIC SING KARAOKE (various ED, ET/MT series) and LEADSINGER KARAOKE (various LS series)
- **Connector Type:** 40 pins
- **Hardware Platform:** Karaoke Machine

These specifications pertain specifically to the Magic Sing Mariachi Spanish Song Chip.

SONG LIST

The Mariachi Spanish Song Chip contains 150 songs. Below are images of the song list, categorized by their starting letters, to help you identify the available tracks.

NO.	SONG TITLE	VERSION

2365	A CAMBIO DE QUE	DURANGUENSE
2366	A CHILLAR A OTRA PARTE	BALADA
2367	ABEJA MIOPE	NORTENA
2368	ABEJA REYNA	BANDA
2369	ACTOS DE UN TONTO	NORTENA
2370	ADIOS ADIOS AMOR	BALADA
2371	ADIO AMOR TE VAS	BANDA
2372	AGUA DULCE	BALADA
2373	ANGEL DE LA NOCHE	DURANGUENSE
2374	ARBOLES DE LA BARRANCA	RANCHERA
2375	ASI COMO HOY	BALADA
2376	AUNQUE ME DUELA	BANDA
2377	BARAJA DE ORO	NORTENA
2378	CAMARON PELAO	CUMBIA
2379	CATORCE ANOS NUEVE MESES	NORTENA
2380	COMO PUDE ENAMORARME DE TI	DURANGUENSE
2381	COMPARAME	BALADA
2382	CON CARTITAS Y PALABRAS	NORTENA
2383	CON TAL QUE SEAS FELIZ	BANDA
2384	CONTRA VIENTO Y MAREA	BALADA
2385	COPA TRAS COPA	DURANGUENSE
2386	CUANDO TE ACUERDES DE MI	BALADA
2387	DESCONTROLADO	BALADA
2388	DONDE ESTAS	BALADA
2389	DOS LOCOS	DURANGUENSE
2390	DUENO DE TI	BALADA
2391	ECHAME A MI LA CULPA	RANCHERA
2392	EL ADIOS RANCHERO	RANCHERA
2393	EL AMOR DE MI VIDA	BALADA
2394	EL CAMINANTE	BALADA

Image: Page 1 of the song list, displaying songs starting with letters A through E, including titles such as "A CAMBIO DE QUE" and "EL CAMINANTE".

NO.	SONG TITLE	VERSION
2395	EL PASADISCOS	RANCHERA
2396	EL PRESO DE NUEVO LEON	RANCHERA
2397	EL SOL NO REGRESA	DURANGUENSE
2398	EL SUBE BAJA	DURANGUENSE
2399	EL ULTIMO TRAGO	RANCHERA
2400	ELLA Y EL	BALADA
2401	EN REALIDAD	DURANGUENSE
2402	ENTRE COBIJAS	BALADA
2403	ERES DIVINA	BALADA
2404	ESTA LLORANDO MI CORAZON	BALADA
2405	GOLPES EN EL CORAZON	BALADA
2406	HACE UN AÑO	BANDA
2407	HAY AMOR	BANDA
2408	HAY OTRA EN TU LUGAR	DURANGUENSE
2409	HE VENIDO A PEDIRTE PERDON	DURANGUENSE
2410	HOY EMPIEZA MI TRISTEZA	BALADA
2411	HUELE A PELIGRO	BANDA
2412	JINETEANDO	RANCHERA
2413	JUAN MARTHA	RANCHERA
2414	LA BANDA EL RECODO LLEGO	BANDA
2415	LA CULPABLE	RANCHERA
2416	LA MILPA	RANCHERA
2417	LA OTRA CARA DE LA MONEDA	BALADA
2418	LA REDEQUITA	RANCHERA

2418	LA PIEDRECITA	RANCHERA
2419	LA RIQUEZA NO SIRVE	RANCHERA
2420	LA VECINITA	RANCHERA
2421	LA ZOPILOTA	RANCHERA
2422	LADRONA	BALADA
2423	LAGRIMAS DE CRISTAL	RANCHERA
2424	LAGRIMAS DE ESCARCHA	CUMBIA


SPANISH VOL. 8 150 SONGS
 E / L

Image: Page 2 of the song list, displaying songs starting with letters E through L, including titles such as "EL PASADISCOS" and "LAGRIMAS DE ESCARCHA".

NO.	SONG TITLE	VERSION
2425	LAGRIMAS Y LLUVIA	RANCHERA
2426	LAMENTO DE AMOR	BALADA
2427	LAS MANANITAS	RANCHERA
2428	LAS TRES TUMBAS	RANCHERA
2429	LASTIMA ES MI MUJER	BALADA
2430	LLORA	BALADA
2431	MACARIO LEYVA	RANCHERA
2432	MALDITO AMOR	BALADA
2433	MALDITO VENENO	BANDA
2434	MARIPOSA TRAICIONERA	DURANGUENSE
2435	ME GUSTA ESTAR CONTIGO	RANCHERA
2436	ME LLAMAS	DURANGUENSE
2437	ME VALE	BANDA
2438	METIENDO LAS PATAS	BANDA
2439	MI CREDO	DURANGUENSE
2440	MI ETERNO AMOR SECRETO	DURANGUENSE
2441	MI III AMADA	RAI ANA

NO.	SONG TITLE	VERSION
2442	MI RANCHITO	RANCHERA
2443	MI VIDA	BALADA
2444	MORENITA PIEL CANELA	BANDA
2445	MUNECA DE OJOS DE MIEL	BALADA
2446	NADIE	BALADA
2447	NADIE ES COMO TU	BALADA
2448	NECESITO UN AMOR	BALADA
2449	NO ME HA HIDO BIEN	RANCHERA
2450	NO ME QUEDA MAS	RANCHERA
2451	NO PUEDO OLVIDARTE	RANCHERA
2452	NO SE VIVIR SIN TI	BALADA
2453	NO TENGO DINERO	CUMBIA
2454	NO VOLVERE	RANCHERA
L / N SPANISH VOL. 8 150 SONGS 03 VER. 100		

Image: Page 3 of the song list, displaying songs starting with letters L through N, including titles such as "LAGRIMAS Y LLUVIA" and "NO VOLVERE".

NO.	SONG TITLE	VERSION
2455	NUNCA MAS PODRE OLVIDARTE	BALADA
2456	OBSESION	DURANGUENSE
2457	OJALA QUE TE MUERAS	BALADA
2458	OJITOS SONADORES	RANCHERA
2459	PA QUE VOLVER	RANCHERA
2460	PALOMA NEGRA	DURANGUENSE
2461	PARA QUE REGRESES	BALADA
2462	PARA QUE SEGUIR	BALADA
2463	PARECE MENTIRA	BALADA
2464	PARECE QUE BAILA	CARIBENSE

2465	PASCUAL SARMIENTO	RANCHERA
2466	PASO DEL NORTE	RANCHERA
2467	PERDON	MARIACHI
2468	POBRE BOHEMIO	RANCHERA
2469	POR MUJERES COMO TU	MARIACHI
2470	POR QUE QUERER VOLVER	RANCHERA
2471	POR UNAS MONEDAS	MARIACHI
2472	PORQUE TE FUISTE	RANCHERA
2473	QUE MAS QUISIERA	RANCHERA
2474	QUERIDA	BALADA
2475	QUIEN MAS QUE TU	BALADA
2476	QUIERO CONTIGO	BALADA
2477	QUIERO SABER DE TI	DURANGUENSE
2478	QUIDIERA SER PAJARILLO	RANCHERA
2479	PEDONDITO EN TUS BRAZOS	RANCHERA
2480	ROSAS	BALADA
2481	SABIENDO QUIEN ERA YO	RANCHERA
2482	SE ME CAYERON LAS ALAS	RANCHERA
2483	SI LA QUIERES	RANCHERA
2484	SI ME RECUERDAS	DURANGUENSE

SPANISH VOL. 8 150 SONGS **N / S**

Image: Page 4 of the song list, displaying songs starting with letters N through S, including titles such as "NUNCA MAS PODRE OLVIDARTE" and "SI ME RECUERDAS".

NO.	SONG TITLE	VERSION
2485	SI NO TE HUBIERAS IDO	BALADA
2486	SI TE VUELVES A ENAMORAR	DURANGUENSE
2487	SI TU AMOR NO VUELVE	BALADA
2488	SI TU TE FUERAS DE MI	RANCHERA

2489	SI YO FUERA EL	BALADA
2490	SI YO FERA EL LADRON	BALADA
2491	SIN SANGRE EN LAS VENAS	RANCHERA
2492	SIN TU AMOR	BALADA
2493	SOBREVIVIRE	BALADA
2494	SOLAMENTE	BALADA
2495	SOLO LOS TONTOS	DURANGUENSE
2496	SON HABLADAS	RANCHERA
2497	SUERTE HE TENIDO	RANCHERA
2498	TE DOY LAS GRACIAS	RANCHERA
2499	TE PARTO EL ALMA	BALADA
2500	TE QUIERO PARA MI	BALADA
2501	TODO LO QUE HAGO LO HAGO POR TI	BALADA
2502	TU MIRADA	RANCHERA
2503	TU SOLO TU	RANCHERA
2504	TU SOMBRA	BALADA
2505	TU YO Y LA LUNA	BALADA
2506	UNA SOLA CAIDA	RANCHERA
2507	UNA VIEJA CANCION DE AMOR	BALADA
2508	VEN CONMIGO	RANCHERA
2509	VIERNES SIN TU AMOR	BALADA
2510	VOLVERE	DURANGUENSE
2511	Y DICEN	RANCHERA
2512	Y TE VI CON EL	DURANGUENSE
2513	YO ME QUEDE SIN NADA	DURANGUENSE
2514	YO VENDO UNOS OJOS NEGROS	BALADA
S / Y		
SPANISH VOL. 8 150 SONGS 05 VER. 100		

and "YO VENDO UNOS OJOS NEGROS".

SUPPORT INFORMATION

For further assistance, technical support, or inquiries regarding your Magic Sing Mariachi Spanish Song Chip or compatible karaoke system, please visit the official Magic Sing website or contact their customer service. Refer to your primary karaoke microphone manual for specific support contact details.

Online Resources: [Magic Sing Store on Amazon](#)

© 2024 Magic Sing. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question