

iClever GK03

iClever GK03 Wireless Keyboard and Mouse Combo User Manual

Model: GK03 | Brand: iClever

1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for the iClever GK03 Wireless Keyboard and Mouse Combo, a 2.4G portable wireless solution designed for enhanced productivity and comfort. It features a full-size, slim, and thin design with stable connectivity for Windows and Mac OS systems.

Key features of your iClever GK03 combo include:

- **Wireless Keyboard & Mouse Combo:** Stainless steel & ABS construction with a 10-degree tilt for comfortable use.
- **Plug & Play and Win & Mac Compatibility:** Easy setup with a single receiver for both devices, supporting both Windows and Mac layouts.
- **Responsive & Low-Profile Keys:** Scissor key mechanism for enhanced feedback, stability, and quiet, precise typing.
- **Compact & Efficient Design:** Includes a standard numeric keypad and convenient hotkeys for improved workflow.
- **Rechargeable Keyboard:** Long-lasting battery life for extended use.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- iClever GK03 Wireless Keyboard
- Wireless Mouse
- USB Receiver (located in the mouse battery compartment)
- Charging USB Cable
- Silicone Keyboard Cover

3. SETUP INSTRUCTIONS

Follow these steps to set up your iClever GK03 Wireless Keyboard and Mouse Combo:

1. **Locate the USB Receiver:** The 2.4G USB receiver is stored conveniently on the bottom of the mouse. Gently remove the cover to access it.
2. **Connect the Receiver:** Plug the USB receiver into an available USB-A port on your computer or laptop.
3. **Power On:** Turn on the keyboard and mouse using their respective power switches. The devices should automatically connect to your computer.
4. **Initial Charge (Keyboard):** For optimal performance, it is recommended to fully charge the keyboard for 2 hours before first use.



Figure 3.1: The iClever GK03 Wireless Keyboard and Mouse Combo, showing the compact design and the USB receiver.

CRAFTSMANSHIP AT ITS DELICATE BEST



3 Adjustable DPI



3000000 Keystrokes



Figure 3.2: Illustrates the USB receiver being plugged into a laptop's USB-A port for connection.

4. OPERATING INSTRUCTIONS

Your iClever GK03 combo is designed for intuitive use across various operating systems.

4.1. Windows and Mac Compatibility

The keyboard and mouse are fully compatible with both Windows and Mac OS systems. You can switch between Windows and Mac layouts by pressing the **Fn+Q** (for Mac) or **Fn+W** (for Windows) keys. The keyboard automatically adjusts its layout to match the selected operating system.

FOR MAC AND WINDOWS



Figure 4.1: Demonstrates the keyboard's compatibility with both Mac and Windows operating systems, highlighting the Fn+Q/W key combinations.

4.2. Hotkeys and Functionality


The keyboard includes various hotkeys and an Fn lock feature to enhance your productivity. These include media control keys (Mute, Volume up/down) and other shortcuts. Refer to the keyboard's keycap legends for specific functions.

4.3. Low-Profile Keys and Typing Experience

The keyboard features a scissor key mechanism that provides enhanced feedback and stability. The optimized key-travel and anti-slip tapes contribute to a comfortable, quiet, and precise typing experience.

LOW PROFILE KEYS

Thanks to their low profile and scissor switch design, these keys guarantee quiet, comfortable typing



SCISSOR SWITCH



Figure 4.2: A close-up view of the keyboard's low-profile keys, illustrating the scissor switch design for quiet and comfortable typing.

4.4. Mouse DPI Adjustment

The mouse offers adjustable DPI (Dots Per Inch) settings to customize cursor sensitivity. You can cycle through different DPI levels (e.g., 800, 1200, 1600 DPI) by pressing the DPI button, usually located near the scroll wheel.

ULTRA SLIM DESIGN




Figure 4.3: Shows the iClever mouse and its adjustable DPI settings, allowing users to select their preferred cursor speed.

5. COMPATIBILITY NOTES

The iClever GK03 Wireless Keyboard and Mouse Combo uses a 2.4Ghz USB wireless connection via a USB-A receiver. Please note the following compatibility details, especially for Mac devices:

- The USB receiver requires a standard USB-A port.
- **Compatible Mac Devices:** iMac 21.5 (Intel, 2017, 2019), iMac Pro (Intel, 2017), Mac mini (M2 or M2 Pro), Mac mini (Intel, 2018), Mac mini (M1, 2020).
- **Not Compatible (Directly):** MacBook Air/Pro, iMac (M1, Two ports), iMac (M1, four ports), Mac Pro (Intel, 2019), Mac Pro, Mac Studio.
- **USB-C Port Devices:** For Mac devices with only USB-C ports, a hub/extender or a USB-A to USB-C adapter is required to connect the USB receiver.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your iClever GK03 combo:

6.1. Charging the Keyboard

The keyboard is rechargeable. Connect the provided USB charging cable to the keyboard's charging port and a power source. A full charge typically takes 2 hours and can provide up to 90 days of standby time. Low battery power can affect connectivity and functionality, so ensure the keyboard is charged regularly.

ENERGY SAVING AND ENVIRONMENTALLY FRIENDLY



Lithium Battery Capacity
280 mAh



Charge time: **<2 hours**
Stand- by time: **90 days**



Figure 6.1: Details the keyboard's charging process and its impressive battery life, indicating a 2-hour charge for 90 days of standby.

6.2. Mouse Batteries

The mouse is not rechargeable and requires 2 AAA batteries (not included). Replace them when the mouse performance degrades.

6.3. Cleaning and Protection

A silicone cover is attached for key protection. Use it to keep your keyboard clean and free from dust and spills. Regularly wipe down the keyboard and mouse with a soft, dry cloth.

6.4. Power Saving

Both the mouse and keyboard are designed to enter a sleep mode after a period of inactivity to conserve battery life. To wake the mouse, simply right-click. The keyboard will wake upon pressing any key.

7. TROUBLESHOOTING

If you encounter issues with your iClever GK03 combo, refer to the following common troubleshooting steps:

7.1. Keyboard/Mouse Not Working Correctly

- **Charge the Keyboard:** Ensure the keyboard is fully charged (2 hours).
- **Check Connection:** Verify that the USB receiver is plugged directly into the computer's USB-A port, not through a hub, extender, or switch.
- **Re-pair/Reconnect:** Try unpairing and re-pairing the devices, or simply disconnecting and reconnecting the USB receiver.
- **Try Different Port/Computer:** Test the combo on a different USB port or another computer to isolate the issue.

7.2. Delay When Typing

- **Restart Computer:** A simple restart can often resolve connectivity issues.
- **Charge Keyboard:** Low battery power can cause delays. Ensure the keyboard is charged.
- **Direct Connection:** Confirm the receiver is connected directly to the computer, not via an intermediary device.
- **Proximity to Receiver:** Move the keyboard closer to the USB receiver. If the receiver is in the back of your computer, try relocating it to a front port to avoid signal blockage.
- **Minimize Interference:** Keep other electrical wireless devices away from the USB receiver to prevent signal interference.
- **Check Background Processes:** Ensure no heavy updates or background processes are consuming system resources, which might cause input delays.

7.3. Cannot Find the USB Receiver

The USB receiver for both the keyboard and mouse is located on the bottom of the mouse. You can access it by removing the cover. Only one USB receiver is included for both devices.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	14.37 x 4.92 x 0.43 inches
Item Weight	14.9 ounces
Model Number	GK03
Keyboard Battery	1 Lithium Ion battery (included, rechargeable)
Mouse Battery	2 AAA batteries (not included)
Connectivity Technology	2.4Ghz Wireless USB (USB-A port required)
Color	Silver
Manufacturer	HisgadgetInc
Compatible Devices	PC, Laptop, iMac (specific models, see Compatibility Notes)

9. WARRANTY AND SUPPORT

The iClever GK03 Wireless Keyboard and Mouse Combo comes with a 1-year limited hardware warranty. For warranty claims or technical support, please contact iClever customer service.

You may also find additional support and information, including a PDF version of the user manual, on the official iClever website or through the retailer's support channels. The user manual PDF can be accessed [here](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question