

[Manuals.plus](#) /

› [The Learning Journey](#) /

› The Learning Journey Techno Gears Dizzy Droid Instruction Manual

The Learning Journey 188712

Techno Gears Dizzy Droid Instruction Manual

Model: 188712

Brand: The Learning Journey

1. INTRODUCTION

The Techno Gears Dizzy Droid is a construction set designed to introduce users to fundamental engineering and mechanics principles through hands-on building. This set allows for the assembly of a motorized droid featuring rotating gears and continuous tracks, providing an engaging experience in STEM learning.



Figure 1.1: Fully assembled Techno Gears Dizzy Droid.

2. SAFETY INFORMATION

- **WARNING: CHOKING HAZARD** – Small parts. Not for children under 3 years.
- All components of this product are regularly safety tested and comply with domestic and international toy safety regulations.
- Adult supervision is recommended during assembly and play, especially for younger children within the recommended age range.
- Do not ingest any parts.

3. PACKAGE CONTENTS

Your Techno Gears Dizzy Droid set includes over 60 brightly colored pieces necessary for construction. Please verify that all components are present before beginning assembly.

- Interlocking plates
- Various gears
- 3-D connectors
- Continuous track segments
- Motorized power unit
- Detailed step-by-step instruction manual



Figure 3.1: Product packaging indicating 60+ pieces included.

4. SETUP AND ASSEMBLY

Follow the detailed step-by-step instruction manual included in your package to assemble the Dizzy Droid. Ensure each piece is securely connected as indicated in the diagrams.

4.1 Battery Installation

1. Locate the battery compartment on the motorized power unit.
2. Using a small Phillips head screwdriver (not included), open the battery compartment cover.
3. Insert two (2) AA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Note: Always use fresh batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

Your browser does not support the video tag.

Video 4.1: An overview of the Dizzy Droid's features and assembly process. This video demonstrates how the various components fit together to form the complete droid.

5. OPERATING INSTRUCTIONS

Once assembled and batteries are installed, the Dizzy Droid is ready for operation.

1. Locate the ON/OFF switch on the motorized power unit.
2. Flip the switch to the 'ON' position to activate the droid.
3. Observe as the Dizzy Droid moves across a flat surface, with its continuous tracks propelling it forward.

4. The droid's head will rotate, and the interconnected gears will spin, demonstrating mechanical motion.
5. To stop the droid, flip the switch back to the 'OFF' position.



Figure 5.1: Detail of the continuous tracks in motion.



Figure 5.2: Detail of the rotating gears.

Your browser does not support the video tag.

Video 5.1: Demonstration of the Dizzy Droid in operation, showcasing its movement and rotating parts.

6. MAINTENANCE

- **Cleaning:** Wipe the surface of the Dizzy Droid with a soft, damp cloth. Do not immerse the motorized unit in water.
- **Storage:** Store the assembled or disassembled set in a cool, dry place away from direct sunlight to prevent material degradation.
- **Battery Care:** Remove batteries from the motorized unit if the toy will not be used for an extended period to prevent leakage and damage.

7. TROUBLESHOOTING

- **Droid does not move:**
 - Ensure batteries are correctly installed and are not depleted.

- Check that the ON/OFF switch is in the 'ON' position.
- Verify that all gears and connectors are properly aligned and securely attached, allowing for free movement.

- **Parts do not connect securely:**

- Refer to the instruction manual to ensure the correct pieces are being used for each step.
- Avoid excessive force when connecting pieces, as this can damage the connectors.

- **Movement is erratic or sluggish:**

- Check for any obstructions in the gears or tracks.
- Ensure the droid is operating on a flat, smooth surface.
- Replace batteries if they are low.

8. SPECIFICATIONS

Model Number	188712
Product Dimensions	11.5 x 3 x 10.5 inches
Item Weight	1.1 pounds
Recommended Age	6 - 12 years
Batteries Required	2 AA batteries (not included)
Manufacturer	The Learning Journey International
Release Date	February 1, 2018

9. SUPPORT

For further assistance, replacement parts, or inquiries not covered in this manual, please refer to the contact information provided in the original product packaging. You may also visit The Learning Journey International website for additional resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question