

Amazon Echo Input

Amazon Echo Input User Manual

Model: Echo Input

INTRODUCTION

The Amazon Echo Input is a compact device designed to bring the power of Alexa to your existing speaker system. It connects to your speaker via a 3.5 mm audio cable or Bluetooth, allowing you to stream music, get information, control smart home devices, and more, all using your voice.

WHAT'S IN THE BOX

- Echo Input device
- Power adapter
- 3.5 mm audio cable
- Quick Start Guide (not included in this manual)

SETUP


1. Connect to Power

Plug the included power adapter into the Echo Input and then into a wall outlet. The light ring on the Echo Input will illuminate.

2. Connect to Your Speaker

You have two options to connect the Echo Input to your speaker:

1. **Using the 3.5 mm Audio Cable:** Connect one end of the included 3.5 mm audio cable to the Echo Input's audio output port and the other end to your speaker's auxiliary input port.
2. **Using Bluetooth:**
 - a. Ensure your speaker is in Bluetooth pairing mode.
 - b. Open the Alexa app on your mobile device.
 - c. Go to *Devices > Echo & Alexa > [Your Echo Input Name] > Bluetooth Devices > Pair a New Device*.
 - d. Select your speaker from the list of available devices.



Connect to a speaker via AUX or Bluetooth

Image: The Echo Input connected to a speaker, demonstrating both AUX and Bluetooth connection options. The device is small and discreet, fitting easily into a home setup.

3. Set up with the Alexa App

Download the Amazon Alexa app from your device's app store. Follow the on-screen instructions to connect your Echo Input to your Wi-Fi network and complete the setup process. This is essential for Alexa functionality.

OPERATING THE ECHO INPUT

Once set up, the Echo Input is ready to respond to your voice commands. Simply say "Alexa" followed by your request.


Voice Commands and Capabilities

- **Music and Audio:** "Alexa, play music by [artist/genre]," "Alexa, play [song title]," "Alexa, stream [radio station]," "Alexa, play my [playlist name]." The Echo Input supports streaming from Amazon Music, Apple Music, Spotify, Pandora, SiriusXM, and more.
- **Information:** "Alexa, what's the weather like today?" "Alexa, tell me the news," "Alexa, what's the traffic like?"

- **Productivity:** "Alexa, set a timer for 10 minutes," "Alexa, set an alarm for 7 AM," "Alexa, add milk to my shopping list."
- **Smart Home Control:** "Alexa, turn on the lights," "Alexa, set the thermostat to 72 degrees." (Requires compatible smart home devices and setup in the Alexa app).



Image: A user interacting with the Echo Input, demonstrating a common voice command for music playback. The device is shown discreetly placed on a wooden surface.



Ask for info, news,
weather, and more

Image: The Echo Input is shown on a table, illustrating its use for general information queries such as news, weather, and more.

Microphone Control

The Echo Input features a microphone off button for privacy. Pressing this button electronically disconnects the microphones, preventing the device from listening for the wake word or recording audio. The light ring will change color to indicate the microphones are off.



Press the mic off button to disconnect the microphones

Image: A close-up view of the Echo Input, highlighting the microphone off button. Pressing this button ensures privacy by electronically disconnecting the microphones.

MAINTENANCE

To ensure the longevity and optimal performance of your Echo Input, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the exterior of the device. Do not use abrasive cleaners, solvents, or aerosol sprays.
- **Placement:** Place the Echo Input on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture. Ensure it has adequate ventilation.
- **Handling:** Handle the device with care. Avoid dropping it or subjecting it to strong impacts.

TROUBLESHOOTING

If you encounter issues with your Echo Input, try the following troubleshooting steps:

- **No Sound from Speaker:**

- Ensure the Echo Input is properly connected to your speaker via AUX cable or Bluetooth.
- Check the volume levels on both your speaker and within the Alexa app.
- Verify that your speaker is powered on and set to the correct input source (AUX or Bluetooth).

• **Alexa Not Responding:**

- Check if the microphone is muted (red light ring). Press the microphone button to unmute.
- Ensure the Echo Input is connected to Wi-Fi. Check the network status in the Alexa app.
- Try repositioning the Echo Input closer to your Wi-Fi router or away from interference.
- Restart the device by unplugging it from power for a few seconds and then plugging it back in.

• **Bluetooth Connectivity Issues:**

- Ensure your speaker is in pairing mode.
- Forget the Echo Input from your speaker's Bluetooth settings and re-pair.
- Note: Calling and Drop In via Bluetooth are currently not supported on the Echo Input.

• **Poor Voice Recognition:**

- Speak clearly and at a normal volume.
- Ensure there is no excessive background noise.
- Position the Echo Input in an open area, away from walls or other obstructions that might block the microphones.

SPECIFICATIONS

Model Name	Echo Input
Connectivity	3.5 mm audio output, Bluetooth
Microphones	Multiple (4 microphones for far-field voice recognition)
Dimensions	Slim, low-profile design (exact dimensions not provided in source, but described as compact)
Power	Included power adapter



Image: A detailed view of the Echo Input, showcasing its compact and minimalist design, which allows it to fit almost anywhere.



Slim design fits
almost anywhere

Image: The Echo Input's slim design allows it to be placed discreetly in various locations, such as on a side table, blending into the home environment.

WARRANTY AND SUPPORT

For information regarding the warranty of your Amazon Echo Input, please refer to the warranty card included with your product or visit the official Amazon support website. For technical support, frequently asked questions, and additional resources, please visit the Amazon Devices Support page.

Note: Specific warranty terms and support contact details may vary by region and purchase date.

