

[manuals.plus](#) /

› [WMF](#) /

› [WMF Kult X Edition Food Chopper Instruction Manual](#)

WMF 0416590011

WMF Kult X Edition Food Chopper Instruction Manual

Model: 0416590011 | Brand: WMF

1. INTRODUCTION

Thank you for choosing the WMF Kult X Edition Food Chopper. This appliance is designed for efficient and quick chopping of various food items. With its powerful 320W motor, 1-liter glass container, and two speed settings, it simplifies food preparation tasks. Please read this instruction manual carefully before first use to ensure safe operation and optimal performance of your appliance. Keep this manual for future reference.



Figure 1.1: Fully assembled WMF Kult X Edition Food Chopper.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not immerse the motor unit in water or other liquids.
- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts. The blades are very sharp; handle with extreme care during assembly, disassembly, and cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction

concerning use of the appliance by a person responsible for their safety.

- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Ensure the lid is securely locked in place before operating the appliance.
- Do not process hot liquids or very hard ingredients like coffee beans or ice cubes, as this may damage the blades or motor.

3. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the parts of your WMF Kult X Edition Food Chopper:

1. **Motor Unit:** Contains the powerful 320W motor and control buttons.
2. **Lid:** Secures the motor unit to the glass container.
3. **Blade Assembly:** Sharp stainless steel blades for chopping.
4. **Glass Container:** 1-liter capacity bowl for ingredients, with measurement markings.



Figure 3.1: Food Chopper showing the 'MAX' and '0.5 l' measurement lines on the glass container.



Figure 3.2: Close-up view of the sharp stainless steel blade assembly.



Figure 3.3: The durable 1-liter glass container.

4. SETUP

Before first use, wash all parts that will come into contact with food (glass container, blade assembly, lid) according to the cleaning instructions. Ensure all parts are completely dry before assembly.

1. Place the glass container on a stable, flat surface.
2. Carefully place the blade assembly onto the central pin inside the glass container. Ensure it sits securely.
3. Add your ingredients to the glass container. Do not exceed the 'MAX' fill line indicated on the container.
4. Place the lid onto the glass container, ensuring it aligns correctly with the container's rim.
5. Position the motor unit onto the lid. It should fit snugly and lock into place, activating the safety interlock.
6. Plug the power cord into a suitable electrical outlet.

5. OPERATING INSTRUCTIONS

The WMF Kult X Edition Food Chopper features two speed settings for versatile chopping.



Figure 5.1: Top view of the motor unit showing the two speed control buttons.

1. Ensure the appliance is correctly assembled and plugged in.
2. **Speed I (Gentle):** Press and hold the button marked with a single line (I) for a slower, more controlled chop, ideal for softer ingredients or coarser results.
3. **Speed II (Powerful):** Press and hold the button marked with a double line (II) for a faster, more powerful chop, suitable for harder ingredients or finer results.
4. Pulse operation: For best results and to prevent over-processing, use short pulses by pressing and releasing the desired speed button repeatedly.
5. Once chopping is complete, release the button and unplug the appliance from the power outlet.
6. Carefully remove the motor unit, then the lid, and finally the blade assembly before emptying the chopped ingredients.

Tips for Best Results:

- Cut larger ingredients into smaller, uniform pieces (approx. 1-2 cm) before placing them in the container.
- Do not overload the container. Process in smaller batches if necessary.
- For ingredients like herbs or garlic, add a small amount of liquid (water or oil) to help them circulate and chop evenly.



Figure 5.2: The food chopper in action, processing onions.

6. MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your appliance. Always unplug the chopper before cleaning.

- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
- **Glass Container, Lid, and Blade Assembly:** These parts are recommended for **hand wash** only. Wash them in warm, soapy water immediately after use to prevent food residue from drying. Rinse thoroughly and dry completely before storing.
- **Caution:** The blades are extremely sharp. Handle the blade assembly with extreme care during cleaning to avoid injury.
- Store the appliance in a dry place, out of reach of children.

7. TROUBLESHOOTING

If you encounter issues with your WMF Kult X Edition Food Chopper, refer to the following common problems and solutions:

- **Appliance does not turn on:**

- Ensure the power cord is securely plugged into a working outlet.
- Check that the motor unit is correctly seated and locked onto the lid, and the lid is properly placed on the glass container. The appliance has a safety interlock system.

- **Ingredients are not chopping evenly:**

- Ensure ingredients are cut into uniform, smaller pieces before processing.
- Do not overload the container. Reduce the quantity of ingredients.
- Use the pulse function (short bursts) to allow ingredients to settle between pulses.

- **Motor sounds strained or stops:**

- The container might be overloaded. Remove some ingredients.
- Ingredients might be too hard. Avoid processing extremely hard items like ice or frozen foods.
- Unplug the appliance and let the motor cool down for a few minutes before resuming operation.

- **Leakage from the container:**

- Ensure the lid is properly sealed onto the glass container.
- Do not overfill the container beyond the 'MAX' line.

If the problem persists after trying these solutions, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions	6.1 x 7.68 x 8.46 inches
Item Weight	3.72 pounds
Model Number	0416590011

Brand	WMF
Power	320W
Container Capacity	1 Liter
Product Care Instructions	Hand Wash


9. WARRANTY AND SUPPORT

WMF products are manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official WMF website. For technical support, spare parts, or service inquiries, please contact WMF customer service through their official channels. You can often find contact information on the WMF official website or on the product packaging.

© 2025 WMF. All rights reserved.

Related Documents - 0416590011

 WMF Multihacker Multihacker Bedienungs- und Pflegemanual Multihacker Instructions for use and care Multihacker Instructions d'utilisation et d'entretien Multihacker Instrucciones de manejo y cuidado Multihacker Instruções para fazer o manuseio 多用途工具 多用途工具	<p>WMF Multihacker: Instructions for Use, Care, and Safety</p> <p>User manual for the WMF Multihacker, providing detailed instructions on safe operation, usage tips, cleaning procedures, and storage guidelines for this versatile kitchen appliance. Includes multilingual guidance.</p>
 WMF Stelio WMF Stelio DE Bedienungsanleitung DE Bedienungsanleitung EN Operating Manual EN Operating Manual FR Mode d'emploi FR Mode d'emploi ES Instrucciones de uso ES Instrucciones de uso IT Istruzioni per l'uso IT Istruzioni per l'uso NL Gebruiksaanwijzing NL Gebruiksaanwijzing	<p>WMF Stelio Coffee Grinder Edition - Operating Manual</p> <p>This document provides operating instructions, safety guidelines, and maintenance information for the WMF Stelio Coffee Grinder Edition.</p>
 WMF Kult Pro WMF Kult Pro DE Bedienungsanleitung 1,8 L DE Bedienungsanleitung 1,8 L EN Operating Manual 1,8 L EN Operating Manual 1,8 L FR Mode d'emploi 1,8 L FR Mode d'emploi 1,8 L ES Instrucciones de uso 1,8 L ES Instrucciones de uso 1,8 L IT Istruzioni per l'uso 1,8 L IT Istruzioni per l'uso 1,8 L NL Gebruiksaanwijzing 1,8 L	<p>WMF Kult Pro Table Blender 1.8L - Operating Manual</p> <p>Comprehensive operating manual for the WMF Kult Pro Table Blender (1.8L), covering safety instructions, usage, components, programs, technical data, and cleaning.</p>

 <p>KULT X Mix it Go, Mix it Go Duo, Mix it Go Duo Edition, Mix it Go Keep Cool</p> <p>DE 1 Gehäusemontierung DE 18 Gehäuseentmontierung DE 2 Gehäusemontierung DE 29 Gehäuseentmontierung DE 3 Gehäusemontierung DE 30 Gehäuseentmontierung DE 4 Gehäusemontierung DE 10 Gehäusemontierung DE 11 Gehäusemontierung DE 12 Gehäusemontierung DE 13 Gehäusemontierung DE 14 Gehäusemontierung DE 15 Gehäusemontierung DE 16 Gehäusemontierung DE 17 Gehäusemontierung DE 18 Gehäusemontierung DE 19 Gehäusemontierung DE 20 Gehäusemontierung DE 21 Gehäusemontierung DE 22 Gehäusemontierung DE 23 Gehäusemontierung DE 24 Gehäusemontierung DE 25 Gehäusemontierung DE 26 Gehäusemontierung DE 27 Gehäusemontierung DE 28 Gehäusemontierung DE 29 Gehäusemontierung DE 30 Gehäusemontierung DE 31 Gehäusemontierung DE 32 Gehäusemontierung DE 33 Gehäusemontierung DE 34 Gehäusemontierung</p>	<p>WMF KULT X Mix & Go Blender User Manual</p> <p>This document provides comprehensive instructions for the WMF KULT X Mix & Go blender, covering safe operation, assembly, cleaning, and maintenance. It details the features of various models including Mix & Go, Mix & Go Duo, and Mix & Go Keep Cool.</p>
 <p>KULT X Mix it Go, Mix it Go Duo, Mix it Go Duo Edition, Mix it Go Keep Cool</p> <p>DE 1 Gehäusemontierung DE 18 Gehäuseentmontierung DE 2 Gehäusemontierung DE 29 Gehäuseentmontierung DE 3 Gehäusemontierung DE 30 Gehäuseentmontierung DE 4 Gehäusemontierung DE 10 Gehäusemontierung DE 11 Gehäusemontierung DE 12 Gehäusemontierung DE 13 Gehäusemontierung DE 14 Gehäusemontierung DE 15 Gehäusemontierung DE 16 Gehäusemontierung DE 17 Gehäusemontierung DE 18 Gehäusemontierung DE 19 Gehäusemontierung DE 20 Gehäusemontierung DE 21 Gehäusemontierung DE 22 Gehäusemontierung DE 23 Gehäusemontierung DE 24 Gehäusemontierung DE 25 Gehäusemontierung DE 26 Gehäusemontierung DE 27 Gehäusemontierung DE 28 Gehäusemontierung DE 29 Gehäusemontierung DE 30 Gehäusemontierung DE 31 Gehäusemontierung DE 32 Gehäusemontierung DE 33 Gehäusemontierung DE 34 Gehäusemontierung</p>	<p>WMF KULT X Mix & Go Blender User Manual</p> <p>Comprehensive user manual for the WMF KULT X Mix & Go blender, covering safety instructions, operation, cleaning, and maintenance for various models including Mix & Go, Mix & Go Duo, and Mix & Go Keep Cool.</p>
 <p>WMF Kult X</p> <p>DE Gehäusemontierung DE 1 Gehäusemontierung DE 14 Gehäusemontierung DE 2 Gehäusemontierung DE 24 Gehäusemontierung DE 3 Gehäusemontierung DE 30 Gehäusemontierung DE 4 Gehäusemontierung DE 10 Gehäusemontierung DE 11 Gehäusemontierung DE 12 Gehäusemontierung DE 13 Gehäusemontierung DE 14 Gehäusemontierung DE 15 Gehäusemontierung DE 16 Gehäusemontierung DE 17 Gehäusemontierung DE 18 Gehäusemontierung DE 19 Gehäusemontierung DE 20 Gehäusemontierung DE 21 Gehäusemontierung DE 22 Gehäusemontierung DE 23 Gehäusemontierung DE 25 Gehäusemontierung DE 26 Gehäusemontierung DE 27 Gehäusemontierung DE 28 Gehäusemontierung DE 29 Gehäusemontierung DE 31 Gehäusemontierung DE 32 Gehäusemontierung DE 33 Gehäusemontierung DE 34 Gehäusemontierung</p>	<p>WMF Kult X Induktionskochfeld Gebrauchsanweisung</p> <p>Umfassende Bedienungsanleitung für das WMF Kult X Induktionskochfeld. Erfahren Sie alles über Sicherheit, Bedienung, Reinigung und Fehlerbehebung für Ihr Kochgerät.</p>