

[Manuals.plus](#) /

› [TOSING](#) /

› TOSING 008 Wireless Bluetooth Karaoke Microphone User Manual

TOSING 008-1

TOSING 008 Wireless Bluetooth Karaoke Microphone User Manual

Model: 008-1

1. INTRODUCTION

Thank you for choosing the TOSING 008 Wireless Bluetooth Karaoke Microphone. This device is a versatile 3-in-1 portable handheld microphone that combines a microphone, Bluetooth speaker, and karaoke machine. It is designed to provide an enjoyable audio experience for various activities, including KTV singing, family gatherings, travel, and more. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.





Figure 1: TOSING 008 Wireless Bluetooth Karaoke Microphone. This image displays the main product, a sleek black handheld microphone with integrated speakers and control buttons on the handle.

2. PRODUCT OVERVIEW

2.1 Key Features

- **3-in-1 Functionality:** Combines a wireless microphone, Bluetooth speaker, and karaoke machine.
- **Dual Speakers:** Equipped with two high-performance speakers for a crystal-clear stereo sound experience.
- **KTV Echo Effect:** Advanced chipset provides stunning KTV live-sound with echo reverberation.
- **Advanced Technology:** Features an aluminum-magnesium alloy shell, professional tuning system, three-layer high-density noise reduction, intelligent mixing chip, and professional audio processor.
- **Wide Compatibility:** Connects wirelessly via Bluetooth 4.2 or via a 3.5mm audio cable to various devices including iPhones, Android phones, iPads, and PCs.
- **Long Battery Life:** Up to 8 hours of singing time with volume set to 2/3 of maximum playing volume.

2.2 Components and Controls

Familiarize yourself with the various parts and controls of your TOSING 008 microphone:

Double Speakers, More Powerful

10W high-performance drivers delivers a crystal-clear stereo sound experience



Figure 2: Dual Speakers for Powerful Sound. This image highlights the two integrated speakers on either side of the microphone's body, emphasizing their 10W high-performance drivers for stereo sound.



Figure 3: Bottom View with Ports. This image shows the bottom section of the microphone's control panel, revealing the 3.5mm headphone jack, SD card slot, and USB charging port.

- **Power Button:** Press and hold to turn on/off. Short press to switch modes.
- **Volume Controls (+/-):** Adjust the speaker volume.
- **Microphone Volume Controls (+/-):** Adjust the microphone input volume.
- **Echo Controls (+/-):** Adjust the echo effect level.
- **Previous/Next Track:** Skip between songs when playing music.
- **Play/Pause:** Control music playback.
- **Original Voice Elimination:** Button to remove original vocals from a song, leaving only the accompaniment.
- **3.5mm Audio Jack:** For wired connection to devices or headphones.
- **USB Charging Port:** For charging the internal battery.
- **SD Card Slot:** For playing music directly from an SD card.

3. SETUP

3.1 Charging the Microphone

Before first use, fully charge the microphone. The device includes a Lithium Ion battery.

1. Connect the provided USB charging cable to the microphone's USB charging port.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off, depending on the model.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the device powers on and you hear an audible prompt.
- **To Power Off:** Press and hold the Power button until the device powers off.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Connection

The TOSING 008 uses Bluetooth 4.2 for wireless connectivity.

Wireless Speaker

With bluetooth capability allows for wireless music sharing and operation rang up to **33FEET**



Aux-In-Stereo

Play music through bluetooth or with a 3.5mm audio cable from these compatible devices



Figure 4: Wireless Bluetooth and Aux-in Stereo Connectivity. This image illustrates the microphone's ability to connect wirelessly via Bluetooth 4.2 to a smartphone and wired via a 3.5mm audio cable to various devices like computers and tablets.

1. Ensure the microphone is powered on. It will automatically enter Bluetooth pairing mode, indicated by a flashing light or audible prompt.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "TOSING 008" (or similar name) from the list.
4. Once connected, you will hear a confirmation sound. You can now play music from your device through the microphone's speakers and use the microphone for singing.

4.2 Wired Connection (Aux-In)

For devices without Bluetooth or for a stable wired connection, use the 3.5mm audio cable.

1. Connect one end of a 3.5mm audio cable (not included) to the microphone's 3.5mm audio jack.
2. Connect the other end to the headphone jack or audio output of your device (e.g., computer, tablet).
3. The microphone will automatically switch to Aux-In mode.

4.3 Karaoke Mode

Once connected via Bluetooth or Aux-In, you can use the microphone for karaoke.



Figure 5: Full Compatibility with Music Apps. This image shows the microphone alongside a tablet and smartphone displaying various music and karaoke applications, indicating broad software compatibility.

- Play your desired karaoke track from your connected device or an SD card.
- Adjust the music volume using the microphone's volume controls.
- Adjust your microphone's vocal volume and echo effect using the dedicated controls for a personalized singing experience.
- Use the "Original Voice Elimination" button to reduce or remove the lead vocals from a song, allowing you to sing along with the instrumental track.

4.4 Using as a Bluetooth Speaker

The TOSING 008 can also function as a standalone Bluetooth speaker.

- Connect your device via Bluetooth as described in section 4.1.
- Play music from your device. The audio will be output through the microphone's dual speakers.
- Adjust the music volume using the microphone's volume controls or your connected device.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the microphone's surface. Do not use abrasive cleaners or solvents.
- **Storage:** Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Avoid Moisture:** Keep the device away from water and high humidity to prevent damage to internal components.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Microphone does not power on.	Battery is depleted.	Charge the microphone for at least 2-3 hours.
No sound from speakers.	Volume is too low; Device not connected; Incorrect mode.	Increase volume; Ensure Bluetooth or Aux-In is properly connected; Check if the microphone is in the correct operating mode.
Bluetooth connection fails.	Microphone not in pairing mode; Device Bluetooth off; Interference.	Restart microphone and try pairing again; Ensure Bluetooth is enabled on your device; Move closer to the microphone; Disconnect other Bluetooth devices.
Poor sound quality/distortion.	Volume too high; Low battery; Interference.	Reduce volume; Charge the microphone; Move away from sources of interference.
Echo effect not working.	Echo level set to minimum.	Increase the echo level using the dedicated controls.

7. SPECIFICATIONS

Feature	Detail
Model	008-1
Power Source	Battery Powered (1 Lithium Ion battery included)
Material	Metal, PVC
Signal to Noise Ratio	80 dB
Number of Channels	2
Frequency Range	50-15000 Hz
Speakers Maximum Output Power	10 Watts

Feature	Detail
Connectivity Technology	Bluetooth 4.2
Connector Type	3.5 mm Jack
Audio Sensitivity	115 dB
Microphone Form Factor	Handheld
Product Dimensions	24.7 x 7.4 x 7.05 cm; 544 g

8. WARRANTY AND SUPPORT

The TOSING 008 Wireless Bluetooth Karaoke Microphone comes with a **1-year product guarantee**. If you encounter any issues or have questions regarding your product, please refer to the troubleshooting section of this manual. For further assistance, contact TOSING customer support through the retailer's platform or the official TOSING website. Please retain your proof of purchase for warranty claims.

