**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Dyson Dyson Pure Cool Link DP01

# Dyson Pure Cool Purifying Fan DP04 User Manual

Model: Dyson Pure Cool Link DP01

## 1. Introduction

Thank you for choosing the Dyson Pure Cool Purifying Fan DP04. This advanced appliance is designed to sense pollution and allergens, capture them within a sealed HEPA and activated carbon filter, and project purified air throughout your room. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device.




Figure 1.1: Front view of the Dyson Pure Cool Purifying Fan DP04.

## 2. Safety Information

Please read all safety instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the appliance before cleaning or performing any maintenance.
- Do not use outdoors or on wet surfaces.
- Keep out of reach of children.
- Do not operate with a damaged cord or plug.

- Ensure the appliance is placed on a stable, level surface.

## 3. Package Contents

Verify that all items are present in your package:

- Dyson Pure Cool Purifying Fan DP04 unit
- Remote control
- HEPA and Activated Carbon filter set
- Power cord
- User manual (this document)




Figure 3.1: Side view of the Dyson Pure Cool Purifying Fan DP04.

## 4. Setup

Follow these steps to set up your Dyson Pure Cool Purifying Fan:

1. Unpack the unit and all components from the box.
2. Place the unit on a firm, level surface, ensuring adequate space around it for optimal airflow.
3. Install the HEPA and Activated Carbon filters. Refer to the 'Maintenance' section for detailed filter installation instructions.
4. Connect the power cord to the unit and then plug it into a suitable wall outlet.

### 4.1. Initial Setup and Filter Installation Overview

Your browser does not support the video tag.

Video 4.1: This video provides an overview of the Dyson Pure Cool DP04, including aspects of its setup and operation. It demonstrates the unit's features and how it purifies air.

## 5. Operating Instructions

Your Dyson Pure Cool Purifying Fan offers various modes and features for optimal air purification and cooling.

### 5.1. Power On/Off

Press the power button on the unit or the remote control to turn the appliance on or off.

### 5.2. Modes and Settings

- **Purifying Fan Mode:** The unit senses pollution and allergens, captures them in its sealed filter system, and projects purified air.
- **Oscillation:** Activate oscillation to distribute purified air throughout the room.
- **Night Mode:** For lighter sleepers, night-time mode activates quiet settings and dims the display automatically.

### 5.3. Connectivity and Voice Control

- **WiFi Connected:** Use the Dyson Link app to see real-time reports, remotely control your machine, and create schedules.
- **Voice Control:** The unit supports voice control for convenient operation. Refer to the Dyson Link app for compatible voice assistants and setup instructions.

## 6. Maintenance

Regular maintenance ensures optimal performance and longevity of your Dyson Pure Cool Purifying Fan.

### 6.1. Filter Replacement

The HEPA and Activated Carbon filters should be replaced periodically, typically every 6-12 months, depending on usage and air quality. The Dyson Link app will notify you when filter replacement is needed.

1. Unplug the appliance from the power outlet.
2. Press the release buttons on either side of the filter cover and remove the cover.
3. Carefully remove the old filters.
4. Unpack the new filters and insert them into the unit, ensuring they click securely into place.
5. Replace the filter cover, ensuring it is properly aligned and secured.
6. Plug the appliance back in.




Figure 6.1: Illustration of the Dyson Pure Cool filter components, showing how air passes through for purification.

### 6.2. Cleaning

Wipe the exterior of the appliance with a soft, dry cloth. Do not use detergents or polishes. Do not immerse the appliance in water.

## 7. Troubleshooting

If you encounter issues with your Dyson Pure Cool Purifying Fan, refer to the table below for common problems and solutions.

| Problem | Possible Cause | Solution |
|---|---|---|
| Unit does not turn on | No power supply | Check power cord connection and wall outlet. |
| Poor airflow | Blocked air intake/outlet or dirty filter | Clear any obstructions. Replace filters if indicated by the app or if airflow remains low. |
| Unusual noise | Foreign object inside or unit not on level surface | Unplug and check for foreign objects. Ensure unit is on a stable, level surface. |
| App connectivity issues | WiFi signal weak or incorrect setup | Ensure unit is within WiFi range. Re-pair with the Dyson Link app if necessary. |

If the problem persists after attempting these solutions, please contact Dyson customer support.

## 8. Specifications

| Feature | Detail |
|---|---|
| Brand | Dyson |
| Model Number | Dyson Pure Cool Link DP01 |
| Product Dimensions | 13.85"D x 8.7"W x 24.25"H |
| Weight | 10.18 Pounds |
| Color | White/Silver |
| Wattage | 70 watts |
| Connectivity | WiFi enabled (Dyson Link app) |
| Filter Type | Sealed HEPA and Activated Carbon |
| UPC | 885609014753 |

## 9. Warranty and Support

Your Dyson Pure Cool Purifying Fan DP04 comes with a manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Dyson website. For technical support, replacement parts, or further assistance, please contact Dyson customer service through their official channels.
**Dyson Official Website:** www.dyson.com

© 2023 Dyson. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07BJDSKS8**

More documents and user manuals: **https://manuals.plus/**